

Product Datasheet - Technical Specifications



More information in our Web-Shop at ► www.meilhaus.com and in our download section.

Your contact

Technical and commercial sales, price information,
quotations, demo/test equipment, consulting:

Tel.: **+49 - 81 41 - 52 71-0**

FAX: **+49 - 81 41 - 52 71-129**

E-Mail: sales@meilhaus.com

Downloads:

www.meilhaus.com/en/infos/download.htm

Meilhaus Electronic GmbH | Tel. **+49 - 81 41 - 52 71-0**
Am Sonnenlicht 2 | Fax **+49 - 81 41 - 52 71-129**
82239 Alling/Germany | E-Mail sales@meilhaus.com

Mentioned company and product names may be registered trademarks of the respective companies. Prices in Euro plus VAT. Errors and omissions excepted.
© Meilhaus Electronic.

www.meilhaus.de

User Manual

Medical Isolator

MI 1005

Galvanic Ethernet Isolator
for medical electrical appliances
in accordance with

IEC/EN 60601-1 and IEC/EN 60601-1-2



Table of Contents

| | |
|------------------------------------|----|
| 1. General Safety Advise | 3 |
| 1.1 Location..... | 3 |
| 1.2 Connection | 3 |
| 1.3 Environmental Protection..... | 3 |
| 1.4 Meaning of used symbols..... | 3 |
| 2. Intended Use | 3 |
| 3. Installation | 4 |
| 4. Maintenance | 4 |
| 5. Cleaning | 4 |
| 6. Declaration of Conformity | 5 |
| 7. Certificate of Compliance | 6 |
| 8. Certificate ISO 9001:2008 | 7 |
| 9. Technical Specification..... | 8 |
| 9.1 Classification | 8 |
| 9.2 Technical Data..... | 8 |
| 10. Delivery Contents | 9 |
| 11. Warranty Regulations | 9 |
| 12. Manufacturer Contact | 11 |

1. General Safety Advise

- a. Before use the following section should be read carefully through to the end.
- b. The **MI 1005** can only be installed and put into operation by qualified and trained personnel.
- c. Do not open the housing; there are no serviceable parts inside. Faulty or defective devices have to be exchanged and returned to the manufacturer.
- d. Before starting the MI 1005, ascertain without fail from the manufacturer of your medical appliances/systems whether they – with sufficient galvanical isolation – permit coupling to the local network (LAN) or to other computer.

1.1 Location

During installation ensure that the MI 1005 is protected from penetration by moisture, high humidity and mechanical damage. It should not be operated in close proximity to atmospheres with combustible composites.

The MI 1005 should also not be operated in close proximity to devices that emit electromagnetically radiation to avoid electromagnetically interferences like for example mobile phones. Potential interferences can be avoided by operating the MI 1005 outside this electromagnetically environment.

1.2 Connection

When connecting the **MI 1005** Medical Isolator please observe that:

- a. you do not connect any telecommunications appliances, voltage supplies or similar to the MI 1005. By doing so, both the MI 1005 and personnel could be harmed!
- b. you only connect network components complying with IEEE 802.3 or IEEE 802.3ab (10/100/1000-BaseT, Twisted-Pair) to the MI 1005.
- c. you use, without exception, tested and approved CAT 6 network cable (with appropriate test mark).

1.3 Environmental Protection

For disposal of the MI 1005 stipulations subject to public law may involve special instructions. Before the final de-commissioning of the appliance, contact the manufacturer.

1.4 Meaning of used symbols



Accompanying documents!

2. Intended Use

The **MI 1005** is an appliance especially developed for use in medical technology. The purpose of the **MI 1005** is to connect, in compliance with the relevant norms for electrical safety (IEC 60601-1) and EMC (IEC 60601-1-2), a medical appliance or system equipped with a network interface to a non-medical appliance or system (Single PC or local network).

Examples for the use of the **MI 1005** :

- Connection to the practice or clinic networks with the PC of a prolonged EEG system
- Connection to an analysis computer in the doctor's or consulting room with an EMG measuring station

Point d. of Chapter 1 - General Safety Advice - is to be observed for this.

3. Installation

Only qualified and trained personnel should connect the MI 1005. Please instruct your network systems administrator or your medicine technology department for this purpose. The installation of the MI 1005 is done by means of the two pluggable connections (RJ-45-sockets). To do this, plug the network connection cable into the socket of the MI 1005, until the lock engages with an audible ‚click‘. The installation of the MI 1005 should be done near the medical appliance/system. The safety advice in Chapter 1.2 – Connection - is to be observed!

4. Maintenance

For maintaining a safe technical condition, an annual inspection is recommended, which includes the following checks:

1. Examination for external damage (housing, network connections, legibility of labeling, dirt, etc.) of the MI 1005 .
2. Examination for substances which may have penetrated, in particular moisture.
3. Function test.
4. Isolation test. The isolation resistance of the MI 1005 should not exceed 20 MOhm. For testing, at both connections all data cables as well as the screen should always be shut down briefly. The isolation resistance should be measured between signal entry and signal exit.
5. Availability and sufficiency of the documents.

Should any deficiency be established during a test, the MI 1005 should not be used any longer, as the safety of the patients and the operator cannot be guaranteed.

In case of doubt please contact your supplier or the manufacturer.

5. Cleaning

Use a dry or a moderately moisturized cloth to clean the MI 1005. It must be noted that no fluids or moisture will penetrate into the device.

6. Declaration of Conformity

EG - Konformitätserklärung

EC declaration of conformity



Baaske Medical GmbH & Co. KG

Bacmeisterstr.3

32312 Lübbecke

Deutschland / Germany

erklärt in alleiniger Verantwortung, dass die Produkte

declares in sole responsibility, that the products

**Typ: MI 1005
MI 1005 E**

mit den grundlegenden Vorschriften der folgenden EG-Richtlinien übereinstimmt,
wenn es für seinen bestimmungsgemäßen Zweck verwendet wird:

*complies with the essential requirements of the following EC-Directives,
if used for its intended use:*

EMV-Richtlinie 2014/30/EU

EMC Directive 2014/30/EU

Niederspannungsrichtlinie 2014/35/EU

Low-Voltage Directive 2014/35/EU

Angewandte harmonisierte Normen oder normative Dokumente:

Applied harmonized standards or normative documents:

IEC 60601-1:2005 / EN 60601-1 : 2006

IEC 60601-1-2:2007 / EN 60601-1-2 : 2007

UL 60601-1 (e342310)

Lübbecke, 14.04.2016

Andreas Baaske (GF)

Ort und Datum der Ausstellung
Place / Date

Angaben zum Unterzeichner
Issuer

A handwritten signature in black ink, appearing to read 'A. Baaske', is written over a horizontal dashed line. Below the line, the word 'Unterschrift' is printed, followed by the word 'Signature' in italics.

Unterschrift
Signature

Diese Erklärung bescheinigt die Übereinstimmung mit den genannten Richtlinien, beinhaltet jedoch keine Zusicherung von Eigenschaften. Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten.

This declaration certifies the conformity with the named directives, but does not contain any assurance of quality. The safety instructions of the instruction manual are to be followed.

7. Certificate of Compliance

Certificate of Compliance

Certificate Number 20110729-E342310
Report Reference E342310-A1-UL
Issue Date 2011 July 29

Page 1 of 1



Issued to: BAASKE MEDICAL GMBH & CO KG
SIEMENSSTRASSE 5
32312 LUEBBECKE GERMANY

*This is to certify that
representative samples of*

MEDICAL EQUIPMENT



Medical isolator - MI 1005, MI 1005 E

*Have been investigated by Underwriters Laboratories in accordance with
the Standard(s) indicated on this Certificate.*

Standard(s) for Safety: UL 60601-1, 1st Edition, 2006-04-26 (Medical Electrical Equipment, Part 1: General Requirements for Safety), CAN/CSA-C22.2 No. 601.1-M90, 2005 (Medical Electrical Equipment - Part 1: General Requirements for Safety)

Additional Information: See UL On-line Certification Directory at WWW.UL.COM for additional information.

Only those products bearing the UL Recognized Component Marks for the U.S. and Canada should be considered as being covered by UL's Recognition and Follow-Up Service and meeting the appropriate U.S. and Canadian requirements.

The UL Recognized Component Mark for the U.S. generally consists of the manufacturer's identification and catalog number, model number or other product designation as specified under "Marking" for the particular Recognition as published in the appropriate UL Directory. As a supplementary means of identifying products that have been produced under UL's Component Recognition Program, UL's Recognized Component Mark:  may be used in conjunction with the required Recognized Marks. The Recognized Component Mark is required when specified in the UL Directory preceding the recognitions or under "Markings" for the individual recognitions. The UL Recognized Component Mark for Canada consists of the UL Recognized Mark for Canada:  and the manufacturer's identification and catalog number, model number or other product designation as specified under "Marking" for the particular Recognition as published in the appropriate UL Directory.

Look for the UL Recognized Component Mark on the product

William R. Carney
Director, North American Certification Programs

Underwriters Laboratories Inc.

Any information and documentation involving UL Mark services are provided on behalf of Underwriters Laboratories Inc. (UL) or any authorized licensee of UL.

For questions, please contact a local UL Customer Service Representative at <http://www.ul.com/global/eng/pages/corporate/contactus>

8. Certificate ISO 9001:2008

CERTIFICATE



ISO 9001:2008

DEKRA Certification GmbH hereby certifies that the company

Baaske Medical GmbH & Co. KG

Scope of certification:

Sales and services in the field of information technology in medical use, computer systems and accessories

Certified location:

D-32312 Lübbecke, Bacmeisterstraße 3

has established and maintains a quality management system according to the above mentioned standard. The conformity was adduced with audit report no. A13101661.

This certificate is valid from 2014-03-21 to 2017-03-20

Certificate registration no.: 100311188/1
Duplicate



DEKRA Certification GmbH
Stuttgart, 2014-02-14



Lack of fulfilment on conditions as set out in the Certification Agreement may render this certificate invalid.

DEKRA Certification GmbH * Handwerkstraße 15 * D-70565 Stuttgart * www.dekra-certification.de
page 1 of 1

9. Technical Specification

9.1 Classification

| | | |
|---|--|---|
| Mark of Origin (Manufacturer) | | Baaske Medical GmbH & Co. KG Lübbecke, Germany |
| Type Designation | | MI 1005 |
| Operating Mode | | Continuous operation |
| Environmental conditions during operation | Temperature | -10°C to +85°C |
| | Relative air humidity | 10% to 90% (not condensing!) |
| | Air pressure | 700 hPa to 1060 hPa |
| Environmental conditions during Storage/Transport | Temperature | -25°C to +85°C |
| | Relative air humidity | 10% to 95% (not condensing!) |
| | Air pressure | 500 hPa up to 1060 hPa |
| | Rated for Altitude | Up to 3000 m |
| Dimensions (L x B x H) | | 65 x 29 x 23 mm |
| Weight | | ~ 50 g |
| Classification | Protection Class | Not applicable |
| | Protection against water penetration | No protection |
| | Degree of protection of the user parts against electric shock | Not applicable |
| | Degree of protection against discharge from defibrillators | Not applicable |
| | Protection during use in the presence of combustible compounds of anaesthetics with air or with oxygen or laughing gas | No protection |
| Connection to the supply | | Not applicable |
| Supply frequency | | Not applicable |
| Power input | | Not applicable |
| Pollution degree | | 2 |

9.2 Technical Data

| | |
|--|---|
| MI 1005 | |
| Max. Isolation Voltage between Ethernet connectors | 5kV AC (50/60Hz 1 Minute) |
| Connection sockets | 2 x RJ45 |
| Network specifications | IEEE 803.2ab 10/100/1000-BaseT, Twisted-Pair, auto-conf (completely transparent in ethernet network, no drivers required) |
| Material | UL94V-0 complying materials / RoHs compliant |
| MTBF | 0,21 x 10 ⁸ (1 Fault in 21 000 000 hrs) |
| Product rating | Passive ethernet isolating device, insulation rating DI (250V AC / 300V DC) tested at 5kVAC |

10. Delivery Contents

- MI 1005
- User Manual
- TP Network Cable CAT6 25 cm (optional)

Check the delivery contents and request any missing items from your retailer immediately.

11. Warranty Regulations

These Representations and Warranties are applicable to all end-customers (the “Customers” and each, individually, a “Customer”) purchasing products (the “Products”) manufactured by Baaske Medical GmbH & Co. KG (the “Company”).

11.1 Warranty and Limitations:

11.1.1 Company warrants solely to the original purchaser of the Products that for the Warranty Period (as defined below), the Products will be free from defects in materials and workmanship under normal use, and will conform to Company’s published specifications of the Products. Notwithstanding the foregoing, Company retains its right to deviate from its published specifications due to the latest innovations and improvements in function and design of the Products. The foregoing warranty is subject to the proper storage, operation, transportation and use of the Products, and does not include defects due to normal unauthorized repairs, wear and tear or deterioration, lightening, fire, excessive voltage, humidity and unsuitable software programs.

11.1.2 Upon delivery, Customer shall immediately inspect the Products for conformity and visible defects. Customer shall give Company written notice of any non-conformities or visible defects immediately, but in no event later than two (2) weeks following delivery, and return the Products to Company at Company’s expense. In the event of any apparent shipping and freight damages of the Products, Customer shall refer any claims to the shipping company.

11.1.3 Customer shall notify Company in writing of any other defects of the Products within two (2) weeks upon discovery, and the Company shall not be obligated to accept any warranty claims based upon later notices. Company’s sole obligation under the foregoing warranty is, at Company’s option, to repair or correct any such covered defect or to replace or exchange the Product. Any repaired, corrected, replaced or exchanged Products shall be subject to the warranty set forth in 1.1., following their repair, correction, replacement or exchange.

11.1.4 With respect to orders made to custom, any defects of the Products caused by Customer’s specifications are excluded from the warranty set forth in 1.1.

11.1.5 Company also makes no warranty that the Products manufactured under an order made to custom do not infringe the intellectual property or other proprietary rights of any third party and Customer is solely responsible for assuring that such Products do not so infringe.

11.1.6 The “Warranty Period” begins on the date on which the Products are being physically delivered to Customer’s site, and continues to be in effect for one (1) year.

11.1.7 Company does not authorize any person or party to assume or create for it any other obligation or liability in connection with the Products except as set forth herein.

11.1.8 All requests and notices under this Warranty shall be directed to:

Baaske Medical GmbH & Co. KG

Service

Bacmeisterstr. 3

32312 Lübbecke, Germany

Phone: +49 5741 236027 - 0

Fax.: +49 5741 236027 - 99

E-mail: support@baaske.net

11.1.9 The warranty set forth in section 1.1 is made in lieu of all other warranties (whether express or implied), rights or conditions, and customer acknowledges that except for such limited warranty, the products are provided “as is.” Company specifically disclaims, without limitation, all other warranties, express or implied, of any kind, including, without limitation, the implied warranties of merchantability and fitness for a particular purpose, non-infringement, and those warranties arising from a course of performance, a course of dealing or trade usage.

11.2 Limitation of liability:

11.2.1 In no event shall company be liable for any indirect, incidental, punitive, special or consequential damages, including but not limited to, damages for loss of profits, revenue, goodwill or use, incurred by customer or any third party, whether in an action in contract, tort, strict liability, or imposed by statute, or otherwise, even if advised of the possibility of such damages. Company’s liability for damages arising out of or in connection with this agreement shall in no event exceed the purchase price of the products. It is agreed and acknowledged that the provisions of this agreement allocate the risks between company and customer, that company’s pricing reflects this allocation of risk, and but for this allocation and limitation of liability, company would not have entered into this agreement.

11.2.2 In jurisdictions that limit the scope of or preclude limitations or exclusion of remedies or damages, or of liability, such as liability for gross negligence or willful misconduct or do not allow implied warranties to be excluded, the limitation or exclusion of warranties, remedies, damages or liability set forth above are intended to apply to the maximum extent permitted by applicable law. Customer may also have other rights that vary by state, country or other jurisdiction.

12. Manufacturer Contact

For queries and problems please contact:

Manufacturer:

Baaske Medical GmbH & Co. KG

Bacmeisterstr. 3

32312 Lübbecke

Germany

Phone: +49 5741 236027 - 0

Fax: +49 5741 236027 - 99

E-mail: sales@baaske.net

Internet: www.baaske-medical.de



Baaske Medical GmbH & Co. KG

Bacmeisterstr. 3

32312 Lübbecke, Germany

Phone: +49 5741 236027 - 0

Fax.: +49 5741 236027 - 99

E-mail: sales@baaske-medical.de

www.baaske-medical.de