

Product Datasheet - Technical Specifications



More information in our Web-Shop at **> www.meilhaus.com**

Your contact

Technical and commercial sales, price information, quotations, demo/test equipment, consulting:

Tel.:	+49 - (0)81 41 - 52 71-0
FAX:	+49 - (0)81 41 - 52 71-129
E-Mail:	sales@meilhaus.com

Meilhaus Electronic GmbH Tel. Am Sonnenlicht 2 82239 Alling/Germany Mentioned company and product names may be registered trademarks of the respective companies. Errors and omissions excepted. © Meilhaus Electronic.

+49 - (0)81 41 - 52 71-0 Fax +49 - (0)81 41 - 52 71-129 E-Mail sales@meilhaus.com

www.meilhaus.com

Keysight U3900DAQ Multiplexing Solution



Demo Guide Edition 1, Dec 2020

Contents

Demo Guide Overview	1
Solution feature and benefits	1
Demo Guide	1
Demo 1: Basic Electronics	2
Overview	2
Objectives	2
Equipment and Accessories Required	3
Software Required	4
Setting up the DUT with ME3000	4
DUT Connection Setup	6
Instrument Setup	8
Setting Up the Function Generator	9
Setting Up the Oscilloscope	10
Setting Up the DAQ Internal DMM	13
Begin Labwork	14
Demo 2: RF Labs	20
Overview	20
Equipments and Accessories Required	20
Software Required	21
Demo Setup	21

Demo Guide Overview

The demo guide is to help you to promote key values of Keysight Data Acquisition and Switching Solutions to the audiences. Please always convey these messages to the audience before the demo. For more info, please refer to <u>kesyight.com</u>

The Keysight U3900DAQ is an automated test system with excellent measurement performance on accuracy, resolution, and speed. Powered by an industry-proven and software-controlled switching system, the U3900DAQ covers a broad spectrum of switching and routing requirements for the teaching lab. Is easy to use for data logging and monitoring applications, either stand-alone or with a computer.

Solution feature and benefits

- A complete selection of plug-in modules provides high-quality measurement, switching, and control capabilities
- 20 Channel Multiplexer + 2 Channels for dedicated current measurement
- 20 Channel Actuator/General Purpose Switch
- Dual 4 Channel RF Multiplexer

Demo Guide

There are 2 demos for selection:

- <u>Demo 1</u>: For Basic Electronics Lab U3900DAQ + ME3000 (DUT). To demonstrate the capabilities of performing switching and multiple measurements with a single setup.
 Ordering information:
 - 1. U3900DAQ (is included in the demo transit case with all the accessories needed)
 - 2. Oscilloscope (proposed model DSO1002A 60 MHz Oscilloscope or equivalent)
 - 3. 2x oscilloscope probes (N2863A 10:1 ratio probe)
 - 4. Function/Arbitrary Waveform Generator (proposed model 33220A 20 MHz or equivalent)
- <u>Demo 2</u>: For RF Lab U3900DAQ (DAQM905A) + U3851A (DUT). To demonstrate the RF switching capability of the RF Mux, hence realizing the remote learning.

Ordering information:

- 1. U3900DAQ (is included in the demo transit case with all the accessories needed)
- 2. U3851A
- 3. Keysight FieldFox N9917A

Demo 1: Basic Electronics

Overview

This demo will demonstrate a half-wave rectifier circuit as shown in Figure 1. When the sinusoidal input voltage (Vi) goes positive, the diode is forward biased and conducts current through the load resistor. The current produces an output voltage (V_o) across the load which has the same shape as the positive cycle of the input voltage. When the input voltage goes negative, the diode is reverse biased. Thus, there is no current or voltage flow across the load. The net result is only the positive half cycle of the input signal appearing across the load as shown in Figure 2(b).



Figure 1 – Half-Wave Rectifier Schematic Diagram



Figure 2 – Half-Wave Rectifier Input and Output Voltages

Objectives

- i. To demonstrate the operation of half-wave rectifier circuits
- ii. To demonstrate the switching concept through DAQ and measure the output voltage waveform with different load and capacitor filters on various rectifier circuits.

Equipment and Accessories Required

Provided in the U3900DAQ transit case:

- i. Keysight DAQ970A Data Acquisition System (pre-slotted with 3 modules)
- ii. ME3000 Analog Electronics Training Kit
- iii. 1 x BNC(m)-to-grabber clips coaxial cable
- iv. 1 x antistatic wrist strap
- v. 8x grabber clips to pigtail jumper cables.
- vi. 11x pigtail to 2-ways 2.54mm connector (F) jumper cables pair

NOT provided:

- 1. Windows 10 Laptop/PC
- 2. Keysight DSO1002A 60 MHz Oscilloscope
- 3. 2x oscilloscope probes (10:1 ratio probe)
- 4. Keysight 33220A 20 MHz Function/Arbitrary Waveform Generator

Software Required

- i). Keysight BenchVue PC software with the following BenchVue app installed:
 - a. DAQ app
 - b. OSC app
 - c. FG App
- ii). Keysight Connection Expert

Caution:

An electrostatic discharge generated by a person or an object coming in contact with electrical components may damage or destroy the training kit. To avoid the risk of electrostatic discharge, please wear the antistatic wrist strap and observe the handling precautions and recommendations contained in the EN100015-1 standard. Do not connect or disconnect the device while it is being energized.

Setting up the DUT with ME3000

- 1. Please ensure all the connector (F) jumper cables and grabber clips are connected to the DUT according to the Test Point (TP0 and Jumper (J) location.
- 2. Locate the Diode Circuit section on the ME3000-M1 training kit.
- 3. Disconnect all the jumpers located in the Diode Circuit section.
- 4. Connect the Function Generator, Oscilloscope, ME3000 training kit and the DAQ970A according to the diagram below:



DUT Connection Setup









Instrument Setup

- 1. Connect the Oscilloscope, Function Generator and DAQ to your PC using their provided USB cables.
- 2. Turn ON the Oscilloscope, Function Generator and DAQ instruments.
- 3. Run the Keysight BenchVue software and **launch the Keysight BenchVue DAQ App** and load the attached DAQ instrument state (.state file) for Half Wave.

ME3000_HalfWave rectifier.state

NOTE: Drag and drop the state file to your PC to use it with BenchVue software.



If you are asked to load a configuration, select Create NEW (Default).

- 5. Please ensure Keysight DAQ970A Data Acquisition System pre-slotted with the following modules installed:
 - a. Slot #1: Keysight DAQM901A 20 channels Multiplexer
 - b. Slot #2: Keysight DAQM903A 20 channels Actuator/GP Switch
 - c. Slot #3: Keysight DAQM905A Dual RF Switch

IMPORTANT

Make sure that the DAQ modules are installed to the specified slots according to the list above. Failure to do so will cause the provided instrument state files unable to be restored successfully.

4. After loading the state file, you should see the switch set up according to the picture below:



Setting Up the Function Generator

- 1. Launch Function Generator App by double-click the Keysight 33220A, which is located on the Instrument Tab (on the right side of the screen).
- Set the function generator output to a 10 kHz sine wave. Adjust the amplitude to 5 V peak-topeak. On the Output function tab, set the Load to High-Z by enabling it. After that, set the Output to ON.

Channel 1			Output On	Click	to set ON
- Select Waveform	<u>~</u> ъ ии		(<u>•</u>	
Amplitude:	• S Vpp	1 requency: •	10 kHz		
Offset:	• 0 Vdc	Phase:	0 deg 2		
Odina					
Polarity:	Normal •	Load:	50.0		
			Iligh-Z 3		
			Ŭ		
- Sync Output					
Enable Sync i	Out				

Setting Up the Oscilloscope

 Launch Keysight BenchVue Oscilloscope by double-click the Keysight DSO1002A which is located on Instrument Tab (on the right side of the screen). We will be setting the Oscilloscope according to the table below:

Setting	Value
Voltage /Div	1V
Voltage Level Position	0V
Time/div	50 us
Trigger Control	Edge
Trigger Source	Channel 1
Trigger Mode	Auto



🔺 Instrument Settin	web UE	Screen 3mage	Trace Data	iii Mea	surement / Trace D	otalog	-			
4 Settings		11/	V ~ 🔳	5V/ /	V ~ 5	v/ 🛝	~ _ ×	ys/ A	V V Run C	ontrol
Default Setup	Auto Scale	Î ev	× • •	οv -		v 🔻	· ·	- 10		top Single
Oscilloscope Setting		8		The second second						9
Trigger										Ý
Tripper Control:	Edge	- K								
Source:	Channel I		0	- ·	C		-			2
Steps:	Positive	· /	Set the .	l rigger	Source	5	Set Tin	ie/div t	to 50 us/	div
Level			to:							
Mode:		_	 Co 	ntrol -	Edge		\sim	*	\sim	2
Huld Off:	60 ms		 So: 	11000	Channel	1				
HF Reject:	OF	• 20	- 30		Jiannei	i s	50 yrs	200 pm	150 ps 200	yn 250 yn
Noise Reject:	of	•	• Mo	ode - A	uto					
Resurements		• Stariate	s		(3	n Pause Updat	94]		
Heat	urements		Heating	Carriet	Heat	Ma	Max	Std Dev	Court	
Satstics			Ph: Ph(1)	4.34 ¥	3.445 V	160 mW	6.44 V	2.128 V	2956292	
Deploy On			Pk-Ph(2)	1.28 V	220.39 mV	130 mW	2.76 V	193.555 mW	2990621	
Feset	Increment									
 New Setup 										

2. To obtain the peak-peak voltage (Vpp) reading on Channel 1 & 2, Click "Measurement" and enable Channel 1 on 2 on **Vpp** section

4 Settings	1 Heasurements X ↓ ■ 1 V/ A	Single
Occloscope Settings	I a waxe	
• higger	Maiman Den Sources	Ø
Measurements	pk.pk 1 2 1 OtherSources +	
Measurements	And Average	
Display On	Anglitude II II II OtherSources	
Reset Increment	1 Base 2 8 8 00 OtherSources	
Prois Setup	0 Time	
• Curson	Images representation Images representation	
		···· <1

5. Click the Display on to show the measurement reading on Channel 1 and Channel 2

Instrument Settings 👘 Web UI [🚺 Screen	Image 🔚 Trace Duta	Measurement / Trace D	stalog		Puerlan Generator
4 Settings	5V/ 4/~	11/ 1/~	5V/ V~	5 V/ V ~ Ran Control	
Default Setup Auto Scale	-10.48 V 💌 🔺 📟	3.256.V	60 mV	OV V Step	Single 2
Outbacage Settings	R	pronononon			Collector
• haper					
Measurements	**				+ Add
Resurements					å 🗳
Statistics					
first Increased	$ \rightarrow $				T Sected Control CONT Put
Heas Setup					
• Curson	-100 ps -40 ps -40 p	s 40 ps -20 p	s Us 28 ps Tone	et he on he on he t	70
		🖲 Trace Pre	view Screen Pause Update		
	• Statiatica				
	Measure 0	Current Mean	Me Max	Std Dev Court	
	Pk Ph(1)	8.4 V 8.514 V	8.3V 8.8V	104.513 mV 367994	
	M-M(2)	2.8LV 2.81V	130 m¥ 2.94 ¥	33.335 mN 367172	
Start				0 1 1 0 0 0	P Equat

Setting Up the DAQ Internal DMM

- Use the built-in DMM to measure the circuit output. Go to the DAQ app > Configure Channels.
- 2. Select MUX01 and MUX02 for scanning.

i≣c₀	nfigure Channels	- → → → → Digitize	er Channels	А́⊢е	raphics Setu	p	-
	Channel			١	1easurement		
Scan	Number	Name	Function		Range		R
\odot	DAQM901A:20-C	hannel Armatı	ure Multiplexer				
	101	MUX01	DC Voltage	•	Auto	•	5.
Z	102	MUX02	DC Voltage	-	Auto	•	5.
	103		DC Voltage	•	Auto	•	5.
	104		DC Voltage	-	Auto	-	5 1

3. Click the monitoring button.

i≣co ∢	onfigure Channels	- ↓ ← Digitize	er Channels 🛛 😽	hα	Graphics Setu	p	+ No	ne Of	f		Ø]
	Channel			j	Measurement						s	icali
Scan	Number	Name	Function		Range		Res	More	Scale	Function		Ga
\odot	DAQM901A:20-C	hannel Armatu	ure Multiplexer									
~	101	MUX01	DC Voltage	•	Auto	•	5.5 🗖			SCAL	•	1
 Image: A second s	102	MUX02	DC Voltage	•	Auto	•	5.5 🗖			SCAL	•	1
	103		DC Voltage	-	Auto	-	55 -			SCAL	-	1

4. Select MUX01 to get DC voltage reading of the transformer output.

Monitor Channel Properties	8	×
Monitor Channel		
Select Channel: None		
None		
Binary Data Format 101-MUX01 (Vdc)		
Decimal Decimal Decimal Decimal		
Color		
Background 👻 🔲 🗸		
Ok	Canc	el

5. You will able to see the reading.



Note: You can switch to MUX02 to get the Vdc reading of the circuit output.

Begin Labwork

 Go to the BenchVue DAQ App and switch 214 & switch 215 remains off by default. This is to connect FG to the diode circuit (via TP9 & TP10) to TP15 & TP16) and to form a Half Wave rectifier setup.



2. Close J3_D1, J9_R3 and J10_R3 switches.



3. You have now constructed the Half-Wave Rectifier circuit and you can now observe the waveform on the BenchVue Oscilloscope App.



4. Open J9_R3 and J10_R3 and then close J11_R4 and J12_R4 switches.

This will replace the R3 with R4 as the load.





13. Open J11_R4 and J12_R4 and then close J5_C2 and J6_C2 switches. This will replace R4 with C2 as the load.

NOTE

You can set the time/div from 50 us to 150 us on BenchVue Oscilloscope App to observe clearer rippled output voltage on Channel 2(Green).



5. Open J5_C2 and J6_C2 and then close J7_C3 and J8_C3 switches. This will replace C2 with C3 as the load.

6. **Open J7_C3** and **J8_C3** and then **close J9_R3**, **J10_R3**, **J11_R4** and **J12_R4** switches. This will replace **C3** with **R3 & R4** in parallel as load.



7. Open all MUX and switches.

Demo 2: RF Labs

Overview

This demo will demonstrate the capability of the RF Multiplexer which offer broadband switching. The capability is one of the keys to realize the RF lab remote learning. In this demo, we will make S-parameter of two DUT: a lowpass filter and a transmission line. Once the connection is set up as below, we will make use of BenchVue as the user interface for to achieve the remote-control portion.



Equipments and Accessories Required

In the U3900DAQ

- i). Keysight DAQ970A Data Acquisition System with DAQM905A (pre-slotted slot 3)
- ii). USB Type A to Type B cable x1
- iii). X-microwave coaxial connector U3851-22100 x1

In the U3851A

- iv). Education hardware kit U3851-66500 x1
- v). SMA M-M cables U3851-61700 x2
- vi). N type (M) to SMA (F) adaptors U3800-37603 x2
- vii). 8lb-in, 5/16 Inch torque wrench 8710-1765x1
- viii). Hex screwdriver U3851-33801 x1
- ix). LAN Cable 34980-61614 x1
- x). Keysight FieldFox N9917A or anything similar
- xi). Windows 10 PC

Software Required

- iii). Keysight BenchVue PC software with the following BenchVue app installed:
 - a. DAQ App
 - b. FieldFox App
- iv). Keysight Connection Expert

Demo Setup

 Place the X-Microwave probes on below locations as shown below. By default, there are only 3 X-microwave probes on the education hardware kit, please get the 4th one from U3900ADAQ. You may use hex screwdriver in helping move those X-Microwave probes.



2. **Connect** the educational hardware kit, FieldFox, and DAQ following the diagram below. The **yellow labels** on the SMA(M)-SMB(F) cables will help you setting the connection up. Do take note that the polarity is not important as both DUTs are passive component.



- 3. Connect the FieldFox and the DAQ to the PC with LAN cables (in the U3851A) and USB cable (in the U3900ADAQ) respectively.
- 4. Launch the BenchVue software. Make sure all the instrument that will be used in this demo can be found at the right-hand side column, else please **add them in**.

Keysight BenchVue	🕇 Home 🗸	0	° 🗭 🗘 🛛 – 🕫 ×
BenchVue 2020			Instruments
	Welcome to BenchVue BenchVue makes it simple to connect, control instruments, and automate test sequences for guide access to your test results. Start here	What do you want to do? \leftrightarrow Connect to my instruments install a BenchVue license · Hore Topic	Add A
		Recent Activity Recent Applicators:	Spectrum Analysis
	Library View manuals, application notes, videos, Test Flow examples, and more.	MA. Find. Bendfikith: for Bendfikast-Filter.buscq 6/38/2020 514-92 AI Variable: Simple.buscq 6/38/2020 518-92 AI Variable: Simple.buscq 6/38/2020 518-92 AI Variable: Simple.buscq 6/38/2020 518-92 AI Chrangendar Zaraffikter.buscq 6/38/2020 518-22 AI Dorg, Editional Simple Markan Mark Mitchahamatelsamped Marghanat, Fra. 6/38/2020 513-52 AI Dorg, Editional Simple Markan Mark Mitchahamatelsamped Marghanat, Fra. 6/38/2020 513-52 AI Rock_Editional Simple Markan Markan Markanatelsamped Marghanat, Fra. 6/38/2020 513-52 AI Proverside Variabilitatel Simple Markanatelsamped Marghanat, Fra. 6/38/2020 512-52 AI Proverside Variabilitatel Simple Markanatelsamped Marghanat, Markanatelsamped Marghanatanatelsamped Marghanatanatelsamped Marghanatanatelsamped Marghanatelsamped Marghanatanatelsamped Marghanatanatelsampe	Signal Generator 152,24,131 Control Co

5. Launch the FieldFox App and choose the "**NA Mode**". The FieldFox App is used for network analysis. Results can be viewed real time here.

Su	pported FieldFox Modes
	Switch to SA Mode
	Switch to NA Mode

6. Next is to setup up the screen to view result that is making sense. The low pass filter has a cutoff frequency ~200MHz. My advice will be setting up S11 and S21 trace with start and stop frequencies at 30kHz to 500MHz respectively. The state file here was created with N9917A. That should work on all FieldFox on BenchVue.



7. Switch "On" the Trigger Continuous to make sure the data is live and hit "Start".



8. **Launch the DAQ app**. The DAQ App used for changing the path of DUT that connects to the DAQ. The DAQ app will automatically detect all modules that are slotted in the DAQ970A mainframe. At the configure channel page, look for DAQM905A and expand it.

Keysight BenchVue 🕇 Ho	ome > Benc	h v													-	6.	• • 0 • • • •
Start All 🛑 Stop All 🔛 🎥 🕞 I	Export All Bench La	yout: 28 00 1													er Ber	hchVue Test Flow	Instruments
10AQ // DAQ970A // 16.82.100.215 🕹 🕑 건 추 🗙																	
Instrument Settings Data Logging Settings	E Configure Chan	nels 🕂 Oigil	tizer Channels	Gra	phics Setup	+ None	Off		🛞 HW Alai	m 12	2.4]					DAQ
Slot 1: DAQM903A +	Char	nel		Me	asurement				Scaling (Mx	+ B)						Alarm Limits	10.42.100.215
20-Channel Actuator/General-Pu	Scan Number	Name	Function	8	lange	Res M	ore Scale	Function	Gain (M)	Offset (B)	Units	More	Alarm Type	Low	High	∆ Band After N	+ Add
Version: 01.02	DAQM903A:20-0	Channel Actuator/	General-Purpose	Switch													
C Shet 21 DADMODEA -	DAQM905A:Dua	I 4-Channel RF M	ultiplexer (50 oh	ms)													
and 2. Distance -	211		Close	•													Network Analyzer
Dual 4-Channel RF Multiplexer Marsion: 01.02			Open	•													10.82.97.22
Control of the	213		Open	•													No. of Concession, Name
Slot 3: DAQM901A +	214		Open	•													1
	221		Close	•													Signal Generator 10.82.97.179
Scan Module Switch Module	222			•													O
20-Channel Armature Multiplexe Version: 01.02	223		Open	•													
	224		Open														Construct Andrews
More Settings		nannel Armature	Multiplexer	and diverse													
	DAQ970A Comp	uted Channels:20	-Built In Compu	ted Chann	eis												
	Computed Chan	neis +															
																	Spectrum Analyzer 169.254.18.210
																	Power Sunnly
																	9
																	The second second
																	Signal Generator 10.02.90.101
																	0
																	=
A															*	- 0 - ·	
V Start															φ H	Export	

The table below shows the connected switches connected to the DUT. The switches will come in **pairs**. Make sure the switches are in "**Close**" mode if you want to measure the DUT.

DUT	Switches
Filter	313,323
Transmission Line	314,324

9. Interchange between the two DUT and look at the S parameters on the BenchVue FieldFox App.