

Product Datasheet - Technical Specifications



More information in our Web-Shop at ▶ www.meilhaus.com

Your contact

Technical and commercial sales, price information, quotations, demo/test equipment, consulting:

Tel.: +49 - (0)81 41 - 52 71-0

FAX: +49 - (0)81 41 - 52 71-129

E-Mail: sales@meilhaus.com

















Wireless data logging at 1 kS/s (1 ms)

330-channel portable logger available with your choice of plug-in modules and wireless modules





Two models: Standard Model and Wireless LAN Model



Standard model (designed for use with plug-in modules only)

LR8450

You can add up to 4 plug-in modules which provides 120 channels of measurement






Configuration example: 120 channels of analog input

Plug-in units

VOLTAGE/TEMP UNIT U8552×4

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Add four units for 120 channels of measurement.

Depending on various scenes, you can freely combine six types of plug-in modules





Configuration example: 60 channels of analog input + 1,000 channels of CAN input

Plug-in units

VOLTAGE/TEMP UNIT U8552×2 CAN UNIT U8555×2

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Each CAN UNIT U8555 accepts 500 channels of input.

Wireless LAN model

Add channels freely via either plug-in or wireless modules

Can also be used exclusively with wireless modules



Wireless LAN model LR8450-01

Add up to 7 wireless modules in total for a maximum of 330 channels

Configuration example: 330 channels

Plug-in modules

VOLTAGE/TEMP UNIT U8552×4



Wireless modules

WIRELESS VOLTAGE/TEMP UNIT LR8532×7



With four U8552 VOLTAGE/TEMP UNITs and seven LR8532 WIRELESS VOLTAGE/TEMP UNITs, you can measure a total of 330 channels.

Mix plug-in and wireless modules

Mixing and matching plug-in modules and wireless modules will allow you to build a measurement system that suits your needs.*1

If wireless modules are used with other modules (wireless or plug-in), the sampling-timing shift between the units is periodically corrected.*2

In addition, at times when the wireless communication is cut off, the correction function works after the communication is restored and the sampling-timing shift between the modules is corrected.

^{*1} Up to four CAN modules can be used at the same time. (Plug-in and wireless modules may be used in any combination.)

^{*2} Even in good wireless communication conditions (low interference) the sampling-timing between modules may shift about 20 ms. In bad wireless conditions, the sampling-timing shift will be much worse than this.

Voltage measurement



Measure outputs from a pressure sensor and other sensors at 1 kS/s max. sampling rate (1 ms interval sampling)

1 kS/s sampling is necessary to record outputs of several tens of Hertz from pressure sensors and vibration sensors.







WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

Temperature measurement



Measure temperature near inverters and batteries at a sampling rate of up to 100 S/s (10 ms interval sampling)



VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552(*)




WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532(*)

Consistent sampling rate even with added modules

Battery temperature rise

Each module incorporates its own A/D converter. This design keeps the maximum sampling rate high even when Modules are added.



Example 1: use four U8553 HIGH SPEED VOLTAGE UNITs (with 5 channels each) to measure 20 channels at a sampling rate of 1 kS/s (1 ms).

Example 2: Use four U8550 VOLTAGE/ TEMP UNITs (with 15 channels each) to sample 60 channels at a sampling rate of 100 S/s (10 ms).

Consistent noise resistance even with added modules


Since increasing the number of modules has no effect on the cutoff frequency, which changes with the sampling rate, power supply noise can be reduced without sacrificing noise resistance.

(ex.) Samplr	ig rate: 1 S/s
Number of channels	Cutoff frequency
1 ch to 15 ch	60 Hz
16 ch to 30 ch	60 Hz
31 ch to 45 ch	60 Hz
46 ch to 60 ch	60 Hz
*When using a power supply	
frequency of 60 Hz.	Samo cutoff

frequency

Set filters

Set filters for each module



The cutoff frequency, which varies with the data refresh interval, can be set separately for each module. You can use long data refresh intervals, which boost filter effectiveness, and short data refresh intervals for different modules at the same time.

- Measure control signals at maximum speed: module1 (data refresh interval: 1 ms)
- Measure battery voltage fluctuations: module 2 (data refresh interval: 1 ms)
- Measure temperature using thermocouples: module 3 (data refresh interval: 1 s) with strong filter

^{*}Sampling rate of 100 S/s (10 ms) is available when using 15 or fewer channels.

Strain measurement

Measure strain with a 1 kS/s sampling rate (1 ms)

Connect strain gages directly and measure at a sampling rate of up to 1 kS/s. Strain gages tend to have long, thin wires that are easily broken, but that potential pitfall can be avoided by using wireless modules so that wiring is minimized.






STRAIN UNIT U8554

WIRELESS STRAIN UNIT LR8534

Connect strain gages directly

The strain units have a built-in bridge box, allowing you to connect strain gages directly to their input terminals.



Strain-gage-type converters such as load sensors and pressure sensors can be connected directly to make measurement.





Reduced influence of noise


Stable measurement, even at high voltages and high frequencies

Most competing loggers are incapable of measuring temperature accurately in noisy environments due to the influence of high frequencies, causing values to shift or fluctuate significantly. The LR8450 uses a new design to dramatically reduce the influence of high-frequency noise.

Example: measure temperature by connecting the tip of a K thermocouple to the screw on an inverter's PWM output terminal (W-phase) when using the U8550 VOLTAGE/TEMP UNIT (settings: 10 S/s sampling in the 100°C f.s. range).








Most competing loggers exhibit significant fluctuations when the inverter is operating, whereas the MEMORY HiLOGGER LR8450 does not.

CAN measurement NEW



One instrument, two uses: **CAN input + CAN output of measured values**

	U8555	LR8535
Input: CAN and CAN FD	Yes	Yes
Output: CAN and CAN FD	Yes	No



Receive CAN signals using a contactless, wireless setup!

Wireless modules interoperate flawlessly with the NON-CONTACT CAN SENSOR SP7001-95! Supply power from the battery-driven wireless unit to the NON-CONTACT CAN SENSOR SP7001-95 via USB to implement a wireless CAN measurement setup that requires no external power supply. (The system can operate for about



five hours on battery power.) Since no ECU analysis tools or computer is required, the setup takes little space to reduce the amount of wiring needed for driving tests.

Convenient function 1 Notification when a specific ID is received

Start and stop measurement when a CAN signal with a specific ID occurs



Convenient function 2 Bit mask trigger function

Set a trigger that corresponds to a particular pattern with the bit mask trigger function. For example, this function can be used when you wish to start recording when a control signal exhibits the specific pattern of "10101010."

Support for multichannel measurement: receive up to 500 channels with 1 module

As a result of electrification, automobiles now use enormous quantities of data internally, and the amount of data on CAN buses consequently is growing. A single CAN module can capture up to 500 channels*1 of data. The LR8450 can accommodate up to four modules, allowing you to measure up to 2000 channels of CAN data. Each channel can collect information for one signal

*1 With a recording interval of 100 ms

Convenient function 3 Sending user-defined CAN frames

Sometimes it's necessary to send a CAN signal to an ECU in advance so that the ECU will output data to the CAN bus. With the U8555, you can send userdefined CAN frames to a CAN bus while performing CAN measurement.

One-time transmission

When you need to send a CAN control frame once in order to change an ECU's operating mode

Repeated transmission

When an ECU won't output the value you wish to capture unless you send specific CAN data each time





CAN UNIT U8555CAN and CAN FD input or output



WIRELESS CAN UNIT LR8535

CAN and CAN FD input only





CAN Editor (standard CAN configuration software accessory)

Install this software from the application disc that comes with the MEMORY HiLOGGER LR8450 onto a PC to easily configure CAN Unit settings.

Setting method Online or offline


Save settings configured using the CAN Editor in the CES format and then load them with the LR8450. You can also configure instruments offline when a LAN or USB connection is difficult to patch light.

Receive mode Loading DBC files

In addition to setting up channels manually, you can complete CAN communication definition settings simply by loading a DBC file.

Output mode Automatically configuring output targets

Creating output communication definitions one channel at a time for a logger that's handling a large number of channels is extremely time-consuming. With the CAN Editor, you need only specify the start ID and click the "Configure Automatically" button to complete all communication definitions. Those definitions can then be output as a DBC file and loaded onto an upstream system to complete the configuration process.



Wireless for ease of use

Collect data from dispersed locations all at the same time

The LR8450-01 can simultaneously collect measurement data from wireless units installed on various test equipment.

Collect measurement data from multiple locations with a single logger

Manage data in a single time sequence

Units can be placed in confined locations

Check the display during measurement



Up to 30 m* (line-of-sight)

* Better connection may be attained from placing the LR8450-01 and/or wireless module on the floor or ground for a shorter communication distance.



Peace of mind in the event of an interruption in power or wireless connectivity

Peace of mind if communications are temporarily interrupted

Buffer memory holds up to 5 min.*1 of measurement data

Each wireless unit has a built-in buffer memory that can hold up to 5 min.*1 of measurement data. Data are resent along with more recent measurement data once communications resume, after which the data are restored inside the LR8450-01*2.

The system can be configured to output an alarm if communications are interrupted or if a module encounters a low-battery state.

- *1 The duration for which measurement data can be maintained does not vary with the recording interval (up to a maximum of 5 min.)
- *2 Data collected using the Logger Utility software measurement cannot be restored in this manner.

Battery operation


Use modules in locations where there's no AC power

Example

The wireless VOLTAGE/TEMP UNIT LR8530 can operate for about 9 hours on battery power. If the unit is charged at night, it can operate on just the battery pack during the day.

Using the Battery Pack Z1007

Wireless module model	Continuous operating time
LR8530	Approx. 9 hr.
LR8531	Approx. 7 hr.
LR8532	Approx. 9 hr.
LR8533	Approx. 9 hr.
LR8534	Approx. 5 hr.
LR8535	Approx. 10 hr.*



Peace of mind in the event of a power outage during measurement

Install a battery pack for peace of mind

If you've installed a battery pack in a module that's being powered by an AC adapter, the unit will automatically switch to battery power in the event of an outage so that the LR8450-01 can continue making measurements.



Make measurements in locations where it would be difficult to route wires

Work time can be reduced using the LR8450-01 and wireless modules, since only minimal wiring is required. If the measurement target is located in a lab, this approach eliminates the need for wiring and avoids having to drill holes in the walls of the monitoring room where data is being checked.

Inside a room, or outside, you can make measurements with the door closed.



Simple registration of wireless modules

Wireless modules, located within the range, that are not connected to another LR8450-01, can be automatically detected. Simply choose the module you wish to register from the list.








Check the unused wireless LAN channels and select the wireless channel to use

You can reduce interference from other wireless devices by using an open channel (wireless frequency range being used by wireless devices in the area). Check for open channels on the instrument's screen.






Observe data from a remote location using a PC or a tablet

By connecting the LR8450-01 to a PC or a tablet via wireless LAN, you can control the instrument remotely using the built-in HTTP server or obtain older data files using the built-in FTP server.

(You cannot use Logger Utility when using Station Mode or Access Point Mode. See below.)



Easy-to-read display of measured values




External control terminals and interfaces to accommodate a broad range of use cases



Motor speed, flow rate integration, etc.


8 channel pulse measurement



In "Revolve" mode, monitor production equipment by measuring the variations in revolution speed of motors or drills. In "Count" mode, identify operation status by acquiring integrated power or flow rate.

Useful in preventive maintenance


8 channel alarm outputs



You can set alarm output for eight channels. You can set a level, a window, a slope, and a logic pattern on channels you wish to monitor.

Two terminals for voltage outputs (5, 12, or 24 V)

Supplying power to the sensors



The LR8450/LR8450-01 provides two output terminals for voltages, each of which can supply 100 mA current, eliminating the need for a separate sensor power supply. You can select 5 V, 12 V, or 24 V from the VOUTPUT1 terminal and 5 V or 12 V from the VOUTPUT2 terminal.

Replace storage media during real-time saving

No need to stop recording

When you remove the storage media while recording data, and reinsert it, data remaining in the internal buffer memory will continue to be stored in a new and different file.




Extensive calculation functions

Numerical calculation function

In addition to the maximum and minimum value calculation functions provided by previous models, the LR8450/LR8450-01 offers an extensive range of calculations, including on/off time, count, and usage ratio.




Types of calculations



Waveform calculation function

Calculate data while measurement continues and display calculated waveforms in real time. Calculation results are saved on a separate and dedicated calculation channel.



Types of calculations

Basic arithmetic operations

Aggregation

Simple average

Moving average

Integration

Recording over extended periods of time without interruption

Collect data on a storage device (SD memory card or USB drive) while measuring continues. The ability to segment files by hour or day without stopping measurement is convenient when you need to review data later.



Maximum recording time (estimate)

Example: Recording 30 analog channels with 2 modules (no alarm output or waveform processing)

Because the header portion of waveform files is not included in capacity calculations, expected actual maximum time is about 90% of those in the tables. The maximum recording time varies with the number of measurement channels. Recording times are doubled if the number of measurement channels shown in the table is halved.

When recording 30 analog channels with two U8550/U8551 modules or one U8552 module (no alarm output, no waveform processing) When recording 30 analog channels with two LR8530/LR8531 modules or one LR8532 module (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
10 ms	1 d	3 d 20 h	15 d 8 h	30 d 12 h
100 ms	10 d 8 h	38 d 18 h	153 d 9 h	305 d 5 h
1s	103 d 13 h	387 d 12 h	1,533 d 21 h	3,052 d 9 h
10s	500 d	3,875 d 6 h	15,339 d 3 h	30,523 d 19 h

When recording 20 channels with four U8553 modules or U8554 modules (no alarm output, no waveform processing) When recording 20 channels with four U8553 modules or LR8534 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
1 ms	3 h 43 min	13 h 56 min	2 d 7 h	4 d 13 h
10 ms	1 d 13 h	5 d 19 h	23 d	45 d 18 h
100 ms	15 d 12 h	58 d 3 h	230 d 2 h	457 d 20 h
1s	155 d 8 h	581 d 7 h	2,300 d 21 h	4,578 d 13 h
10s	500 d	5,813 d 1 h	23,008 d 20 h	45,785 d 20 h

When recording 330 channels with four U8552 modules and seven LR8532 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
20 ms	4 h 8 min	15 h 28 min	2 d 13 h	5 d 2 h
100 ms	20 h 42 min	3 d 5 h	12 d 18 h	25 d 10 h
1 s	8 d 15 h	32 d 6 h	127 d 19 h	254 d 8 h
10s	86 d	322 d 16 h	1,277 d 23 h	2,543 d 9 h

Control the instrument remotely and capture data on a PC


HTTP server function

Control the instrument remotely from a PC

Use a standard Web browser to control the LR8450/LR8450-01, start and stop measurement, then enter comments.

Use a mouse to operate waveforms displayed on a PC

Enjoy intuitive mouse-based control, including waveform scrolling and cursor operations.



FTP server function

Download data files onto a PC

Your PC can get files from inside the SD memory card or USB drive inserted to the LR8450/LR8450-01.

FTP client

Automatically transfer data files to an FTP server

Automatically transmit files to an FTP server from the SD memory card or in the USB drive inserted to the LR8450/LR8450-01.

NTP client function

Set the logger's clock

Set the clock in the LR8450/LR8450-01 and synchronize it to an NTP server on the network.

E-mail transmission function

CAN-FD - Powertrain

Receive email notices on errors and other information

Receive emails to your PC or mobile phone when there is a communication loss and when an error occurs during measurement and wireless module communications.


It can also send instantaneous values by e-mail periodically.

Use with other tools



Output measured values using XCP on Ethernet

The LR8450 supports XCP slave operation based on the XCP protocol, a standard developed by the Association for Standardisation of Automation and Measuring Systems (ASAM). You can perform control to start and stop measurement and acquire measured values using an XCP master. (Measured values from CAN modules cannot be output.)





CAN - Body
Vehicle bus

ECU access

ECU RAM measurement and calibration task

CAN bus measurement

GateWay ECU

ECU/bus measurement interface

Interface module

•Overwrite control parameters while ECUs continue to operate •Consolidate data from multiple measurement systems and buses •Monitor large amounts of microcontroller RAM at high speeds

Interface module

NEW

Load data using MDF-compatible waveform viewers

Voltage, temperature, strain, CAN, and other measurement data captured by the LR8450 can be saved in the Measurement Data Format (MDF) and loaded by other software that supports the format.

Commercially available software

FAMOS


- · More than 400 calculation processing variables
- · Easy report creation functionality

FlexPro




- · High-speed search and processing of large volumes of data
- Share analysis templates within your company

NI DIAdem



- Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface


OS-2000



- · Freely edit large data that cannot be handled by Excel
- Simultaneously display the waveforms which have different frequencies

Logger Utility (standard accessory)

Collect data at sampling speeds of up to 10 ms on a PC



while recording is in progress. A real-time measurement is supported for recording intervals of 10 ms or longer.

U8555 and LR8535 CAN Unit real-time measurement and viewing of waveform data are not supported. Please use the GENNECT One software for real time viewing of CAN data by the U8555 and LR8535.

Record data on a PC in real time using the Logger Utility application software, a standard accessory. You can even scroll waveforms backwards to view older data

Recording simultaneous recording units

10 ms 2035 channels up to 5

+ 60 waveform calculation channels destination PC

LAN/USB

Connection

method


 \bigcirc

Simultaneously log data from five LR8450 instruments at a speed of up to 10 ms.

Display logged data in real time as a graph.

GENNECT One

Make simultaneous measurements using multiple instruments



Aggregate measurement data from not only loggers, but also waveform recorders, power meters, and other instruments onto a single PC.

Display this measurement data on a single graph in real time. Summarize it in daily and monthly reports. Manage in in a centralized manner. GENNECT One is a Windows application that specializes in aggregating measurement data.

Data including CAN data from the U8555 and LR8535 can be viewed and measured in real time (logging function, dashboard function). Real time measurement and viewing of CAN data will be available from the LR8450's next firmware update around mid or late 2022.

GENNEC One is a free application.

Access this 2D Code for details and downloads.



Recording interval

Simultaneous recording

Total No. of connected devices

Save destination Connection method

1 s 512 channels

up to 15* PC

LAN

*Up to 30 devices can be connected when using only the logging or dashboard functions



Simultaneously log data from instruments like recorders and power meters as frequently as 1 s.



Display logged data in real time as a graph. Automatically create CSV files and daily/monthly reports.



Graphically display measured values using the dashboard function. Visually identify anomalies.



Download instrument data files saved on instruments' SD cards.



Change instrument settings remotely.

			ry HiLogger sic specifications		
Product warrant	y period	3 years	•		
Accuracy guarant		1 year			
Maximum numb connectable mo			n modules + 7 wireless modules* *LR8450-01 only than 4 CAN modules (U8555 and/or LR8535) can be connected.		
Connectable n (plug-in mod	n modules) U8551		VOLTAGE/TEMP UNIT U8553 HIGH SPEED VOLTAGE UNI' UNIVERSAL UNIT U8554 STRAIN UNIT VOLTAGE/TEMP UNIT U8555 CAN UNIT		
Connectable r (wireless mo (LR8450-01	dules)	LR8530 LR8531 LR8532 LR8533 LR8534) WIRELESS VOLTAGE/TEMP UNIT WIRELESS UNIVERSAL UNIT WIRELESS VOLTAGE/TEMP UNIT 8 WIRELESS HIGH SPEED VOLTAGE UNIT WIRELESS STRAIN UNIT		
Internal buffer	memory	-	WIRELESS CAN UNIT memory, 256 M-words		
Clock function	nality	Auto-ca	llendar, automatic leap year recognition, 24-hour clock		
Clock precis (precision of clo played by instru well as start/stop	ck dis- ment as	Time ca	day (at 23°C) an be synchronized with an NTP server to which the instruconnected.		
Time axis ac			day (at 23°C)		
Backup batte service life	ery	For clo	ck, at least 10 years (reference value at 23°C)		
Operating envi	ronment	 	, pollution degree 2, altitude up to 2000 m		
Operating temperating temperations of the comments of the comm	ange erature	(chargir	to 50°C (14°F to 122°F), 80% RH or less (non-condensing) ng temperature range: 5°C to 35°C) to 60°C (-4°F to 140°F), 80% RH or less (non-condensing)		
and humidity r Dimensions		Without	any modules: 272W × 145H × 43D mm (10.72"W × 5.71"H × (excluding protrusions)		
		With 2 i	nodules: 272W × 198H × 63D mm (10.71″W × 7.8″H × 2.78″D ing protrusions)		
			modules: 272W × 252H × 63D mm (10.71"W × 9.92"H × (excluding protruding parts)		
Mass			. 1108 g (39.08 oz.) (excluding battery pack)		
Standards			EN61010 :N61326 Class A		
Vibration		JIS D 1	601:1995:1995 5.3 (1)		
resistance Accessories			: Passenger vehicles; conditions: Class A equivalent		
7.0000001100		instruct CAN ed tion ma	Quick start manual, LOGGER application disc (quick start manual, instruction manual, logger utility, logger utility instruction manual, CAN editor, CAN editor instruction manual, communication instruction manual), USB cable, AC adapter Z1014, precautions concerning use of equipment that emits radio waves (LR8450-01 only)		
Display					
Display		7-inch	FFT color LCD (WVGA 800 × 480 dots)		
Display reso (with wavefo display selec	rm		0 divisions (horizontal axis) × 10 divisions (vertical axis) ion = 36 dots [horizontal axis] × 36 dots [vertical axis])		
Display lang		Japane	se, English, Chinese, Korean		
Backlight serv			. 100,000 h (reference value at 23°C)		
Backlight sa Backlight brig		Turns off backlight when no key is operated for a set amount of time 5 levels (user-selectable)			
Waveform background			ht (user-selectable)		
Power sup	vla				
Power supply	AC ad	apter	Z1014 AC Adapter (12 V DC ±10%) AC Adapter rated supply voltage: 100 V to 240 V AC (assuming voltage fluctuation of ±10%)		
	Batter	y	AC Adapter rated power supply frequency: 50/60 Hz LR8450 accommodates 2 batteries		
			Z1007 Battery pack (when used with AC Adapter, AC Adapter takes priority) Li-ion, 7.2 V, 2170 mAh		
	Extern power	al supply	10 V to 30 V DC		
Power consumption	Norma	al power mption	Using Z1014 AC adapter or 12 V DC external power supply, without Battery Pack With LCD at maximum brightness: 8.5 VA (instrument only) With LCD backlight off: 7 VA (instrument only)		
	Maxim rated p		When using the Z1014 AC adapter 95 VA (including AC adapter) When using a 30 V DC external power supply 28 VA (while charging battery with LCD at maximum brightness) When using the Z1007 Battery pack		
Continuous operating time	s Battery		20 VA (with LCD at maximum brightness) With one Z1007 Battery pack: approx. 2 h (reference value at 23°C) With two Z1007 Battery packs: approx. 4 h (reference value at 23°C) Conditions: with one U8551 Universal Unit connected, backlight on, voltage output off, and Z4006 connected		
Charging functionality	AC ad	apter is	ailable when the Z1007 Battery pack is attached and the connected. Approx. 7 h (reference value at 23°C)		
Interface s					
	erface	and US	B interface (function) cannot be used at the same time		
LAN II interface A	uto ME		rnet, automatic 100Base-TX/1000Base-T detection CP, DNS supported		

LAN interface	LAN func- Configuring settings and controlling recording using communicationality: tions commands					
	Manually acquiring data using the FTP server: Acquiring files from a connected SD Memory Card or USB Drive					
	Automatically sending of data via FTP (FTP client)					
	Transferring files saved on a connected SD Memory Card or USB Drive Waveform files while measurement is in progress: binary, text, MDF Waveform files after measurement has finished: binary, text, MDF,					
	numerical calculation result files					
	HTTP server function Control mode (one instrument):					
	Displaying screen and remotely controlling instrument and modules, current measured value display, starting/stopping measurement, acquiring data via FTP, setting comments, updating instrument and modules Browsing mode (up to four instruments):					
	Displaying screen, measurement status, and comments					
	Email transmission Start trigger, stop trigger, alarm, power outage recovery, internal buffer, memory full, media full, wireless unit communication interruption, battery low, and periodic mail transmission. Instantaneous values can be attached for start trigger, stop trigger, alarm, and periodic transmission. Emails can be sent regularly at the following intervals: 30 min., 1 h, 12 h, or 1 day.					
	NTP client function					
	Time synchronization with an NTP server Regular synchronization intervals: 1 h, 1 day Pre-measurement synchronization function					
Vireless AN	IEEE 802.11b/g/n Communications range: 30 m, line of sight					
nterface	Encryption function: WPA-PSK/WPA2-PSK, TKIP/AES					
LR8450-01 only)	Usable channels: 1 to 11 Auto-connect function: wireless LAN function can be toggled on and off. Supported modes: access point, station, wireless module connectivity Devices that can be connected in wireless module connectivity mode: wireless modules or PC/tablet					
	You can use either a wireless module or PC/tablet with wireless connection Wireless Configuring settings and controlling recording using					
	LAN func- tionality:					
	tionality: Manually acquiring data using the FTP server					
	Acquiring files from a connected SD Memory Card or USB Drive Automatically sending data via FTP (FTP client)					
	Transferring files saved on a connected SD Memory Card or USB Drive					
	Control mode (one instrument):					
	Displaying screen and remotely controlling instrument and mod- ules, current measured value display, starting/stopping measure- ment, acquiring data via FTP, configuring comment, updating the instrument and modules					
	Browsing mode (up to four instruments):					
	Displaying screen, current measured value display, measurement status, and comments					
	Email transmission					
	Start trigger, stop trigger, alarm, power outage recovery, internal buffer, memory full, media full, wireless unit communication interruption, low bat- tery, and periodic mail transmission. Instantaneous values can be attached for start trigger, stop trigger, alarm, and periodic transmission.					
	Emails can be sent regularly at the following intervals: 30 min, 1 h, 12 h, 1 day.					
	NTP client function Time synchronization with an NTP server					
	Regular synchronization intervals: 1 h, 1 day					
USB	Pre-measurement synchronization function Standard compliance: USB 2.0 compliant					
interface	Connectors: Series A receptacle × 2					
(host)	Guaranteed-operation options: Z4006 USB drive (16 GB) File system: FAT16. FAT32					
	Connectable devices: keyboard, mouse, hub (1 layer), USB drive (1 port only)					
USB	USB standard: USB 2.0 compliant					
interface (function)	Connector: series mini-B receptacle USB functionality: data acquisition, condition settings used with the Logger					
,	Utility software (bundled) Configuring settings and controlling recording using com-					
	munications commands USB drive mode: transferring data from a connected SD memory card to a computer					
SD card	Standard compliance: SD standard-compliant slot × 1 (with SD memory card/					
slot	SDHC memory card support) Guaranteed-operation options: Z4001 (2 GB), Z4003 (8 GB)					
	File system: FAT16, FAT32					
-	autual tarusinala					
External c	control terminals lock Push-button type terminal block					

External	control te	rminals	
Terminal	block	Push-button type terr	ninal block
External Number of terminals		4, non-isolated (same	e GND as instrument)
	Input	Input voltage	0 V to 10 V DC
		Slope	Rising/falling (user-selectable)
		Functionality	Choose from off, start, stop, start/stop, trigger input, event input
	Output	Output format	Open-drain output (with 5 V voltage output)
		Maximum switching capacity	5 V to 10 V DC, 200 mA
		Functionality	Trigger output
Alarm ou	itput	Output format	Open-drain output (with 5 V voltage output)
		Maximum switching capacity	5 V to 30 V DC, 200 mA
		Number of terminals	8, non-isolated (same GND as instrument)
Voltage output		Output voltage	Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each *24 V output can be selected for the VOUT- PUT1 terminal only
		Number of terminals	2, non-isolated (same GND as instrument)
GND terr	minal	Number of terminals	10 (common GND)

Recording m					
		Normal			
s, 5 s, 10		s, 5 s, 10	ms*, 5 ms*, 10 ms, 20 ms, 50 ms, 100 ms, 200 ms, 500 ms, 1 s, 2 s, 20 s, 30 s, 1 min., 2 min., 5 min., 10 min., 20 min., 30 min., 1 h railable only when using a module with data refresh intervals that include 1 ms		
Data refresh		Automat	ically- or user-selected value per module		
Repeat reco	rding	,	ser-selectable)		
Specified time/continud	ous	Time car (total 25 Continuo If maxim	time: recording time is set in days, hours, minutes, and seconds. n be set up to maximum capacity of internal buffer memory. 6 mega-data-points) bus: recording is performed once until it is stopped. um capacity of internal buffer memory is exceeded, memory verwritten.		
Waveform recording		Last 256 Scroll th	mega-data-points are saved in internal buffer memory. rough and view data stored in internal buffer memory. ource data recording can be toggled on and off.		
Backup of recor	ded data		data recording can be toggica on and on.		
Display		Disalawal			
Sheet function	on	Max. nui CAN cha	neets can be switched between all channels and individual modules mber of channels on all-channel display sheet: 120 analog/ annels, 30 waveform calculation channels, 8 pulse/logic s, 8 alarm channels		
Waveform di screen	splay	(channel	s waveform display: simultaneous display of gages and settings settings and display settings) eous display of time-axis waveforms and values: instantaneous		
		values, cu Numerica cal values	ursor values, or numerical calculation values (user-switchable) Il display: simultaneous display of instantaneous values and statisti- s		
Display form	at		play: display of alarm status and alarm history s waveform display: 1 screen		
piay 101111	س د		eform display: 1 screen		
X-Y composi		<u> </u>	ite up to 8 waveforms.		
Numerical di format		When do	decimal, or exponent (user-selectable) ecimal is selected, number of decimal places to display can alues will then be rounded to set number of places).		
Waveform co Zooming in a		24 colors	2 ms to 1 day/division		
out on the		axis	2 ms to 1 day/division		
waveform dis	spiay	Vertical axis	Number of divisions per screen: 10 Setting method Select position or upper and lower limits for each channel. (Waveform calculation channels: upper and lower limits only) When setting by position: set zoom factor and zero position. Zoom factor: 1/2 ×, 1 ×, 2 ×, 5 ×, 10 ×, 20 ×, 50 ×, 100 × Zero position: -50% to 150% (with a zoom factor of 1 ×)		
Waveform so	crolling	When setting by upper/lower limit: set upper and lower limit. Display can be scrolled left and right both during recording and while recording is stopped (during waveform rendering only)			
Monitor displ	lay		stantaneous values and waveforms without recording data to values and waveforms can be displayed while waiting for a trigge		
Wireless module status Indicat			1 7 0 00		
			s the battery remaining and the radio-wave strength, in the els, of the wirelessly connected modules		
display (LR8450					
display (LR8450) Files	-01 only)	four leve			
	-01 only) SD me	four leve	ls, of the wirelessly connected modules		
display (LR8450 Files Save	SD me (only)	emory ca storage m 8 single-l	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters		
display (LR8450 Files Save destinations	SD m (only s Up to Autom Wavefi (user-s Numer	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable		
Files Save destinations File names	SD m (only s Up to Autom Wavefi (user-s Numer When file or	emory ca storage n 8 single- natic num orm data (selectable ical calcula text form to save e	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format lation results (saved after recording): off or text format (user-selectable at is selected, choose whether to save all calculations in one ach calculation in its own file.		
Files Save destinations File names	SD m (only s Up to Autom Wavefi (user-s Numer When	emory ca storage n 8 single- natic num orm data (selectable ical calcula text form to save e	rd or USB drive (user-selectable) ledia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format lation results (saved after recording): off or text format (user-selectable at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space.		
Files Save destinations File names	SD me (only) Up to Autom Wavefi (user-s Numer When file or Delete	emory ca storage n 8 single- natic num orm data (selectable ical calcula text form to save e	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable ration results (saved after recording): off or text format (user-selectable ati is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.		
Files Save destinations File names	SD me (only) Up to Autom Wavefr (user-s Numer When file or Delete save	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula text form to save e e and	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable ati is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable		
Files Save destinations File names	SD me (only) Up to Autom Wavefr (user-s Numer When file or Delete save	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula text form to save e	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each set period of time is saved in its own file		
Files Save destinations File names	SD me (only) Up to Autom Wavefr (user-s Numer When file or Delete save	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula text form to save e e and	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Time data will be segmented at intervals of the segment time based on the previously set reference time and saved in		
Files Save destinations File names	SD me (only) Up to Autom Wavefr (user-s Numer When file or Delete save	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula text form to save e e and	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off. system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled: data for each recording session is saved in its own file Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in		
Files Save destinations File names	SD m (only) SD m (only) Up to Auton Wavef (user-s Numer The Save Folder File sp Extern eject (s	emory ca storage n 8 single-l natic num orm data (selectable) ical calcula text form to save e e and	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one such calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled; data for each recording session is saved in its own file Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Selit time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d External media can be ejected during real-time saving by		
Files Save destinations File names	SD mi (only support of the state of the stat	emory ca storage n 8 single-inatic num orm data (selectable) ical calcula text form to save e a and Splitting	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format lation results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled: data for each recording session is saved in its own file Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d		
Files Save destinations File names	SD m (only) SD m (only) Up to Control Wavefi (user-s-when file or Delete save Folder File sp Extern eject (factor or loat a in tono o	emory castorage m 8 single-latic num orm data (selectable) icleated actual text form to save estand	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file. On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data. No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d External media can be ejected during real-time saving by activating a button on the screen and confirming a message		

Interval triggers Trigger activated for set recording interval after setting days/hours/minutes/seconds External triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) Trigger response time* Trigger response time* Trigger plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + analog response time* When using plug-in units: (recording interval or data refresh time, whichever is longer) × 2 + wireless response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time* "1: depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). "2: when the radio-wave state is in good condition, 1s. Trigger level resolution Analog 0.1% f.s. (f.s. = 10 divisions) Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarms Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied and the set of the se						
Calculations	_					
Numerical Venter of colicidations of colicidations of colicidations of colicidations of colicidations of colicidations of content time, minimum value, maximum value, maximum value of content time, minimum value, minimum value of the content time, minimum value, maximum value of the content time, and the content time, minimum value of the content time, and time of the content time, and time of the content time, and time, an	Loading s data	aved				
calcular content conte	Calculat	ions				
Caculation Average value, peak to peak value, maximum value, minimum value time, and time value			Up to 10 calcu	ulations simultaneously		
Caculation Cac	tions Calculation		Average value, peak-to-peak value, maximum value, maximum value time, integration*¹, aggregation*¹, usage ratio*², on time*², off time*², on count*², off count*² *1: total, positive, negative, or absolute value (user-selectable)			
calculain calculain calculations performed for all data during recording canabled: data for each segment of time, starting with the start of measurement Segmentation time: set DD.HH.MM format Timed: calculations will be made at intervals of the segment time based on the prevolusly set reference time. Set in hours and minutes. Self time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split time: A federate time: set in hours and minutes. Split tim			During recording calculations per calcul	ng: erformed for all data during recording I has stopped: erformed for all data in the internal buffer memory, or for data		
Waveform Calculation Cortent Cortent Calculation Cortent Calculation Cortent Calculated values are recorded as data for calculation channels (W1 through W30). (Calculations are performed at the same time as measure ment. Values cannot be recalculated after measurement.) Trigger method Digital comparison method Trigger timing Start, stop. or start & stop		calcula-	Disabled: calco Enabled: data surer Segmentation Timed: calcula on the previou Reference tin Split time: 1 n	ulations performed for all data during recording for each segment of time, starting with the start of meament time: set DD:HH:MM format tions will be made at intervals of the segment time based sly set reference time. ne: set in hours and minutes. nin, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h,		
Trigger timing Start, stop, or start & stop Trigger conditions AND/OR operation performed on trigger source, interval trigger, or external trigger when triggers are disabled, free run Trigger sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm SAL (max. 100) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 2 minutes. Low remaining alarm when a thermocouple burnout occurs (when Tc burnout detection setting is enabled) Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless module. Low remaining alarm wireless module. Analog, pulse, logic, waveform calculations disruption continues for calculation, CAN wireless area or wireless module. Alar			Arithmetic ope Moving average Calculated val through W30).	erations among channels , simple average, aggregation, and integration of any channel lues are recorded as data for calculation channels (W1 (Calculations are performed at the same time as measure-		
Trigger timing Start, stop, or start & stop Trigger conditions AND/OR operation performed on trigger source, interval trigger, or external trigger When triggers are disabled, free run Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Level triggers: trigger activated by arising or falling edge at a set level window triggers; it is set by trigger level upper limit and lower limit. Trigger activated when value leaves area or when value enters area External triggers Trigger activated for set recording interval after setting days/hours/minutes/seconds Trigger response time Trigger response time Trigger response ime* When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + wireless response time* "Hone using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time* "1. depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). 2. when the radio-wave state is in good condition, 1s. Analog O.19.6 f.s. (f.s. = 10 divisions) Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied "AND/OR operation performed on alarm sources - Low battery - Thermocouple burnout - Wireless error (LR8450-01 only) Alarm output when a wireless communication disruption a minutes. Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless module. Thermocouple during a larm upon a communication disruption continues for 3 minutes. Analog, pulse, logic, waveform calculations disruption continues for 3 minutes. Sopre. set level and time. The system will output an alarm when value leaves area or w	Triggers					
Trigger sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Interval triggers Interval triggers Trigger activated when patterns of 1/0/X match (where "X" indicates either) Interval triggers Trigger activated for set recording interval after setting days/hours/ minutes/seconds External triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1ms + analor response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time* **1. depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). 2. when the radio-wave state is in good condition, 1s. Trigger level resolution Fulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied of 120 Hz). Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless communication error with a wireless module is detected Offinow's min (user-selectable) Now: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication significance in signing or falling edge at set level Windows and alarm when value leaves area or when			Digital compa	rison method		
external trigger withen triggers are disabled, free run Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, can waveform calculations, and lower limit. Trigger activated by arising or falling edge at a set level waveform calculations, and lower limit. Trigger activated when value leaves area or when value enters area Logic, CAN Trigger activated when patterns of 1/0/X match (where "X" indicates either) Trigger activated for set recording interval after setting days/hours/minutes/seconds External triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) Trigger response time" Trigger response time" When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2+ ms+analor response time" "Y" when using wireless units (LR8450-01 only); (recording interval or data refresh time, whichever is longer) × 2+ wireless response time" + analog response time" "1' depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz.) 2' when the radio-wave state is in good condition, 1s. Trigger level Analog (D.1% f.s. (f.s. = 10 divisions) Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarm conditions Set separately for ALM1 to ALM8 system will output an alarm sources 1-tow battery Thermocouple burnout - Wireless error (LR8450-01 only) Alarm output when a wireless communication error with a wireless module is detected Offinow/3 min (user-selectable) Now: outputs an alarm upon a communication disruption a minutes. Low remaining battery life Thermocouple burnout over remaining battery life is detected for the instrument or a wireless module. Alarm output when a harmecouple burnout occurs (when Tc burnout detection setting is enabled) Type			1			
Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, puls	rrigger co	Diditions	external trigge	er		
pulse, waveform calculations, CAN waveform calculations, CAN long or when value enters area long. CAN long or when value enters area chivated when value leaves area or when value enters area long. CAN long catching or when value enters area long. CAN longer activated when patterns of 1/0/X match (where "X" indicates either) Interval triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + ms + analog response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time** "1: depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). "2: when the radio-wave state is in good condition, 1s. Trigger level analog 0.1% f.s. (f.s. = 10 divisions) Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarms Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied AMD/CR operation performed on alarm sources - Low battery - Thermocouple burnout - Wireless error (LR8450-01 only) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless communication disruption continues for 3 min: outputs an alarm upon a communication disruption continues for 3 min: outputs an alarm upon a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs an alarm upon a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs an alarm when any of the following a rising or filter by the patterns area or when value enters			Analog, pulse			
Interval triggers Trigger activated for set recording interval after setting days/hours/minutes/seconds External triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) Trigger response time Trigger response time Trigger spanse time Trigger level response times Trigger level resolution Trigger level resolution resolution resolution for sum and the radio-wave state is in good condition, 1s. Trigger level resolution resolutio	Trigger ty	pes	pulse, waveform calculations,	edge at a set level Window triggers: it is set by trigger level upper limit and lower limit. Trigger activated when value leaves		
Interval triggers External triggers Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable) Trigger response time When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + analog response time? When using wireless units (LR8450-01 only). (recording interval or data refresh time, whichever is longer) × 2 + wireless response time? + analog response time in the response time in t			-	Trigger activated when patterns of 1/0/X match (where		
Trigger response time When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + analog response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time** **1' depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). **2': when the radio-wave state is in good condition, 1s. Trigger level resolution Pulse	Interval tr	iggers		ted for set recording interval after setting days/hours/		
Trigger response time When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + analoge response time* When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time** **It depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). **2: when the radio-wave state is in good condition, 1s. Trigger level resolution Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting) Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarms Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied • AND/OR operation performed on alarm sources • Low battery • Thermocouple burnout • Wireless error (LR8450-01 only) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless communication error with a wireless module is detected offorwow? an in (user-selectable) Now: outputs an alarm upon a communication disruption of minicutes. Low remaining battery life Alarm output when low remaining battery life is detected for the instrument or a wireless module. Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled) Types of alarms Analog, pulse, waveform calculation, CAN Analog, pulse, waveform calculation, CAN CAN Analog, level: system will output an alarm following a rising or falling edge at set level Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	External t	riggers	Trigger activa	ted by rising or falling edge at set level in external input		
Trigger level resolution Analog	Trigger response time When using plug-in units: (recording interval or data refresh interval, whichever is longer)×2+1r response time*¹ When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer)×2+response time*²+analog response time*¹ *1: depends on filter settings (U8554 with a data refresh interval)		olug-in units: val or data refresh interval, whichever is longer) × 2 + 1 ms + analog ireless units (LR8450-01 only): rval or data refresh time, whichever is longer) × 2 + wireless *2 + analog response time*1 filter settings (U8554 with a data refresh interval of ow-pass filter of 120 Hz).			
Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving. Alarms Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied • AND/OR operation performed on alarm sources • Low battery • Thermocouple burnout • Wireless error (LR8450-01 only) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Wireless error (LR8450-01 only) Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm upon a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs when low remaining battery life instrument or a wireless module. Low remaining battery life Alarm output when low remaining battery life is detected for the instrument or a wireless module. Types of alarms Analog, pulse, waveform calculation, CAN Analog, pulse, waveform will output an alarm following a rising or falling edge at set level Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			Analog	0.1% f.s. (f.s. = 10 divisions)		
Can be set during real-time saving.				count per rotation setting)		
Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied *AND/OR operation performed on alarm sources *Low battery *Thermocouple burnout *Wireless error (LR8450-01 only) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Wireless error (LR8450-01 only) Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs when low remaining battery life is detected for the instrument or a wireless module. Thermocouple burnout Alarm output when low remaining battery life is detected for the instrument or a wireless module. Thermocouple burnout detection setting is enabled) Types of alarms Analog, pulse, waveform calculation, CAN Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).						
System will output an alarm when any of the following conditions are satisfied AND/OR operation performed on alarm sources Low battery Thermocouple burnout Wireless error (LR8450-01 only) Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communication disruption 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs when low remaining battery life is detected for the instrument or a wireless module. Thermocouple burnout Alarm output when low remaining battery life is detected for the instrument or a wireless module. Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled) Types of alarms Analog, pulse, waveform Calculation, CAN Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Alarms					
Wireless error (LR8450-01 only) Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm if a communication disruption continues for 3 minutes. Low remaining battery life Alarm output when low remaining battery life is detected for the instrument or a wireless module. Thermocouple burnout Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled) Types of alarms Analog, pulse, waveform Calculation, CAN Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Alarm cor	nditions	System will out AND/OR op Low battery Thermocour	put an alarm when any of the following conditions are satisfied: eration performed on alarm sources ble burnout		
(LR8450-01 only) module is detected Offnow/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm upon a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 min: outputs an alarm if a communication disruption continues for 3 minutes. Low remaining battery life is detected for the instrument or a wireless module. Thermocouple burnout occurs (when Tc burnout detection setting is enabled) Types of alarms Analog, pulse, waveform calculation, CAN Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).						
Thermocouple burnout when a thermocouple burnout occurs (when Tc burnout detection setting is enabled) Types of alarms Analog, pulse, waveform calculation, CAN Alarm filter Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm if a communication disruption continues for			
Types of alarms Analog, pulse, waveform calculation, CAN CAN Analog pulse, waveform calculation, CAN Mindow: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).						
Types of alarms Analog, pulse, waveform calculation, CAN CAN Level: system will output an alarm following a rising or falling edge at set level Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Thermoco		Alarm output when a thermocouple burnout occurs (when Tc burn			
change (level per unit time) continues to exceed the specified change rate during the set time interval. Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either) Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Types of	alarms	pulse, waveform calculation, CAN	falling edge at set level Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time.		
sources. Set based on sample count (off, 2 to 1000).			Logic	change (level per unit time) continues to exceed the specified change rate during the set time interval. System will output an alarm when patterns of 1/0/X		
System will output an alarm it alarm state continues for set number of samples	Alarm filter Apply a filter to results of AND/OR operations performed on ala					

Alarm retention	On/off (user-selectable) Clear alarms: when alarm retention is on, alarms will be cleared without stopping recording.
Alarm tone	On/off (user-selectable)
Alarm output response time	When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2+1 ms+analog response time*1 when using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer) × 2+ wireless response time*2+ analog response time*1*1* depending on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). *2: when the radio-wave state is in good condition, 1s.

Other functions	ality		
		Jp to 1000 inputs per measurement	
	Search waveforms and display target location in center of waveform screen.		
function	conditions r	Search by choosing level, window, maximum value, minimum value, local maximum value, or local minimum value.	
		All data in internal buffer memory or data between A/B cursors (on vertical axis)	
	Search targets A	Analog, pulse, logic, waveform calculations	
Jump function	Specify event madisplay position t	ark, A/B cursor position, trigger point, or waveform to display that section in center of waveform screen.	
Cursor	Cursor display A	All channels or specified channels (user-selectable)	
measurement function	Cursor movement A	A, B, or simultaneous (user-selectable)	
Turiction	Types of cursors \	Vertical or horizontal (user-selectable)	
Scaling function	Scaling settings	can be configured separately for each channel	
Comment entry function	Enter titles and o	channel-specific comments	
Start state retention function	On/off (user-sele	On/off (user-selectable)	
Auto-start function	On/off (user-sele	ectable)	
Functionality for saving setting conditions	Up to five groups of setting conditions can be saved in the instrument's internal backup memory.		
Auto setup function			
	If there are setting conditions stored in the instrument's memory as well as on an SD memory card and a USB drive, setting conditions have the following precedence:		
		mory, SD memory card, and USB drive.	
Prevention of inadvertent START/ STOP key operation	ing if user wishes	STOP key is pressed, system will display a message askto start or stop measurement. ssage: enable/disable (user-selectable)	
Key lock function	Disables operation		
Beep tone	On/off (user-sele	•	
Self-check function	(LCD, ROM/RAM, LAN, media, and modules.	
Display of horizontal axis (time values)	Horizontal axis (time value) display can be set to time, date, or data point count. These are reflected in saved text data.		
Measurement start/ stop time specifica- tion function		nt start and stop conditions. et start time and stop time (year, month, day, hour, and	
Configuration navigation (quick set) function	nectivity troubles	registration guide (LR8450-01 only), wireless con- shooting guide (LR8450-01 only), connection diagram age, external terminals), loading setting conditions	
Power supply fre- quency filter function	50/60 Hz selection	on	

ln	put	
Pı	ulse/logic input	
	Number of channels	8 channels (common GND, non-isolated) Exclusive setting for pulse/logic input for individual channels
	Terminal block	Push-button type terminal block
	Adaptive input format	Non-voltage contact, open collector (PNP open collector requires external resistor), or voltage input
	Maximum input voltage	0 V to 42 V DC
	Input resistance	1.1 MΩ ±5%
	Detection level	2 levels (user-selectable) High: 1.0 V or greater; low: 0 to 0.5 V High: 4.0 V or greater; low: 0 to 1.5 V

Pulse input

Measurement range, resolution Measurement target Range

	Count		1000 mega-pulse f.s.	1 pulse	0 to 1000 M pulse
	Rotational speed		5000/n (r/s) f.s.	1/n (r/s)	0 to 5000/n (r/s)
			300,000/n (r/min) f.s.	1/n (r/min)	0 to 300,000/n (r/min)
			n: number of pulses per re	otation (1 to 1000)	
	Pulse input With filter off: 200 µs or greater (100 µs or greater during high and lo period With filter on: 100 ms or greater (50 ms or greater during high and lo				
Slo	ре	Set risir	ng/falling for each chan	nel.	_
Mea	surement mode	Integration (addition, instantaneous), rotational speed		eed	
Inte	egration	Addition: counts number of pulses input from start of measurement. Instantaneous: counts number of pulses input within each recording interval (integrated value is reset for each rotational interval).			in each recording
	tational eed	r/s: counts number of input pulses during 1 s and calculates rotational speed. r/min: counts number of input pulses during 1 min and calculates rotational speed.			
	Smoothing Select value from 1 s to 60 s (valid only when set to rotational spee function and r/min).		o rotational speed		

Maximum resolution Measurable range

Chatter pre- vention filter	Set to on/off for each channel
Logic input	
Measure- ment mode	Records 1 or 0 for each recording interval

Software Logger Utility specifications

Operating	Windows7 (32/64 bit) Windows8 (32/64 bit)	
Environment	Windows8 (32/64 bit) Windows10 (32/64 bit)	
Overview	Control PC-connected logger to receive, display, and save measure waveform data sequentially. (Total recording samples is maximum 10 million data. Data exceeding this number will be segmented into separate measurement files while recording continues.) **Real-time measurement on the LR8450, LR8450-01 is possible will a recording interval of 10 ms or more.	
Function	Controllable loggers: 5 Data Collection System: 1 system Display Format: • Waveforms (split time-axis display is possible) • Numerical values (logging): numerical display can be enlarged • Alarms Above items can be displayed simultaneously	
	Numerical value monitor Display: display in a separate window is possible. Scroll: waveforms can be scrolled during measurement.	
Data Collection	Settings: data collection settings of logger modlues can be configured Monitor function can be checked before measurement. Save: save settings from multiple devices supporting real-time measurement (LUS format) and measurement data (LUW format) as one file. Data save format: real-time data collection file (LUW format), transfer data in real-time or non-real-time to Microsoft Excel®, Excel® template can be specified Event mark: recording during measurement is possible	
Waveform Display	Supported files: waveform data file (LUW format, MEM format) Display format: waveforms (split time-axis display available), simulta- neous display of numerical values (logging) is available Maximum number of channels: 2,035 channels (measured) + 60 channels (waveform calculation) Waveform display sheets: waveform of each channel can be dis- played on any of the ten sheets Scroll: available Event mark recording: available Cursors: cursors A and B can be used to display voltage values at cursor positions. Screen capture: screen capture of waveform display is available	
Data Conversion	Applicable files: waveform data file (LUW format, MEM format) Conversion section: all data, specified section Conversion format: CSV format (comma delimited, space delimited, tab delimited), transfer to Excel® sheet, LR5000 format (hrp2,hrp) Data thinning: simple thinning with any thinning number	
Waveform Calculation	Calculation items: arithmetic operations Number of calculation channel: 60 channels	
Numerical Calculations	Applicable data: waveform data file (LUW format, MEM format), real-time measurement data, waveform calculation Calculation items: average value, peak value, maximum value, time to maximum value, minimum value, time to minimum value, on time, off time, on count, off count, standard deviation, aggregation, area value, and integration save calculation: performs numerical calculation and save to file	
Search	Applicable data: real-time data collection file (LUW format), main unit measurement file (MEM format), waveform calculation data Search mode: event mark, date and time, maximum position, minimum position, local maximum position, local maximum position, level, window, and variation	
Print	Applicable printer: printer compatible to the OS in use Applicable data: waveform data file (LUW format, MEM format) Print format: waveform image, report print, list print (channel settings, event, cursor value) Print area: all area, specified area by A-B cursor Print preview: available	

Option specifications (sold separately)

Plug-in units: U8550, U8551, U8552, U8553, U8554, U8555 Shared specifications

Host model	LR8450/LR8450-01 MEMORY HILOGGER
Operating temperature and humidity range	-10°C to 50°C, 80% RH or less (non-condensing)
Storage temperature and humidity range	-20°C to 60°C, 80% RH or less (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
Accessories	User manual, mounting screw × 2, wiring confirmation label (U8554 only)

Wireless units: LR8530, LR8531, LR8532, LR8533, LR8534, LR8535 Shared specifications

Host model	LR8450-01 MEMORY HILOGGER		
Control communications method	Connect wirelessly via Z3230 WIRELESS LAN ADAPTER (included)		
Communications buffer memory	Mword (volatile memory) Saves data in the event of a communications error. Data is resent when communications are restored.		
Operating temperature and humidity range	-20°C to 55°C, 80% RH (non-condensing) (charging temperature range: 5°C to 35°C)		
Storage temperature and humidity range	-20°C to 60°C, 80% RH (non-condensing)		
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent		
LED display	Wireless connection and measurement status, error status, AC		

Auto-connect function	Available
Accessories	Z3230 WIRELESS LAN ADAPTER, user manual, Z1008 AC ADAPTER, mounting plate, M3×4 screw × 2 (for use with mounting plate), wiring confirmation label (LR8534 only)
Z3230 wireless specifications	Wireless LAN (IEEE 802.11b/g/n) Range: 30 m (line of sight) Encryption: WPA-PSK/WPA2-PSK, TKIP/AES Channels: channel 1 to 11

Power supply specifications		
AC adapter	Z1008 AC ADAPTER (12 V DC, standard accessory) Rated supply voltage: 100 to 240 V AC Rated power supply frequency: 50/60 Hz Maximum rated power: 25 VA (including AC adapter) Normal power consumption (instrument only, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531; 3.0 VA LR8534, LR8535: 4.0 VA	
Battery	Z1007 BATTERY PACK (when using AC adapter, AC adapter takes precedence.) Rated supply voltage: 7.2 V DC (Li-ion 2170 mAh) Maximum rated power LR8530, LR8532: 1.5 VA LR8531, LR8533: 2.0 VA LR8534, LR8535: 3.5 VA	
External power supply	Rated supply voltage: 10 to 30 V DC Maximum rated power: 8 VA (30 V DC external power supply, while charging battery) Normal power consumption (12 V DC external power supply, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531: 3.0 VA LR8534, LR8535: 4.0 VA	
Continuous operating time	When using Z1007 BATTERY PACK (all data refresh rates, good communications state, 23°C reference values) LR8530, LR8532, LR8533: approx. 9 h LR8531: approx. 7 h LR8531: approx. 5 h LR8535: approx. 10 h (approx. 5 h when using two non-contact CAN sensors)	
Charging function	When Z1007 BATTERY PACK installed while connected to AC adapter or 10 to 30 V DC external power supply Charging time: approx. 7 h (23°C reference value)	

VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552

WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532

(Accuracy guaranteed for 1 year)

General specifications

General Specificati	ons
Number of input channels	U8550: 15 (set voltage, thermocouple, or humidity for each channel) LR8530: 15 (set voltage or thermocouple for each channel) U8551, LR8531: 15 (set voltage, thermocouple, humidity, RTD, or resistor for each channel) U8552: 30 (set voltage, thermocouple, or humidity for each channel) LR8532: 30 (set voltage or thermocouple for each channel)
Input terminals	U8550, LR8530: M3 screw-type terminal block (2 terminals per channel) U8551, LR8531: push-button type terminal block (4 terminals per channel) U8552, LR8532: push-button type terminal block (2 terminals per channel)
Output terminals	M3 screw-type terminal block (1 output, 2 terminals, Z2000 HUMIDITY SENSOR power supply [can power up to 15 Z2000 HUMIDITY SENSOR])(LR8531 only)
Measurement target	U8550, U8552: voltage, temperature (thermocouples), humidity LR8530, LR8532: voltage, temperature (thermocouples) U8551, LR8531: voltage, temperature (thermocouples), humidity, temperature (RTD), resistor
Input type	Scanning by semiconductor relays All channels isolated (not isolated when measuring with RTD, resistance or humidity)
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel- to-channel voltage	300 V DC (maximum voltage that can be applied between each input channel without causing damage; not isolated when measuring with RTD, resistance or humidity) *Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated terminal-to-ground voltage	300 V AC, DC (maximum voltage that can be applied between input channels and the instrument or its chassis, or between units without causing damage; humidity measurement not isolated)
Input resistance	10 M Ω or greater (10 mV f.s. to 2 V f.s. voltage ranges, thermocouple ranges, RTD and resistor ranges) 1 M Ω ±5% (10 V f.s. to 100 V f.s. voltage range, 1-5 V f.s. voltage range, humidity measurement)
Allowable signal source resistance	1 k Ω or less
Data refresh interval	10 ms to 10 s (10 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout setting, and power supply frequency filter setting
Dimensions	U8550, U8551, U8552: approx. 134W × 70H × 63D mm (5.28"W × 2.76"H × 2.48"D) LR8530, LR8531, LR8532: approx. 154W × 106H × 57D mm (6.06"W × 4.17"H × 2.24"D)
Mass	U8550: approx. 345 g (12.2 oz.), U8551: approx. 318 g (11.2 oz.), U8552: approx. 319 g (11.3 oz.), LR8530: approx. 423 g (14.9 oz.), LR8531: approx. 386 g (13.6 oz.), LR8532: approx. 388 g (13.7 oz.), (including Z3230 WIRELESS LAN ADAPTER)
Accessories	Instruction Manual, installation screws × 2

Analog input specifications (23 \pm 5°C [73 \pm 9°F], 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Voltage

			I
Range	Maximum resolution	Measurable range	Measurement accuracy
10 mV f.s.	500 nV	-10 mV to 10 mV	±10 μV
20 mV f.s.	1 μV	-20 mV to 20 mV	±20 μV
100 mV f.s.	5 μV	-100 mV to 100 mV	±50 μV
200 mV f.s.	10 μV	-200 mV to 200 mV	±100 μV
1 V f.s.	50 μV	-1 V to 1 V	±500 μV
2 V f.s.	100 μV	-2 V to 2 V	±1 mV
10 V f.s.	500 μV	-10 V to 10 V	±5 mV
20 V f.s.	1 mV	-20 V to 20 V	±10 mV
100 V f.s.	5 mV	-100 V to 100 V	±50 mV
1-5 V f.s.	500 μV	1 V to 5 V	±5 mV

Temperature

Thermocouple (not including accuracy of reference junction compensation) Standards: JIS C1602-2015 IFC584

ype		Measurable range	Maximum resolution	Measurement accura
K	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to less than 500°C	±0.5
			500°C to 1,350°C	±0.7
J	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 1,200°C	±0.5
Ε	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 1,000°C	±0.5
Τ	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 400°C	±0.5
	2000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 400°C	±0.5
N	100°C f.s.	0.01°C	-100°C to less than 0°C	±1.1
			0°C to 100°C	±0.9
	500°C f.s.	0.05°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 500°C	±0.9
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 1,300°C	±0.9
R	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
S	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2,000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
В	2,000°C f.s.	0.1°C	400°C to less than 600°C	±5.4
		[600°C to less than 1,000°C	±3.7
			1,000°C to 1,800°C	±2.4
С	100°C f.s.	0.01°C	0°C to 100°C	±1.7
	500°C f.s.	0.05°C	0°C to 500°C	±1.7
	2,000°C f.s.	0.1°C	0°C to 2,000°C	±1.7

Reference junction compensation: internal/external	At INT RJC, total accuracy = add ±0.5°C
detection: on/off	System will check for burnout at each data refresh interval during thermocouple measurement. (not available with 10 ms interval)

U8550, U8551, U8552, LR8531 only input specifications Humidity (use HUMIDITY SENSOR Z2000)

HUMIDITY SENSOR Z2000

Operating temperature and humidity range:

0°C to 50°C (32°F to 122°F), 100% RH or less (non-condensing)


Range	Maximum resolution	Measurable range
100% rh f.s.	0.1% rh	5.0% rh to 95.0% rh

HUMIDITY SENSOR Z2000 accuracy

If the humidity value lies on a boundary line below, the better of the two regions' mea-

surement accuracy values applies.





U8551, LR8531 only input specifications

Temperature RTD

Connection: 3-wire/4-wire, measurement current: 1mA (Pt100, Jpt100), 0.1mA (Pt1000) Standards: Pt100, Pt1000: JIS C1604-2013, IEC751 JPt100: JIS C1604-1989

Туре	Range	Maximum resolution	Measurable range	Measurement accuracy	
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C	
Pt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C	
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C	
JPt100	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C	
	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C	
	2,000°C f.s.	0.1°C	-200°C to 500°C	±0.9°C	
Pt1000	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C	
	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C	
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C	

*When using Pt1000, data refresh intervals of 10ms, 20m, and 50ms are not available. Resistance

Connection: 4-wire: measurement current is 1 mA

Range	Maximum resolution	Measurable range	Measurement accuracy
10 Ω f.s.	0.5 mΩ	0 Ω to 10 Ω	±10 mΩ
20 Ω f.s.	1 mΩ	0 Ω to 20 Ω	±20 mΩ
100 Ω f.s.	5 mΩ	0 Ω to 100 Ω	±100 mΩ
200 Ω f.s.	10 mΩ	0 Ω to 200 Ω	±200 mΩ

HIGH SPEED VOLTAGE UNIT WIRELESS HIGH SPEED VOLTAGE UNIT LR8531

(Accuracy guaranteed for 1 year)

General specifications

Number of input channels	s 5 (voltage only)		
Input terminals	M3 screw-type terminal block (2 terminals per channel), outfitted with terminal block cover		
Measurement target	Voltage		
Input type	Scanning by semiconductor relays, all channels isolated		
A/D resolution	16 bits		
Maximum input voltage	± ±100 V DC (maximum voltage between input terminals without causing damage)		
Maximum channel-to- channel voltage	300 V DC (maximum voltage between input channels without causing damage) *Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.		
Maximum rated termi- nal-to-ground voltage	300 V AC, DC (maximum voltage between input channel and chassis, or between modules, without causing damage)		
Input resistance	1 MΩ ±5%		
Allowable signal source resistance	100 Ω or less		
Data refresh interval	1 ms to 10 s (13 selectable levels)		
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout detection setting, and power supply frequency filter setting.		
Dimensions	U8553: approx. 134W×70H×63D mm (5.28"W×2.76"H×2.48"D) LR8531: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)		
Mass	U8553: approx. 237 g (8.4 oz.) LR8531: approx. 370 g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)		

Analog input specifications (23 \pm 5°C/73 \pm 9°F, 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Measurement target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	100 mV f.s.	5 μV	-100 mV to 100 mV	±100 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±200 μV
	1 V f.s.	50 μV	-1 V to 1 V	±1 mV
	2 V f.s.	100 μV	-2 V to 2 V	±2 mV
	10 V f.s.	500 μV	-10 V to 10 V	±10 mV
	20 V f.s.	1 mV	-20 V to 20 V	±20 mV
	100 V f.s.	5 mV	-100 V to 100 V	±100 mV
	1-5 V f.s.	500 μV	1 V to 5 V	±10 mV

STRAIN UNIT L	J8554	WIRELESS STRAIN UNIT LR8534		
(Accuracy guarant General specifica		year)		
Number of input channels	5 (set voltage or strain for each channel)			
Input terminals		ton type terminal block (5 terminals per channel), outfitted with block cover, set DIP switches according to measurement target		
Measurement	Voltage			
target	Strain	Strain gage-type converter Strain gage 1-gage method (2-wire setup), 1-gage method (3-wire setu) 2-gage method (adjacent sides), 4-gage method		
Adaptive gage resistance		nethod, 2-gage method: 120 Ω (external bridge box required for 350 Ω nethod: 120 Ω to 1 $k\Omega$		
Gage ratio	2.0 (fixed	i)		
Bridge voltage	2 V ±0.0	5 V DC		
Balance	Method	Electronic auto-balancing		
adjustment	Range	Voltage: ± 20 mV or less (1 mV f.s. to 20 mV f.s. range), ± 200 mV or less (50 mV f.s. to 200 mV f.s. range) Strain: $\pm 20,000$ με or less (1,000 με f.s. to 20,000 με f.s. range), $\pm 200,000$ με or less (50,000 με f.s. to 200,000 με f.s. range)		
Input type	Balanced differential input, simultaneous sampling of all channels (nor isolated channels)			
A/D resolution	16bit			
Maximum input voltage	±0.5 V DC (maximum voltage between input terminals without causing damage)			
Maximum channel- to-channel voltage	Non-isolated (all channels share common GND)			
Maximum rated terminal-to-ground voltage	30 Vrms AC or 60 V DC (maximum voltage between input channel and chassis without causing damage)			
Input resistance	2 MΩ ±5	%		
Data refresh interval	1 ms to 1	10 s (13 selectable levels)		
Low-pass filter	Cut-off frequency: -3 dB ±30% Auto, 120, 60, 30, 15, 8, 4 (Hz) Auto: cut-off frequency of low-pass filter is automatically set based on set data refresh interval.			
	Attenuation characteristics: 5th-order butterworth filter, -30 dB/oct			
Dimensions	U8554: approx. 134W×70H×63D mm (5.28"W×2.76"H×2.48"D) LR8534: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)			
Mass	U8554: approx. 236 g (8.3 oz.) LR8534: approx. 372 g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)			

Analog input specifications (23 ± 5 C/73 ± 9 F, 80% rh or less, auto-balance at least 30 minutes after power on, with LPF set at 4 Hz)

Measure- ment target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	1 mV f.s.	50 nV	-1 mV to 1 mV	±9 μV
	2 mV f.s.	100 nV	-2 mV to 2 mV	±10 μV
	5 mV f.s.	250 nV	-5 mV to 5 mV	±25 μV
	10 mV f.s.	500 nV	-10 mV to 10 mV	±50 μV
	20 mV f.s.	1 μV	-20 mV to 20 mV	±100 μV
	50 mV f.s.	2.5 μV	-50 mV to 50 mV	±250 μV
	100 mV f.s.	5 μV	-100 mV to 100 mV	±500 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±1 mV
Strain	1,000 με f.s.	0.05 με	-1,000 με to 1,000 με	±9 με
	2,000 με f.s.	0.1 με	-2,000 με to 2,000 με	±10 με
	5,000 με f.s.	0.25 με	-5,000 με to 5,000 με	±25 με
	10,000 με f.s.	0.5 με	-10,000 με to 10,000 με	±50 με
	20,000 με f.s.	1 με	-20,000 με to 20,000 με	±100 με
	50,000 με f.s.	2.5 με	-50,000 με to 50,000 με	±250 με
	100,000 με f.s.	5 με	-100,000 με to 100,000 με	±500 με
	200,000 με f.s.	10 με	-200,000 με to 200,000 με	±1000 με

^{*} Internal bridge resistance precision tolerance: ±0.01%; temperature characteristics: ±2 ppm/°C * Measurement accuracy does not include internal bridge resistance tolerance and temperature characteristics

CAN UNIT U85	55	WIRELES	SS CAN UNIT LR8535		
General specifica	General specifications				
Number of ports	2				
Input terminals	D-sub 9 pin MAL	E × 2			
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$		
	Pin No.	Signal	Function		
	1	N.C.	Unused		
	2	CAN_L	CAN_L communications line		
	3	GND	GND		
	4	N.C.	Unused		
	5	N.C.	Unused		
	6	N.C.	Unused		
	7	CAN_H	CAN_H communications line		
	8	N.C.	Unused		
	9	N.C.	Unused		
Power supply terminals (LR8535 only)	Dedicated powe	r supply for H	A receptacle × 2) lioki NON-CONTACT CAN SENSOR		
Interface	CAN, CAN FD, (,	· · · · · · · · · · · · · · · · · · ·		
Terminator	On/off setting av 120 Ω ±10 Ω bui	ailable for ea ilt-in resistan	ich port ce		
ACT LED	Displays CAN bus operating status				
TERM LED	Illuminates when terminator is on				
Data refresh interval	10 ms to 10 s (10 selectable levels)				
Baud rate	CAN/CAN FD (arbitration): 50k, 62.5k, 83.3k, 100k, 125k, 250k, 500k, 800k, 1,000k [Baud] CAN FD (data): 0.5M, 1M, 2M, 2.5M, 4M, 5M [Baud]				
Sampling point	CAN or CAN FD (arbitration): 50.0% to 95.0% CAN FD (data): 50.0% to 95.0%				
ACK transmission	ACK response when receiving CAN data can be set to on or off				
Operation mode	U8555: supports switching between receive mode and measured value output mode LR8535: supports only receive mode				
Dimensions	U8553: approx. 134W×70H×54D mm (5.28"W×2.76"H×2.13"D) LR8531: approx. 154W×106H×48D mm (6.06"W×4.17"H×1.89"D)				
Mass	U8553: approx. 235 g (8.3 oz.) LR8531: approx. 355 g (12.2 oz.) (including Z3230 WIRELESS LAN ADAPTER)				
Receive mode sp	pecifications				
No. of measurement channels	Data refresh interval 10 ms: max. 50 channels (max. 50 signals) Data refresh interval 20 ms: max. 100 channels (max. 100 signals) Data refresh interval 50 ms: max. 250 channels (max. 250 signals) Data refresh interval 100 ms or greater: max. 500 channels (max. 500 signals)				
Receive ID count	during the data r	efresh interv			
User-defined frame transmission (U8555 only)			nes during receive mode operation s: 8 per unit		
Measured values	output mode s	pecifications	s (U8555 only)		
Overview	Converts LR845 frames.	0 measured	values and output them as CAN		
Output target			-in modules (other than CAN Unit)		
Output data refresh period	fast as 1 ms)		rval of module generating output (as		
Response	Data refresh inte 1 Varies with filte (U8554: 5 ms wi	er settings	ms + analog response time (*1) v-pass filter)		
Function specific	cations (LR8535	only)			
LED display when in wireless mode	or external power	er supply, bat	ement status, error status, AC adapter tery power, charge status		
Control keys Auto-connect	[AUTO], [RESE] Available	<u> </u>			
function	, tranabio				

CAN Editor (software) specifications

Operating environment	ions Windows 10 (32/64-bit), Windows 11 (64-bit)			
Interface	LAN/USB			
	Japanese/English/Chinese			
	HIOKI LR8450/LR8450-01 MEMORY HILOGGER			
Set module position	Module 1 to module 4			
	Wireless module 1 to wireless module 7			
CAN interface set- ting	sampling points, AC	Interface, terminator, baud rate, data rate, sampling points, data sampling points, ACK		
Module operating mode	Switch between receive mode and measured value output mod on a module-by-module basis			
Receive mode sett		ngs		
Data refresh interval	10 ms to 10 s (10 se			
Receive channel definition settings	CAN input port settings			
delimition settings	Channel type	Data or ID count		
	Shared settings	1. Format: standard/extended 2. ID: Oh to 1 FFFFFFh 3. Comment 4. Unit 5. Factor, offset		
	Channel type: data	Start bits: 0 to 511 Bit length: 1 to 64 [bits] Byte order: Motorola/Intel Data type: unsigned/signed/IEEE/floa		
	LR8450 display settings	Display upper limit value or display lower limit value No. of display digits, display format Numerical calculation threshold Waveform color		
transmission set-	Receive condition numbe	No. 1 to No. 8		
tings	CAN output port set- ting	Port 1 or Port 2		
	No. of frame	1 to 8		
	Regular transmis- sion setting			
	Regular transmis- sion interva	`/		
	Timing	At measurement start, at measurement sto at start trigger, at alarm, manual		
	Frame type	CAN standard, CAN extended, CAN FD standard, CAN FD extended		
	Transmit ID	0 h to 1FFFFFFF h		
	DLC (bite)	0 to 15 (0, 12, 16, 20, 24, 32, 48, 64)		
	Transmit data	Set as hexadecimal value		
	Delay	0 to 9999 (× 10 [ms])		
Measured value out				
Measured value output setting	CAN output port set- ting			
	Frame type	Standard/extended		
	ID	0 h to 1FFFFFFF h		
	Data	Measured values from the following module can be set as output data U8550, U8551, U8552, U8553, U8554		
CAN bus load ratio estimation function		Id be the CAN bus load increase rate if were to be output using the current setting		
File specifications				
Save function	CANdb file (.dbc) for transmit data defined using measured value output mode settings Overall settings data for CAN Editor (.CES)			
Load function	Loads CANdb files (.dbc) and MR8904 definition files (.CDF) and use them to configure receive channel settings. Loads LR8450 settings (.SET) and CAN Editor settings (.CES) and applies them to the CAN Editor's overall settings.			
Title	Sets titles for setting	gs data (.CES) (up to 50 single-byte or 25		

Model: MEMORY HILOGGER LR8450



Option

Plug-in modules



VOLTAGE/TEMP UNIT U8550

Channels: 15: maximum sampling rate: 10 ms



UNIVERSAL UNIT U8551

Channels: 15; maximum sampling rate: 10 ms



VOLTAGE/TEMP UNIT U8552 Channels: 30: maximum sampling rate: 20 ms

(When 15 or fewer channels are used, 10 ms)



HIGH SPEED VOLTAGE UNIT U8553

Channels: 5; maximum sampling rate: 1 ms



STRAIN UNIT U8554

Channels: 5; maximum sampling rate: 1 ms



CAN UNIT U8555

Ports: 2, input: CAN or CAN FD, output: CAN or CAN FD maximum sampling rate: 10 $\ensuremath{\mathsf{ms}}$

Model No. Specifications (order code) LR8450 Standard model, main unit only LR8450-01 Wireless LAN equipped model, main unit only

- The LR8450 and LR8450-01 cannot perform measurement on their own. One or more plug-in modules or wireless modules are required (sold separately).
- The LR8450-01 and each wireless module emit radio waves. Use of radio waves is subject to licensing requirements in certain countries. Using it in a country or region other than those indicated may violate the law and may result in legal penalties for the operator. For the latest information about countries and regions where wireless operation is currently supported, please visit the Hioki website.

Wireless modules



WIRELESS VOLTAGE/TEMP UNIT LR8530

Channels: 15: maximum sampling rate: 10 ms



WIRELESS UNIVERSAL UNIT LR8531

Channels: 15; maximum sampling rate: 10 ms



WIRELESS VOLTAGE/TEMP UNIT LR8532

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

Channels: 5; maximum sampling rate: 1 ms



WIRELESS STRAIN UNIT LR8534

Channels: 5; maximum sampling rate: 1 ms



WIRELESS CAN UNIT LR8535

Ports: 2, input: CAN or CAN FD, maximum sampling rate: 10 ms

Power supplies

For instrument and wireless modules



BATTERY PACK Z1007

Instrument takes two wireless modules take one For instrument



AC ADAPTER Z1014

Ships standard with LR8450/LR8450-01

For wireless modules



AC ADAPTER Z1008

Fixed Stand



FIXED STAND Z5040

For installing logger on wall

CASE



CARRYING CASE C1012

Accommodates instrument and four plug-in modules or seven wireless modules

Wireless Lan Adapter

For wireless modules



WIRELESS LAN ADAPTER Z3230

Cables, sensors, etc.



LAN CABLE 9642

Straight Ethernet cable, supplied with straight to cross conversion adapter, 5 m (16.41 ft) length



HUMIDITY SENSOR Z2000

(analog output), 3 m (9.84 ft) length



Thermocouple

For reference only. Please purchase locally.



CAN CABLE 9713-01

For the U8555, LR8535. Unprocessed on one end, 1.8 m (5.91 ft) length



NON-CONTACT CAN SENSOR SP7001-95

Supports CAN FD or CAN signals, SP7001, SP9250, SP7150 set

Storage media

*Always use HIOKI optional storage media. Proper operation is not guaranteed when using storage media from other manufacturers, and may prevent the product from saving and loading data properly.



SD memory card Z4001

2 GB capacity



Z4003

8 GB capacity

SD memory card



USB drive Z4006

16 GB, long-life, high-reliability SLC flash memory

For the PC





GENNECT One

LOGGER UTILITY/CAN EDITOR

LOGGER UTILITY: The control of the measurement of loggers, real-time data collection CAN EDITOR: CAN configuration software Standard accessory

Displays measurement results from multiple instruments in graph form Free application for Windows



You can download the latest version from our website Note: Company names and product names appearing in this catalog are trademarks or registered trademarks of various companies