

## **Product Datasheet - Technical Specifications**



More information in our Web-Shop at ▶ www.meilhaus.com

#### Your contact

Technical and commercial sales, price information, quotations, demo/test equipment, consulting:

Tel.: +49 - (0)81 41 - 52 71-0

FAX: +49 - (0)81 41 - 52 71-129

E-Mail: sales@meilhaus.com





Fast and powerful - the best specs in the history of Memory HiCorders



Usability
User-friendly design for accurate and smooth operation
Intuitive operation via large 12.1-inch touch screen

Speed
Blazingly fast, Sampling that never fails

High-speed isolation measurement at 200 MS/s

Storage

Radically improved time to save measurement data

Stress-free user experience

Long-term Recording

Superior processing capacity so you can save data during measurement Save data in real time, 32 times faster than conventional market-leading models











## **Overwhelmingly High-speed Technology**

## A Revolutionary Approach to Measurement, Recording, and Analysis




## Flexible, User-friendly Design


- · Fast and convenient touch screen
- · Operation as smooth as silk



The capacitive touch screen delivers intuitive operability. Select a setting item directly by tapping the screen, and use your fingers to enlarge the part you want to see.

This improved user interface makes setting measurement items for multiple channels easy.







▲ Tap the screen and use the knob to move the trace cursor as desired.

Video describing the MR6000's intuitive user experience https://www.youtube.com/watch?v=z7kFRPsub9U



Up to

## **Highest Sampling Speed in the Entire Series**

- · High-speed isolation measurement at 200 MS/s
- · Up to 16 analog channels & 12-bit ADC resolution

The Hioki Memory HiCorder lineup now includes a powerful input unit that unlocks the full measuring potential of the MR6000.

The High Speed Analog Unit U8976 boasts the highest sampling rate in its entire series, an order of magnitude faster than conventional models, enabling the unit to perform isolated measurement at 200 MS/s.

(200 MS/s measurements can be achieved even if a unit other than the U8976 is connected at the same time. However, the data update rate will not exceed the maximum sampling rate of the other units.)



Max. 16 channels 12-bit ADC resolution

High Speed Analog Unit U8976

#### Blazingly fast, Sampling that never fails

The High Speed Analog Unit U8976 delivers a 30 MHz frequency band in addition to high-speed sampling at 200 MS/s. It has the performance needed to accurately capture switching waveforms during inverter evaluation testing, an application where high efficiency is critical. Adapted to the Memory HiCorder's direct input feature, it can accept inputs of up to 400 V DC.

#### Used in combination with the 10:1 Probe 9665

If you encounter issues with the capacitance components of connection cords, use the 10:1 Probe 9665 to reduce the effects on measured waveforms.




\*For more information about frequency deratings, either consult the user manual that comes with the 9665 or contact Hioki.

#### Safer due to channel-to-channel optical isolation

Connections between analog input channels, and between the input channel and the main unit, are fully isolated. This means that, unlike an oscilloscope, measurements can be made without concern with negative effects from voltage



differences. This is because connections between analog input channels, and between the input channel and the main unit, are fully isolated.



No missed high-speed signals

Capture switching waveforms accurately

| Available recording duration 5-second continuous recording at 200 MS/s |                 |               |           |           |            |  |  |  |
|--|-----------------|---------------|-----------|-----------|------------|--|--|--|
| h: hours, m: minutes, s: seconds                                       |                 |               |           |           |            |  |  |  |
| Sampling rate  | 1 ch            | 2 ch          | 3 to 4 ch | 5 to 8 ch | 9 to 16 ch |  |  |  |
| 200 MS/s   | 5 s             | 2.5 s         | 1 s       | 0.5 s     | 0.25 s     |  |  |  |
| 100 MS/s   | 10 s            | 5 s           | 2 s       | 1 s       | 0.5 s      |  |  |  |
| 50 MS/s  | 20 s            | 10 s          | 4 s       | 2 s       | 1 s        |  |  |  |
| 20 MS/s  | 50 s            | 25 s          | 10 s      | 5 s       | 2.5 s      |  |  |  |
| 10 MS/s  | 1 m 40 s        | 50 s          | 20 s      | 10 s      | 5 s        |  |  |  |
| 1 MS/s   | 16 m 40 s       | 8 m 20 s      | 3 m 20 s  | 1 m 40 s  | 50 s       |  |  |  |
| 100 kS/s   | 2 h 46 m 40 s   | 1 h 23 m 20 s | 33 m 20 s | 16 m 40 s | 8 m 20 s   |  |  |  |
| slower than above  | more than above |               |           |           |            |  |  |  |

(In the case that the internal memory and U8976 are used.)

Video describing measurement at up to 200 MS/s ► https://www.youtube.com/watch?v=VsEu4FFyaFA



## Fastest Save Processing in the Entire Series

- · Radically improved data saving time
- · Stress-free user experience

Transferring very large amounts of data measured over a long period of time used to be very time-consuming.

The MR6000 features a brand new interface and faster internal processing, reducing the time required to save measurement data to media.

For example, a save operation that took 1 minute on the previous model now completes in 2 seconds. This saves you the trouble of waiting for data to be saved and



| FTP     | Existing models |                   |
|---------|-----------------|-------------------|
| FIF     | MR6000          | ■ Reduced to 1/4  |
| USB 2.0 | Existing models |                   |
| 0362.0  | MR6000          | ■ Reduced to 1/5  |
| USB 3.0 | INIKOUUU        | ■ Reduced to 1/10 |
| HDD     | Existing models |                   |
|         | MR6000          | ■ Reduced to 1/20 |
| SSD     | INIU 0000       | ■ Reduced to 1/30 |

Video describing radically improved data save time 
https://www.youtube.com/watch?v=9glU9XUaH2o



32 ch

h at 1MS/s

Recording

Save Time Reduced to

1/30th Compared to

revious Mode

## Longest Continuous Recording in the Entire Series


- · Long-term recording and high-speed sampling in multiple channels
- · Instant analysis of measurement results

You can control the available measurement time by using the real-time save function and an additional storage media.

For long-term recording, we recommend ordering the MR6000 with a built-in high-capacity SSD or HD unit. You can also use a more convenient USB memory stick or SD memory card. All phenomena can be recorded at a high sampling rate over a long period of time.

#### Saving data directly to your PC

Transfer measurement data directly to your PC by using the FTP sending function or network drive function together with the real-time save function. This makes it easier to observe data after the measuring process.



#### Available real-time save duration when setting 1 MS/s

| Save destination     | ns       | Sampling rate | Number of channels | Available measurement duration | Maximum sampling rate for real-time save*1 |
|----------------------|----------|---------------|--------------------|--------------------------------|--|
| SSD Unit U8332       | (256 GB) | 1 MS/s        | 32 ch              | Approx. 1 h                    | 20 MS/s                                    |
| HD Unit U8333        | (320 GB) | 1 MS/s        | 16 ch              | Approx. 2 h 40 m               | 10 MS/s                                    |
| USB Drive Z4006      | (16 GB)  | 1 MS/s        | 8 ch               | Approx. 16 m                   | 5 MS/s*2                                   |
| SD Memory Card Z4003 | (8 GB)   | 1 MS/s        | 8 ch               | Approx. 8 m                    | 5 MS/s                                     |
| PC                   |          | 1 MS/s        | 8 ch               | Depends on PC capacity         | 5 MS/s                                     |

\*1: For 2 channels (no settings for 1 channel) \*2: When using the USB 3.0 connector

#### Maximum sampling speeds at which real-time saving is supported

| Save destination                              | Number of channels used |           |           |            |             |  |  |
|---|-------------------------|-----------|-----------|------------|-------------|--|--|
| Save destination                              | Up to 2 ch              | 3 to 4 ch | 5 to 8 ch | 9 to 16 ch | 17 to 32 ch |  |  |
| SSD Unit U8332                                | 20 MS/s                 | 10 MS/s   | 5 MS/s    | 2 MS/s     | 1 MS/s      |  |  |
| HD Unit U8333                                 | 10 MS/s                 | 5 MS/s    | 2 MS/s    | 1 MS/s     | 500 kS/s    |  |  |
| USB Drive Z4006<br>SD Memory Card Z4003<br>PC | 5 MS/s                  | 2 MS/s    | 1 MS/s    | 500 kS/s   | 200 kS/s    |  |  |

#### Maximum recording duration for real-time saveing with SSD UNIT U8332 (reference values) d: days, h: hours, m: minutes, s: seconds

| Sampling | The number of channels used |                    |                     |                     |                   |  |  |
|----------|-----------------------------|--------------------|---------------------|---------------------|-------------------|--|--|
| rate     | 2                           | 4                  | 8                   | 16                  | 32                |  |  |
| 20 MS/s  | 53 m 20 s                   | -                  | -                   | -                   | -                 |  |  |
| 10 MS/s  | 1 h 46 m 40 s               | 53 m 20 s          | _                   | _                   | -                 |  |  |
| 5 MS/s   | 3 h 33 m 20 s               | 1 h 46 m 40 s      | 53 m 20 s           | -                   | -                 |  |  |
| 2 MS/s   | 8 h 53 m 20 s               | 4 h 26 m 40 s      | 2 h 13 m 20 s       | 1 h 6m 40 s         | -                 |  |  |
| 1 MS/s   | 17 h 46 m 40 s              | 8 h 53 m 20 s      | 4 h 26 m 40 s       | 2 h 13 m 20 s       | 1 h 6m 40 s       |  |  |
| 100 kS/s | 7 d 9 h 46 m 40 s           | 3 d 16 h 53 m 20 s | 1 d 20 h 26 m 40 s  | 22 h 13 m 20 s      | 11 h 6 m 40 s     |  |  |
| 10 kS/s  | 74 d 1 h 46 m 40 s          | 37 d 0 h 53 m 20 s | 18 d 12 h 26 m 40 s | 9 d 6 h 13 m 20 s   | 4 d 15 h 6 m 40 s |  |  |
| 1 kS/s   | more than above             | more than above    | 185 d 4 h 26 m 40 s | 92 d 14 h 13 m 20 s | 46 d 7 h 6 m 40 s |  |  |



# An Extensive Line of Units for Detecting a Wide Range of Phenomena

Combine multiple units to record a range of phenomena. Use multiple logic units to measure relay ON/OFF signals or PLC (programmable logic controller) signals across up to 128 channels simultaneously. You can also measure temperature by attaching a thermocouple to a temperature unit







## Simultaneously measure up to 32 channels

#### 4ch Analog Unit U8975

The U8975 accepts direct input of up to 200 V DC across 4 channels. With a sampling rate of 5 MHz (across a frequency band of 2 MHz), high speed, and 16-bit resolution, it can perform multi-channel, high-speed, and high-resolution measurement.



Simultaneous measurement of multiple locations across 32 channels at 5 MS/s






## Record frequency fluctuation and pulse count/integration data

#### Frequency Unit 8970

Use the Frequency Unit 8970 to record measured waveform frequency, RPM, input pulse integration, duty ratio, and pulse width variations. It can accommodate numerous applications, including measurement of motor RPM, vehicle speed, and power supply frequency fluctuations. Thanks to a maximum input voltage of 400 V DC, it can also directly measure 3-phase circuit carrying up to 200 V.



Time




AC 700 V DC 1000 V

## Direct, high-voltage input without differential probes

#### High Voltage Unit U8974

The U8974 is ideal for measuring the primary and secondary sides of UPS power supplies and commercial power supply transformers. It can measure high-voltage power lines, including 380 V and 480 V circuits found in many countries. With high-speed sampling at up to 1 MS/s and 16-bit resolution, it can also be used in load rejection testing and switch testing.





Analyze correlations between phenomena, including voltage levels before and after generator disconnection, RPM fluctuation rates, governor servo operating status, and voltage governor switching timing.



resolution 0.1 μV

Minimum

## Specifically designed for DC voltage measurement with extremely high precision and resolution

#### Digital Voltmeter Unit MR8990

The MR8990 can measure minuscule fluctuations in sensor output of automobiles and voltage fluctuations in batteries, both at high precision and resolution. It can accommodate maximum input of 500 V DC. This high input impedance allows you to measure the battery voltage without being concerned about leakage current. Additionally, the amount of space taken up by instruments can be reduced by replacing a bench-style DMM with the MR6000. Systems can be simplified by eliminating the need to control multiple instruments.



Battery Battery pack





# Simultaneously measure up to 32 channels at high resolution 4ch Analog Unit U8978

Thanks to four input channels and a high-sensitivity 100 mV f.s. range, the U8978 can measure multiple channels of output from a variety of sensors. The unit is ideal for use in measuring currents of various magnitudes in the development of automobile accessory controls. Utilized in combination with the multi-range Current Probe CT6711, it can measure currents from 1 mA to 50 A.


## Observe minuscule currents using high-sensitivity wideband current probes

#### Current probe lineup

Analyze minuscule current waveforms from low-power-consumption devices in 100 µA resolution. Record device current consumption waveforms in high resolution over extended periods of time.



Current consumption waveform for a temperature and humidity sensor




During measurement with the CT6711 (10 V/A range)



## High-speed sampling lets you accurately measure inrush current

#### High-Speed Analog Unit U8976

Combine the High-Speed Analog Unit U8976's 30 MHz frequency band with the Current Probe CT6711 to measure inrush currents and minuscule currents.



#### Power can be supplied from the MR6000.

Power can be supplied to current probes by using the Power Probe Unit Z5021.



Hioki offers a wide range of current probes to suit all frequency band and rated current needs.



## 3ch 5 MS/s

## Single solution for 3-phase current measurement 3ch Current Unit U8977

The U8977 delivers a sampling rate of 5 MS/s, frequency characteristics of 2 MHz, 16-bit A/D resolution, and DC accuracy of 0.3% f.s. to facilitate wideband, high-precision current measurement using Hioki current sensors.

## Automatic configuration of sensor scaling values

When you connect a current sensor, the MR6000 will automatically detect the model and set the appropriate scaling value.



#### Connect sensors directly

## Power is supplied from the current unit

Since current sensor power is supplied directly from the current unit, there's no need to provide a sensor power supply.



## Compatible with high-precision sensors for measuring large currents


#### Current sensor lineup

Clamp-type high-accuracy sensors deliver excellent temperature characteristics, allowing highly accurate measurements to be made even in the confined space of a vehicle's engine compartment.




10043-03

#### Sensitivity variations of high-accuracy clamp-type sensors caused by temperature



#### Zero-point stability


Wideband flux gate technology delivers high zero-point stability over extended periods of time.



Hioki offers a wide range of current sensors to suit all frequency band and rated current needs.


## CAN/CAN FD Measurement, LIN Measurement

CAN buses carry not only control information, but also sensor information required by the ECU for control purposes. Analog values for sensor input signal quantities such as voltage, strain, temperature, flow rate, RPM, torque, vehicle speed, and vibration can be measured at the same time as these signals.



## Capture all data on the CAN and LIN bus during measurement

The MR6000 captures all frame data on the CAN or CAN FD bus and LIN bus during the set recording time. After measurement, you can specify the signals you wish to check and display them on the screen.



Choose signals to display after measuring all bus signals

#### Vector VN1600 interface family

#### Simple USB connection

Measure CAN signals without using a special unit. Using a Vector VN1600 interface family product, you can measure CAN signals simply by connecting it to the MR6000's USB port.

No effect on the input units

#### Principal CAN or LIN signal measurement specifications

 $^{\star}$  CAN bus and LIN bus cannot be measured at the same time.

| Compatible instruments                                     | Memory HiCorder MR6000/MR6000-01  |  |  |
|--|---|--|--|
| Compatible interfaces                                      | Vector VN1600 interface family  |  |  |
| Number of interfaces that can be connected                 | Up to 1   |  |  |
| Standards  | CAN, CAN FD, LIN*   |  |  |
| Number of CAN or LIN channels that can be measured         | Up to 4*  |  |  |
| Number of CAN or LIN signals that can be measured          | All frame data on CAN bus or LIN bus  |  |  |
| Number of CAN or LIN signals that can be displayed at once | While measuring: 64 preset signals After measuring: 16 signals can be selected and displayed from all recorded data |  |  |


\*Varies with the specifications of the Vector VN1600 product.

\*"Vector" refers to the Vector Group, whose parent company is Vector Informatik GmbH. \*Hioki is unable to provide Vector products. Please purchase those products separately.


## Load to waveform viewers compatibled with MDF format

Analog, logic, CAN, and LIN data measured using the MR6000 are saved in MDF (Measurement Data Format) and can be loaded by any waveform viewer that supports MDF.





Loading an MDF file on Measure Data Analyzer (MDA)



Loading an MDF file on Vector CANape (vSignalyzer)

## Load DBC and LDF files with the MR6000

For CAN For LIN

Set the definitions by loading DBC and LDF files on the MR6000. A PC is not required.

| File selection | Select the line to add to the ugnal settings. |           |             |            |           |        |       |           |
|----------------|---|-----------|-------------|------------|-----------|--------|-------|-----------|
| Signal         | 10  | Start bit | Dit length. | Byte coder | Data type | Resid  | Other | Check sum |
| ig184          |   |           | ,           | Little     | (Imagnes) | ,      | - 4   |           |
| Ng184          | 36  |           |             | Utse       | Unsigned  | 1      |       |           |
| Sig704         | - 3   |           | 7           | Utile      | Unsigned  | 1      | - 4   |           |
| Discrete       | 60  |           | 1           | Little -   | Unigned   | 1      |       |           |
| tine           | - 60  |           | 10          | Utte       | Unsigned  |        |       |           |
| State          | 64  | - 23      | 1           | Uttle      | Unsigned  | 1      | 11.0  |           |
|                | (4  |           | 18          | Utte       | Unsigned  | 0.3    | 1 19  |           |
| Counter        | 6   | 1 14      | 7           | Little     | thuignest | - 1    | - 0   |           |
| Sinclities:    | 11  | 16        | 16          | Little     | Unsigned  | 0.0001 | -1    |           |
| Sine           | 11  |           | 76          | Uttle      | Unsigned  | 0.5001 | -1    |           |
| Sine           | 80  |           | 19          | Utte       | Unsigned  | 0.0001 | -1    |           |
| head:          | 10  |           |             | Otte       | Unsigned  |        | - 0   |           |
| Peskt          | 1.0   |           | - 2         | Uttle      | Unsigned  | 1      | - 0   |           |

DBC file load screen

#### Transmit function

#### For CAN

You can send data configured before measurement to the CAN bus at the start of measurement or when a trigger is activated.



A shortcut key can be assigned to the transmit function

#### **CAN** trigger function

#### For CAN

You can use a CAN signal (frame) as a trigger source. The trigger will be activated when the set CAN signal type and ID is input.

#### Data frames

#### Remote frames

Set the ID, expressed by a hexadecimal value, as a trigger source.

#### Error frames

Error frames can also be set as a trigger source.

## Hioki offers CAN signal acquisition sensors

#### For CAN

Non-Contact CAN Sensor SP7001/SP7002

> No modification of vehicle cables Acquire signals simply by pinching the cables with the probe.

No effect on the CAN bus or vehicle ECUs

Non-contact sensing technology

Accurate, reliable signal capture Ideal for use in development and evaluation applications


## Real-time Waveform Processing Function

#### Real-time waveform processing

#### Exclusive MR6000-01 feature

#### Calculate measurement data during measurement

The MR6000-01 further features powerful technology designed for robust real-time waveform processing. This function performs arithmetic (addition, subtraction, multiplication, and division), differentiation calculations, or integration calculations during the measuring process, letting you check the calculated results via waveforms while measuring or monitor starting from set triggers. Results can be further processed after measurement and saved.



For example, you can calculate a differential waveform for input signals in real time and apply a trigger based on it. You can detect the timing of an input signal's local maximum and minimum values and output an external signal from the TRIG.OUT terminal.

| W1 | Comment | addition                |
|----|---------|-------------------------|
| On | Formula | (CH(1, 1)) + (CH(1, 1)) |
| W2 | Comment | sabtraction             |
| On | Formula | (CH(1, 1)) - (CH(1, 1)) |
|    | Comment | multiplication          |
| On | Formula | (CH(1, 1)) x (CH(1, 1)) |
| W4 | Comment | division                |
|    | Formula | (CH(1, 1)) / (CH(1, 1)) |

Simple setting method


Real-time waveform processing option

#### Digital filter calculations

#### Exclusive MR6000-01 feature

#### Observe clear waveforms without noise

Remove harmonic noise or specific frequency noise from measurement data. Use it to eliminate the noise that cannot be resolved with the standard filter installed in the unit.




## Long-term Recording Functionality

In addition to the real-time save function, the MR6000 provides a range of functionality for extended recording.

#### **Envelope function**

## Observe fluctuations over the long term with high-speed sampling

The system uses the envelope measurement method to record maximum and minimum values at set intervals while performing oversampling at 100 MS/s. The internal memory has a capacity of 1 G-words, which ensures that the measuring process can continue for a long time without any data loss. Save data in real time while measuring.



| Over-sampling speed | Recording interval | 1 ch               |      | 9 to 16 ch    |
|---------------------|--------------------|--------------------|------|---------------|
|                     | 10 MS/s            | 50 s               |      | 2 s           |
|                     | 1 MS/s             | 8 m 20 s           |      | 20 s          |
| 100 MS/s            | 100 kS/s           | 1 h 23 m 20 s      |      | 3 m 20 s      |
| 100 IVIS/S          | 10 kS/s            | 13 h 53 m 20 s     |      | 33 m 20 s     |
|                     | 1 kS/s             | 5 d 18 h 53 m 20 s |      | 5 h 33 m 20 s |
|                     |                    | more than a        | hove | 9             |

<sup>\*</sup>Limitations apply to measurable time when the U8975, U8977, U8978, or MR8990 is in use, and when performing real-time waveform processing.


#### **Dual sampling function**

#### Measure anomalies during extended testing with high-speed sampling

In vibration testing, it's necessary to record comprehensive test data for several hours. At the same time, it's necessary to capture areas of the waveform where anomalies occur with high-speed sampling for analysis once measurement is complete. The dual sampling function is useful in such situations.


#### (1) Record the entire trend waveform

Use the envelope function to record comprehensive test data for several hours.



## (2) Check details with the instantaneous waveform

Anomalies occurring during the test will be captured with high-speed sampling based on triggers that have been set up in advance. By tapping on a trigger mark's number, you can display the instantaneous waveform for the anomaly that occurred at that waveform area.



Tap to enlarge the anomaly waveform

# Trend waveform

## Verify that no anomalies occurred during extended testing

#### No trigger marks

If no instantaneous waveform triggers activated, there were no anomalies. By viewing the trend waveform, you can not only verify that no anomalies occurred, but also check whether the device under test operated properly.

## Trigger Function


#### Triggers that detect targeted events

Set triggers on any channel to record data whenever an event occurs. Triggers can be set for all channels.



#### Setting multiple triggers for a single channel


Set up to 4 triggers for a single channel. If, for instance, you set the glitch, level, window-in, and window-out triggers for the same input waveform, that waveform is monitored according to the set trigger conditions



## Display Functions

#### Numerical display function


This function is effective for checking the status before and during measurement.



Displays the measured value and the waveform at the same time.

#### Sheet function (display group) NEW Supported by MR6000 Ver.4.00.

The instrument supports 3-, 6-, and 9-segment screen displays, allowing measurement results for 3-phase circuits to be displayed efficiently.





X-Y display

NEW 9-screen display

FFT display






8-screen display



2-screen display


#### Scroll function

You can use the scroll function to check the waveform as if viewing it on paper.



#### Zoom function

The zoom function allows you to display all measurement waveforms on a single screen in the manner of an oscilloscope and to view desired locations in greater detail.



## Waveform Search Function

#### Easily search for waveforms in huge volumes of measurement data

#### Memory HiCorder Concierge function

The Memory HiCorder Concierge function automatically calculates the characteristics of a reference waveform set by the customer and then searches all measured data while identifying waveforms that do not resemble the reference waveform as anomalous waveforms

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually.

Additionally, this function is ideal for situations where it is difficult to set the right triggers before measuring because the nature of potential anomalies cannot be predicted.



#### Peak search

Search for the maximum value, minimum value, local maxima, or local minima in all of the measured data, and mark the search point in the waveform.

#### Trigger search

Set trigger conditions for all of the measured data after measurement to search for points where the conditions are fulfilled, even if no triggers were set before the measuring process.


#### Jump

Jump to an event mark you made while measuring, to the cursor position on the display, or to the measured data of a specified time.

### Waveform Generation Function

#### Achieving the dual role of generation and recording with a single unit


The arbitrary waveform generation function and waveform measurement function are realized by one Memory HiCoder.



## Waveform output as expected ARBITRARY WAVEFORM GENERATOR UNIT U8793

Waveform observation while changing test conditions, such as changing the signal type, amplitude and frequency, and programming various waveforms to output them sequentially, can be made easier.

#### Output waveform example



#### Waveform Maker Software included

After you install the included SF8000 Waveform Maker software on MR6000 or your computer, you can create waveforms easily by either entering them directly or by entering the formulas behind them. You can also quickly add noise and multiply waveforms.




#### **Anomaly Simulation**

Reproduce and output the observed waveforms without modification. When resolving problems observed during research or development, you can reproduce such problems for efficient testing. For example, you could output actual waveforms recorded from a car without modification, and then use them for standalone testing. You can also generate isolated output of up to 15 V while varying the signal's amplitude and frequency without using a generator or amplifier, which is traditionally necessary. For example, you can create a power waveform such as power supply dips, instantaneous interruptions, and voltage fluctuations to use in an immunity test (to cause malfunctions in equipment caused by power supply harmonics).




Reproducibility testing



Measurement of abnormal waveform in actual vehicles



Max. 15 V output + amplifier



Reproduce and output anomalous waveforms

Supported by MR6000 Ver.4.00









#### DC/sine wave output

#### **NEW** WAVEFORM GENERATOR UNIT MR8790

- · 4 channels · DC and up to 20 kHz sine wave signal output
- · Signal output ±10 V, 5 mA

## Pulse/pattern/logic/open collector output

#### **NEW PULSE GENERATOR UNIT MR8791**


- · 8 channels · Pulse waveform signal output
- $\cdot \ \text{Output mode (pulse output, pattern output, logic output, open collector output)} \\$

Supported by MR6000 Ver.4.00

## Power measurement functionality NEW Supported by MR6000 Ver.4.00.

#### Simultaneous measurement of a motor inverter's mechanical signals and power

The MR6000 can perform power measurement, which provides an effective means of evaluating the mechanical operation and electrical characteristics of equipment such as motor inverters. The instrument's power calculation function can display power values that change in small amounts of time on a cycle-by-cycle basis.



# Supplying power from the instrument Wher sense the 3r instrument AC/DC Current Sensor Power Cord 9248 Wher instrument University of the 3r instruments Power Cord 9248 Wher instrument or eight of the 3r instruments Probe Power Cord 9248 Wher instrument or eight of the 3r instruments Probe Power Cord 9248 Wher instrument or eight of the 3r instrument or eight or eight of the 3r instrument or eight or eight or eight of the 3r instrument or eight of the 3r instrument or eight or eigh


When a Hioki high-precision current sensor is directly connected using the 3CH Current Unit U8977, the instrument automatically detects the sensor. (There is a limit on how many sensors can be connected.)

When measuring high voltages, the instrument can supply power to up to eight Differential Probe 9322 units using the Power Cord 9248 and the Probe Power Unit Z5021.

#### NEW

#### Display of voltage, current, and power trends

When measuring voltage and current after configuring power calculation settings, the instrument automatically performs waveform calculations and displays power values. In addition, it can display calculation results after measurement if you configure the power calculation settings.




Example display of power calculation results

#### NEW

#### Cycle-by-cycle calculations

The instrument performs calculation processing for each cycle, defined as the interval from one zero-cross point to the next zero-cross point, based on the waveform chosen as the reference channel.



Power calculations based on detected cycles

#### NEW

#### Simple settings screen

A dedicated screen makes it easy to configure settings for power calculations, including wiring method and voltage and current channels.





No need to register detailed power equations

## Rotation angle measurement functionality NEW Supported by MR6000 Ver.4.00.

#### Measurement of resolver rotation angle

Using the waveform calculation function, the instrument acquires three channels of data (resolver excitation signal,  $\cos\theta$ , and  $\sin\theta$ ) and generates a trend display for the motor's rotation angle.






Example of resolver signal measurement

#### Measurement of rotary encoder rotation angle

Using the waveform calculation function, the instrument acquires the A, B, and Z pulse signals from the rotary encoder and generates a trend display for the motor's rotation angle.

\*Only incremental method is available. Absolute method is not available.






Illustration of PWM waveform and rotation angle recording

#### **Applications**


#### **Time Measurement**

By performing numerical calculations on measured waveforms, you can perform analyses using numerical parameters. Not only analog channels and logic channels, but also results of the real-time waveform calculation function can be used in this calculations.

#### Calculating switching times measured using logic channels (t1, t2, t3, T)

You can calculate time differences by applying numerical calculations to signals measured with logic channels.






Calculate the time difference T (s) at which waveforms A and B cross the specified level when either rising or falling.

Time difference T = Waveform B (time at which levels cross) - waveform A (time at which levels cross)

Reference channel (waveform A) calculation settings: Level Slope Calculation target channel (waveform B) calculation settings: Level Slope



Measurement waveforms and desired time differences


| Trigger time               | 12:00.0 |
|----------------------------|---------|
| No. 1 time difference (t1) | 1.50 s  |
| No. 2 time difference (t2) | 2.00 s  |
| No. 3 time difference (t3) | 1.00 s  |
| No. 4 time difference (T)  | 4.50 s  |

Example above: numerical calculation results

#### Calculating the time that elapses until a reading falls from the maximum value to a defined level (e.g. 50 V) after a capacitor is charged during capacitor charge/discharge testing

You can calculate the defined value by calculating the time at which the maximum value occurs and the time at which the specified level occurs using numerical calculations and then performing your desired arithmetic operations.






- 1. Calculate the time to the maximum value (A) Calculation settings: Time to maximum value
- 2. Calculate the time at the specified level (B) Calculation settings: Level Slope Filter
- 3. Subtract (A) from (B)

Calculation settings:

Calculation No. 1


arithmetic operation

Calculation No. 2



Trigger

Time to maximum value Calculate the time (s) from the trigger time until the maximum value. If the maximum value occurs at 2 or more points, the initial value will be treated



#### Specified level time

The Memory HiCorder searches for the point at which the previously set level is crossed. It then calculates the time between the start of the calculation range to that level crossing point


#### Four arithmetic operations Select the result of the numerical

calculation and apply your desired arithmetic operations (addition, subtraction, multiplication, or division).

#### Calculating the motor inrush starting current time (t1)

You can derive the desired time by calculating the burst width using numerical calculations.





#### Calculate the time at which the burst signal is output

Calculate the duration of an oscillating signal, for example the inrush current when a motor starts operating, as the burst width.

Calculation settings:

Filter **Statistics** Burst end filter Window (upper limit, lower limit)

#### Available calculation functions

Numerical calculations Perform up to 32 of 34 available calculations simultaneously during measurement.

| Average value         | Minimum value         | Rise time      | Specified level time |
|-----------------------|-----------------------|----------------|----------------------|
| RMS value             | Time-to-minimum value | Fall time      | Specified time level |
| Peak-to-peak value    | Period                | Area value     | Pulse width          |
| Maximum value         | Frequency             | X-Y area value | Duty ratio           |
| Time-to-maximum value | Standard deviation    |                |                      |


| Pulse count          | High level   | Overshoot  | Burst width        |
|----------------------|--------------|------------|--------------------|
| Arithmetic operation | Low level    | Undershoot | Integration values |
| Time difference      | Median value | + Width    | X-Y waveform angle |
| Phase difference     | Amplitude    | – Width    | CAN statistics     |

## Applications

# Motor Torque and Vibration Measurement

Using a strain-gage-type converter or acceleration sensor, you can measure torque and vibration during motor operation. Discover unpredicted frequency components by using FFT calculations to perform a frequency analysis.

#### Record torque and vibration during motor operation



## Simultaneous measurement and instantaneous analysis

The torque sensor (strain-gage-type converter) is connected to the Strain Unit U8969 to measure torque.


An acceleration sensor affixed to the chassis on which the motor is mounted, is connected to the Charge Unit U8979 to measure vibrations being transferred to the chassis.

The MR6000's FFT calculation function can be used to perform a frequency analysis of torque and vibration signals.

#### Available calculation functions

#### FFT calculation function


The MR6000 can analyze 8 phenomena simultaneously per measurement. Multiple FFT analyses of signals input from different channels let you investigate the frequency components that appeared for each channel at a single point in time. Similarly, conduct a variety of analyses for a single signal simultaneously.



FFT calculation 4-split screen


#### FFT analysis directly from the measured data

Perform FFT analysis from measured data. Simply touch the screen to specify the starting point for analysis, while simultaneously viewing the calculation results.



Chronological order + FFT calculation screen

#### Products used




\*1 Strain-gage-type converter
\*2 Charge-output-type with built-in
pre-amp (IEPE type)
(For more information about
sensors, please contact the sensor
manufacturer.)

## Measurement of Dynamic Motor Characteristics

By using the X-Y display function with RPM on the X-axis, you can analyze fluctuations in torque, motor power, motor efficiency, and inverter output power for each RPM level

#### Record fluctuations in various parameters from motor's start to stop



#### All-in-one measurement + pinpoint analysis

The signal from the torque sensor (Strain-gage-type converter) is measured with the Strain Unit U8969. Output from the motor's encoder (e.g. A-phase) is connected to the Frequency Unit 8970 to measure RPM.

The 3-phase inverter's voltage is measured using the 4ch Analog Unit U8978 and the Differential Probe 9322.

The 3-phase current is measured using the 3ch Current Unit U8977 and current sensors. Motor power, motor efficiency, and inverter output power are calculated after measurement using high-speed waveform processing, and the results are displayed using the instrument's X-Y display function.


#### Compositing over the specified X-Y interval

You can choose locations and generate an X-Y display of fluctuating waveforms from motor start to motor stop.

#### Available display functions

#### X-Y display function

The MR6000 provides an extensive range of X-Y displays for captured waveforms, including an X-Y 1-screen display, X-Y 2-screen display, X-Y 4-screen display, and time series display + X-Y 2-screen display. The ability to use the X-Y display for waveform processing results as well as input signals from measurement units means that you can perform a broad range of analyses.



4-screen X-Y display

#### XY waveform angle and area values

You can use the numerical calculation function on the X-Y display. Calculate XY waveform angle and area values using the numerical calculation function while viewing the X-Y display.

## Calculate regression lines for the XY composite and then calculate the slope

$$SLOPE = \frac{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x}) \cdot (y_i - \overline{y})}{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x})^2} \\ \sum_{i=1}^{n} (x_i - \overline{x})^2 \\ \text{xi: ith data point for $X$-axis channel} \\ yi: ith data point for $Y$-axis channel } \\ \theta = \arctan\left(SLOPE\right) \cdot \frac{180}{\pi} \left[ \circ \right] \\ \overline{x} \cdot \text{Average value for $X$-axis channel} \\ \overline{y} \cdot \text{Average value for $Y$-axis channel} \right]$$

#### Calculate the area of the XY composite

X-Y area value (coordinate method) with multiple curves



 $S = n \times S0$ S: Area value n: Number of curves

Start point, end point

#### Products used



|                              |                               |                               |                              |                                |                      |   | · · · · · · · · · · · · · · · · · · · |                             |  |
|------------------------------|-------------------------------|-------------------------------|------------------------------|--------------------------------|----------------------|---|---------------------------------------|-----------------------------|--|
| Recording                    | Voltage me                    | easurement                    | Current measurement          |                                | Torque me            | asurement   | RPM measurement                       |                             |  |
| Memory<br>HiCorder<br>MR6000 | 4ch Analog<br>Unit<br>U8978*1 | Differential<br>Probe<br>9322 | 3ch Current<br>Unit<br>U8977 | Current<br>Sensor<br>CT6843-05 | Strain Unit<br>U8969 | Torque<br>sensor*2<br>Products<br>from other<br>manufacturers | Frequency<br>Unit<br>8970             | Connection<br>Cord<br>L9790 |  |
| 1                            | 1                             | 3                             | 1                            | 3                              | 1                    | 1   | 1                                     | 1                           |  |

- \*1 The 4ch Analog Unit U8975 can be used when measuring voltages of 100 V AC or less.
- \*2 Strain-gage-type converter (for more information about the sensor, please contact the sensor manufacturer.)

#### Software



Load data measured with the MR6000/ MR6000-01 onto a PC to display waveforms and perform calculations

Intuitive operation

Waveform processing


FFT calculations


Utilize functionality similar to that provided by the MR6000 on a PC, including numerical calculations, waveform processing, and FFT calculations. (Some restrictions apply.)

| Supported models           | MR6000, MR6000-01  |
|----------------------------|--|
| Supported operating system | Windows 10 (64-bit) For other system requirements, please see the user manual. |
| Availability               | Free download from the Hioki website   |

#### Waveform display zoom

Zoom each axis in or out by spinning the mouse's scroll wheel while placing the cursor over either the left or bottom of the screen.





#### Functionality similar to the MR6000


unctionality and usability

You can display data, change settings, perform calculations, and save data in the MR6000 Viewer.




#### Ideal for creating reports

Copy a screenshot of the waveform screen to the clipboard.



#### Wave Processor 9335 (sold separately)

The 9335 provides waveform display, processing, and printing functionality.



#### Overview of 9335 specifications


| System requirements | Windows 10/8/7 (32-bit/64-bit)  |
|---------------------|---|
| Functionality       | Display functionality: Waveform display, X-Y display, cursor function, etc.     File loading: Loadable data formats (.mem, .rec, .rms, .pow); The maximum loadable file is the maximum size of the Memory HiCorder being used. (The loadable file size is also dependent on the maximum size that can be saved by the PC being used.)     Data conversion: Conversion to CSV format, batch conversion of multiple files, etc. |
| Printing            | Printing functionality: Save print image file (in .emf format) 1, 2, 4, 8, or 16 graphs; 2, 4, 8, or 16 rows, 1, 2, or 4 X-Y graphs; preview; hard copy   |

#### Waveform Viewer Wv (standard accessory)

Download the latest version from Hioki's website.

Waveform Viewer Wv, which provides functionality for displaying and converting waveforms, is a standard accessory.

It allows you to review binary data for waveforms captured by a Memory HiCorder on a PC and convert it to CSV format so that it can be loaded by Excel.



#### Example Excel screen

Overview of Waveform Viewer (Wv) specifications

| System requirements | Windows 10/8/7 (32-bit/64-bit)  |
|---------------------|---|
| Functionality       | Simple display of waveform files     Conversion of binary-format data files to text format (e.g. CSV)     Scroll, display zoom in/out, jump to cursor/trigger point |

#### Comparison with other Hioki software

| Software                    | MR6000 Viewer                                     | Wave Processor 9335             | Waveform Viewer (Wv)       |
|-----------------------------|---|---------------------------------|----------------------------|
| Waveform screen             | Yes   | Yes                             | Yes                        |
| Trace cursor                | Yes   | Yes                             | Yes                        |
| Saving                      | .csv, .txt, .set, .bmp, .png, .jpeg, binary, .flt | .csv, .txt                      | .csv, .txt                 |
| Settings                    | Yes*1   | No                              | No                         |
| Printing                    | No  | Screen image, detailed printing | No                         |
| Numerical calculations      | Yes   | Yes                             | No                         |
| Waveform processing         | Yes   | No                              | No                         |
| FT calculations             | Yes   | No                              | No                         |
| K-Y display                 | Yes   | Yes                             | No                         |
| Supported operating systems | Windows 10 (64-bit)                               | Windows 10, Windows 8,          | Windows 7 (32-bit, 64-bit) |
| Price                       | Free  | Varies with region              | Free                       |



Bringing Field Measuring Results to Your PC Simultaneous Observation of Data from Multiple Instruments

Data collection

Real-time performance Batch display and saving

GENNECT One lets you display and save data in real time on a PC during measurement. It also serves as a useful tool in measurement applications that include other instruments.

| Supported models           | MR6000, MR6000-01, etc.  |
|----------------------------|--|
| Supported operating system | Windows 7 (32-bit / 64-bit), Windows 8.1 (32-bit / 64-bit)<br>Windows 10 (32-bit / 64-bit), Windows 11 |
| Availability               | Free download from the Hioki website   |

## LAN remote control function

Connect to instruments via a LAN.


Change instrument settings and control operation, for example to start or stop measurement.



Example remote control screen

#### Simultaneous, real-time observation

GENNECT One lets you display data from multiple instruments together and in real time in list or graph form.




(up to 512 parameters)

(up to 32 parameters)

List display (up to 32 parameters)

#### Commercially available software

#### **FAMOS**




- · More than 400 calculation processing variables
- · Easy report creation functionality Download a free MR6000 import filter free of charge from Hioki's website.

#### FlexPro




- · High-speed search and processing of large volumes of data
- · Share analysis templates inside your company

#### NI DIAdem



- · Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface

#### OS-2000



- $\cdot$  Freely edit large data that cannot be handled by Excel
- · Simultaneously display the waveforms which have different frequencies

#### Control scripts and drivers

On Hioki's website, search for "MR6000" > "Downloads" > "Drivers, Firmware & Software" to find downloadable drivers.


#### **MATLAB**

Available scripts allow you to directly load waveform data measured and saved using the MR6000's memory function, while control scripts let you start and stop measurement, acquire measurement data, and configure measurement settings.





#### LabVIEW

An available driver lets you control the MR6000 and acquire measurement data. The driver was created using LabVIEW 2009 sp1, and it has been confirmed to operate with LabVIEW 2017.



#### Multifunctional Interface







Onen or close the top panel of the main unit Z4006 USB DRIVE installable

#### Only 6 keys in total New recorder design

Use the touch screen to configure all the basic settings.

#### Display

12.1-inch capacitive touch screen TFT color LCD display

#### USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### SAVE button

For displaying the manual save dialog box

#### Shortcut button 1

For registering frequently used settings

#### Shortcut button 2

For registering frequently used settings

#### Rotary knob X

For moving the tracing cursor and scrolling or zooming the waveform in and out

#### Rotary knob Y

For changing the position and zooming the waveform in and out

#### START button

To begin the measuring process

#### STOP button

For importing the set recording length and stopping the measuring process

#### Power button

For turning the power on or off

#### USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### USB 3.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### SD MEMORY CARD slot For inserting SD memory cards

Output terminal for probe compensation signals For outputting 10:1 or 100:1 PROBE compensation signals

#### KEY LOCK

For disabling the touch screen and buttons

For carrying the device

#### 1000 BASE-T connector

For connecting to a network via LAN cable

#### **DVI terminal**

For outputting the screen display

#### External sampling terminal

For inputting various external sampling signals

#### External control terminal

For inputting various external signals to control the device

## Dedicated power supply terminal for current sensors

For supplying power to current sensors (option)

#### Various units

Install input units appropriate for the measurement target

#### Air inlet

For reducing the internal temperature

#### Media box

For USB 3.0 connectors (USB memory sticks only)

#### Operability and visibility suited for a variety of work environments



Our search for a touch screen with the best operability and visibility angle led us to develop retractable feet that maximize those two important attributes. Tilting the MR6000 with the feet reduces a desk, and keeps your line of sight at a natural level.

# Convenient long handle Robust design

#### Easy handling

The rubber handle boasts excellent grip and makes it easy to carry the device with either one or both hands. The grips on either side of the device can also be used to lift it with both hands.

## Compared to conventional models 1/2 size See compared to 8861-50

#### Space-saving size

We have achieved a design that is compact while still delivering blazing fast processing speeds by using thermal liquid analysis to optimally position the air inlets, heating components, and cooling fans.

#### Sleek design

The beveled corners of the Memory HiCorder's body gives the device a compact and sleek look. This simple and refined appearance is sure to be a strong addition to the creative environment of any R&D workspace.

#### Ergonomical operating angle

the strain on your wrists when you use the device on





#### **Product Specifications**

| Basic Specifications<br>(Accuracy guaranteed for  | 1 year)  |  |  |  |  |  |
|---|--|--|--|--|--|--|
|   | Normal: Regular way<br>Envelope: Periodica   | veform recording<br>Ily recording maximum and minimum values   |  |  |  |  |
| Recording method  | *Envelope setting no   | t available with external sampling   |  |  |  |  |
|   | Dual sampling: Records waveforms at a sampling speed different from the envelope sampling speed during envelope measurement.   |  |  |  |  |  |
|   | Analog with up to 32 channels (with 4ch ANALOG UNIT U8975/U8978)   |  |  |  |  |  |
| No. of channels   | Logic with up to 128 channels (LOGIC UNIT 8973)  *Common GND for the logic probe input connector and main unit CAN/LIN: Up to 64 channels  *CAN/LIN bus data logging function  200 MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT U8976)  |  |  |  |  |  |
|   |  |  |  |  |  |  |
| Maximum sampling  |  |  |  |  |  |  |
| rate  | External sampling (1   | 0 MS/s)  |  |  |  |  |
| Memory capacity   | 1 G-words  |  |  |  |  |  |
| Operating environment Operating temperature   |  | egree 2, altitude up to 2000 m (6562.20 ft)  |  |  |  |  |
| and humidity range  | 0°C to 40°C (32°F to   | 104°F), 80% RH or less (non-condensing)  |  |  |  |  |
| Storage temperature<br>and humidity range   | -10°C to 50°C (14°F  | to 122°F), 80% RH or less (non-condensing)   |  |  |  |  |
| Compliance standards  | Safety: EN61010, EN  | MC EN61326   |  |  |  |  |
| _   | Rated supply voltag<br>for rated supply voltag   | e: 100 V to 240 V AC (consider ±10% voltage fluctuations   |  |  |  |  |
| Power supply  | Rated power supply   | frequency: 50 Hz / 60 Hz<br>t overvoltage: 2500 V  |  |  |  |  |
| Max. power consumption  | 300 VA   | t over voltage. 2000 v   |  |  |  |  |
| Clock   | Auto-calendar, leap-   | year correcting 24-hour clock  |  |  |  |  |
| Backup battery life   |  | 23°C (73°F)) for clock and settings  |  |  |  |  |
| PC interface (overview)  External dimensions  | 353 mm (13.90 in) W x  | a, morntor<br>235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  |  |  |  |  |
|   | 6.5 kg (229.3 oz) (m   | ain unit only)   |  |  |  |  |
| Mass  |  | th Z5021, U8332, or U8333 installed)<br>th HIGH SPEED ANALOG UNIT U8976 installed)   |  |  |  |  |
| Accessories   |  | rt Manual (booklet, CD-R), operating precautions (booklet),<br>), Instruction Manual (detailed edition) (CD-R), Instruction Manua  |  |  |  |  |
|   |  | functions edition) (CD-R), blank panel (blank slot only)   |  |  |  |  |
| Accuracy  |  |  |  |  |  |  |
| Accuracy guarantee conditions   | Temperature and hu   | midity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  |  |  |  |  |
| Time axis accuracy  | ±0.0005%   |  |  |  |  |  |
| Display   | 12 1 inch VCA TET  | Olor I CD (1024 v 759 doto) with acceptation to the  |  |  |  |  |
| Display type  LAN Interface   | 12.1 Inch XGA IFT C  | olor LCD (1024 x 768 dots) with capacitive touch screen  |  |  |  |  |
| Compatibility specifications  | IEEE 802.3 Ethernet  | 1000BASE-T, 100BASE-TX, 10BASE-T   |  |  |  |  |
| Functions   |  | TTP, Network drive, e-mail sending function  |  |  |  |  |
| Connector  Maximum cable length   | RJ-45<br>100 m (328.11 ft)   |  |  |  |  |  |
| USB interface   | 100111 (320.1111)  |  |  |  |  |  |
|   |  |  |  |  |  |  |
| Compatibility specifications  | USB 3.0 compliant x  | 3, USB 2.0 compliant x 4   |  |  |  |  |
| Compatibility specifications  Host  | Connector: Series A  | receptacle   |  |  |  |  |
|   | Connector: Series A  | receptacle<br>Keyboard, mouse, USB memory stick  |  |  |  |  |
| Host Available options SD card slot   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR   | receptacle<br>Keyboard, mouse, USB memory stick<br>Y STICK (16 GB)   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications  | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards)   |  |  |  |  |
| Host Available options SD card slot   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR   | receptacle<br>Keyboard, mouse, USB memory stick<br>Y STICK (16 GB)   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications  | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR<br>Compliant with SD star<br>USB MEMORY STIC<br>Serial ATA Revision   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  |  |  |  |  |
| Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR<br>Compliant with SD star<br>USB MEMORY STIC<br>Serial ATA Revision   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR<br>Compliant with SD star<br>USB MEMORY STIC<br>Serial ATA Revision   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMORY<br>Compliant with SD stat<br>USB MEMORY STIC<br>Serial ATA Revision<br>U8332 SSD UNIT (2)  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output   | Connector: Series A<br>Connected devices:<br>Z4006 USB MEMOR<br>Compliant with SD star<br>USB MEMORY STIC<br>Serial ATA Revision<br>U8332 SSD UNIT (29   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB)  inalog output for external display   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t   | Connector: Series A Connected devices: Z4006 USB MEMOR Compliant with SD star USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2014) Digital output* and a 1024 x 768 (XGA) "Dual-link not suppoterminal  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB)  inalog output for external display   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector   | Connector: Series A Connected devices: Z4006 USB MEMORY Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2:  DVI-I Digital output* and a 1024 x 768 (XGA) "bual-link not suppo   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB)  inalog output for external display   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t   | Connector: Series A Connected devices: Z4006 USB MEMORY Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) "Dual-link not suppo germinal SMB 10 V DC   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB)  inalog output for external display   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width  | Connector: Series A Connected devices: Z4006 USB MEMOR Compliant with SD star USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (20 DVI-1 Digital output* and a 1024 x 768 (XGA) "Dual-link not suppoterminal SMB SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during serial devices."  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  unalog output for external display  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency  | Connector: Series A Connected devices: Z4006 USB MEMORY Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2:  DVI-I Digital output* and a 1024 x 768 (XGA) "bual-link not suppo erminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display reted  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions  | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 x 768 (XGA) *Dual-link not suppo erminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz External sampling of Rising, falling, rising falling, rising  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display reted  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter   | Connector: Series A Connected devices: Z4006 USB MEMOR Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (26) U8332 SSD UNIT (27) U8332 SSD UNIT (28) U8332 SSD UNIT (29) U8332 SSD UNIT (20) U8332 SSD UN | receptacle Keyboard, mouse, USB memory stick YY STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  inalog output for external display rited  n level, 0 V to 0.8 V for low level In ligh periods, 50 ns or more during low periods ock input  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 x 768 (XGA) *Dual-link not suppo erminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz External sampling of Rising, falling, rising falling, rising  | receptacle Keyboard, mouse, USB memory stick YY STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  inalog output for external display rited  n level, 0 V to 0.8 V for low level In ligh periods, 50 ns or more during low periods ock input  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision UB332 SSD UNIT (2: DVI-I Digital output* and a 1024 x 768 (XGA) *Dual-link not suppoterminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz External sampling cl Rising, falling, rising minals Push-button type Maximum input voltage Input voltage  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  a level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block                                    | Connector: Series A Connector Series A Connected devices: Z4006 USB MEMORY COMPliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2): DVI-1 Digital output* and a 1024 x 768 (XGA) "Dual-link not support of the property  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  nalog output for external display  rted  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block                                    | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision UB332 SSD UNIT (2: DVI-I Digital output* and a 1024 x 768 (XGA) *Dual-link not suppoterminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz External sampling cl Rising, falling, rising minals Push-button type Maximum input voltage Input voltage  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  a level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block                                    | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the control of  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  a level, 0 V to 0.8 V for low level y high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods 200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block                                    | Connector: Series A Connector Series A Connected devices: Z4006 USB MEMORY STIC USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2): DVI-1 Digital output* and a 1024 x 768 (XGA) "Dual-link not suppoterminal SMB 10 v DC 2.5 v to 10 v for high 50 ns or more during 10 MHz External sampling of Rising, falling, rising minals Push-button type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output type  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  rted  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output)   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the control of  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  a level, 0 V to 0.8 V for low level y high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods 200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 x 768 (XGA) **Dual-link not suppoerminal SMB 10 V DC 2.5 V to 10 V for high 50 ns or more during 10 MHz External sampling clinging, rising minals Push-button type Maximum input voltage Input voltage Input voltage Input of terminals Fushors pulse width Pulse interval Number of terminals Functions Output type Output voltage   | receptacle Keyboard, mouse, USB memory stick YY STICK (16 GB)  Indards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  Inted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) "Dual-link not suppo Germinal SMB 10 V DC 2.5 V to 10 V for high SO Ns or more during 10 MHz External sampling of Rising, falling, rising minals Push-button type Maximum input voltage Input voltage Response pulse width Pulse interval Number of terminals Functions Output type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output type Maximum input voltage   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  redd  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2  Judgment (PASS), judgment (FAIL), occurrence of errors   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) "bual-link not suppoerninal SMB 10 V DC 2.5 V to 10 V for high Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) "bual-link not suppoerninal SMB 10 V DC 2.5 V to 10 V for high Serial Seri | receptacle Keyboard, mouse, USB memory stick YY STICK (16 GB)  Indards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  Inted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector Series A Connected devices: Z4006 USB MEMORY Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) "Dual-link not suppoerminal SMB 10 V DC 2.5 V to 10 V for high State of the Stat | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  analog output for externa |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the property of th | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  inalog output for external display rited  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater  2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output)  4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input   | Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) *1024 × 768 (XGA) *1024 × | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  Idards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  reted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  cock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the property of th | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  rdards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  rted  rted  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ook input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during high periods for the periods and the periods are the periods are the periods and the periods are |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter   | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the property of th | receptacle Reyboard, mouse, USB memory stick Y STICK (16 GB)  adards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  rited  a level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater  2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output)  4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level  50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  External trigger filter ON: 2.5 ms or more during high periods, 2 us or more during low periods  External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods  Rising, falling, rising & falling (user-selectable)  Rising, Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V).   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output | Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the property of the | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  Idards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  reted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  cock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  External trigger filter OFF: 2 ms or more during high periods, 2.5 ms or more during low periods  Rising, Taling, rising & falling (user-selectable)  Rising, Taling, rising & falling (user-selectable)  Risling, Taling, rising & falling (user-selectable)  Risling, Talingering occurs when the voltage falls from  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output | Connector: Series A Connector devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the property of th | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  Idards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  rted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2. us or more during low periods  External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during the veltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V) to low (0 V to 0.8 V) or when a terminal short circuit occurs.  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output               | Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the property of the | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  Idards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  rted  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter OFF: 2. ms or more during high periods, 2. so ms or more during high periods, 2.  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output               | Connector: Series A Connected devices: Z4006 USB MEMORY STIC With SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) * 7024 l-link not support of the state  | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  Idards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  Inalog output for external display  rited  In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  cock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter of 2.5 ms or more during high periods, 2.5 ms or more during high periods and periods with the voltage falls from high (2.5 V to 10 V) to high (2.5 V to 10 V). Telling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to low (0 V to 0.8 V) or when a terminal short circuit occurs.  When the trigger timing is set to [START&STOP], the edge to be used can be chosen between reising, falling, and both rising & falling for each of [START] and [STOP]   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output               | Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the property of the | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  rdards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  rted  rted  rted  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  External trigger filter OFF: 2. ms or more during high periods, 2. s ms or more during high periods, 2. s ms or more during low periods  External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods  External trigger filter ON: 2.5 ms or more during high periods, 2.5 vice 10 vices when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V),  Falling: Triggering occurs when the voltage rises from high (2.5 V to 10 V), to low (0 V to 0.8 V) or when a terminal short circuit occurs.  When the trigger timing is set to (START&STOP), the edge to be used can be chosen between rising, falling, falling,   |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling t Connector Maximum input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block External input External output External output   | Connector: Series A Connected devices: Z4006 USB MEMORY Compliant with SD stat USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2:  DVI-I Digital output* and a 1024 × 768 (XGA) "bual-link not suppo germinal SMB 10 V DC 2.5 V to 10 V for high 50 Ns or more during 10 MHz External sampling of Rising, falling, rising minals Push-button type Maximum input voltage Input voltage Input voltage Number of terminals Functions Output type Output voltage Maximum input voltage Number of terminals Functions Maximum input voltage Number of terminals Functions Maximum input voltage Maximum input voltage External trigger filter Response pulse width Functions Output type Output voltage Functions Output type Output voltage Maximum input voltage External trigger filter Response pulse width Functions   | receptacle Keyboard, mouse, USB memory stick Y STICK (16 GB)  rdards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display  rted  rted  n level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input 8 falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 0.5 V to 10 V), Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V), Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V), Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V), Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V), Falling: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high evel, 0 V to 0.8 V) or when a terminal short circuit occurs.  When the trigger timing is set to [START] and [STOP], Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  |  |  |  |  |
| Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling i Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block  External input  External input  External output | Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2: DVI-I Digital output* and a 1024 × 768 (XGA) "Dual-link not suppo erminal SMB 10 V DC 2.5 V to 10 V for high SV to 10 V for high summer of the property of | receptacle Reyboard, mouse, USB memory stick Y STICK (16 GB)  ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)  3.0 compliant x 1  56 GB), U8333 HD UNIT (320 GB)  analog output for external display rited  nlevel, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods  ock input & falling (user-selectable)  10 V DC  2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods  200 ms or greater 2  START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW  2  Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby  10 V DC  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods Rising, falling, rising & falling (user-selectable) Rising, Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage fries from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage fries from high (2.5 V to 10 V) to 10 (V to 0.8 V) or when a terminal short circuit occurs.  When the trigger tilling for each of (START) and (STOP), Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level   |  |  |  |  |

| Output signals  | r probe correction   | SIGNAIS<br>Hz ±1% square waves   |  |  |  |
|---|--|--|--|--|--|
| Functions   |  | 100:1 PROBE 9666 correction  |  |  |  |
|   |  |  |  |  |  |
|   | 1  | current sensor<br>with PROBE POWER UNIT Z5021 installed)   |  |  |  |
| Number of terminals Output voltage  | ± 12 V ± 0.5 V DC  |  |  |  |  |
| Trigger *Not available  | when the real-time say   | ve function is used  |  |  |  |
| Trigger type  | Digital comparison t   | уре  |  |  |  |
| Trigger conditions  |  | n for trigger sources and interval trigger   |  |  |  |
|   | When START or ST   | me waveform processing<br>OP is selected: Up to 32 channels  |  |  |  |
|   | *Up to 4 logic trigg   | iggers can be set for each analog channel.<br>gers can be set for each logic probe.  |  |  |  |
|   | When START&STO   | gers can be set for each real-time waveform processing channel<br>P is selected: Up to 16 channels / group   |  |  |  |
| Trigger source  | Logic: Up to 16 pr   | hannels / group (Up to 2 channels per unit can be selected.) robes / group (Up to 2 probes per unit can be selected.)  |  |  |  |
|   |  | n processing: Up to 16 calculations / group<br>pes from each group can be set for each analog channel.   |  |  |  |
|   | *Up to 2 logic trigg<br>External trigger   | gers from each group can be set for each logic probe.  |  |  |  |
|   |  | n is activated if all trigger sources are turned off.  |  |  |  |
|   | Level trigger  | Triggering occurs when the set level rises (falls).  Triggering occurs when peak voltage drops below the set level.  |  |  |  |
|   | Voltage drop trigger   | (For a 50 Hz / 60 Hz commercial power supply only) *1, *2, *3  |  |  |  |
|   |  | Sets the upper and lower limit for trigger level.  |  |  |  |
|   | Window trigger   | Triggering occurs when leaving (OUT) or entering (IN) the area *1  |  |  |  |
|   |  | Sets the period reference value and cycle range.   |  |  |  |
|   | Period trigger   | Triggering occurs when the rising (falling) reference value period is measured and determined to be outside or within the cycle range.   |  |  |  |
| Analog triggers   |  | *1, *2, *3  Sets the reference value and pulse width (glitch width).   |  |  |  |
|   | Glitch trigger   | Triggering occurs if the value is below the set pulse wid  |  |  |  |
|   |  | from rising or falling of the reference value. *1, *Not available with MR8990, *3  |  |  |  |
|   |  | Specifying events (1 to 4000)  Counts the number of times conditions were fulfilled for each trigge  |  |  |  |
|   | Specifying events  | source. Triggering occurs when the set number of times is reached *Not available when the trigger conditions are set to AND  |  |  |  |
|   |  | *1: Disabled when sampling rate is set to 200 MS/s.  |  |  |  |
|   |  | *2: Not available with MR8990 or 8970 *3: Not available with envelope setting  |  |  |  |
| Logic trigger   | Pattern trigger using  | 1, 0, or x   |  |  |  |
| Forcible trigger  |  | riggering can be prioritized over all trigger sources.)  |  |  |  |
| CAN trigger   | or remote frame.   | ggered when receiving a specific data frame, error frame   |  |  |  |
|   | When a data frame is chosen, the instrument can be triggered by comparing between bits in specific byte positions.   |  |  |  |  |
| Interval trigger  | Recording possible at  | t specified measuring intervals (hours, minutes, or seconds) as are fulfilled when the measuring process starts.   |  |  |  |
|   |  | er conditions are met at the set measuring intervals.  |  |  |  |
| Trigger filter  | Normal   | OFF, 10, 20, 50, 100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples   |  |  |  |
|   | Envelope   | OFF, 1 ms, 10 ms   |  |  |  |
| Trigger level setting resolution  |  | lue set in 1% steps available), displaying the recording   |  |  |  |
| Pre-trigger   | time for pre-trigger   |  |  |  |  |
| Post-trigger<br>Trigger priority  | 0% to 40%, displayir<br>ON / OFF   | ng the recording time for post-trigger   |  |  |  |
| Trigger mark  |  | ks for the positions where triggers are set.   |  |  |  |
| Trigger timing  | START, STOP, STAR  |  |  |  |  |
| Waveform monitoring display   | Displays the wavefor<br>be turned off.)  | rm monitor in the trigger standby state. (The display can  |  |  |  |
| Waveform screen   |  |  |  |  |  |
|   | Time-domain  | 1, 2, 3, 4, 6, 8, 9, 16 screens<br>(Up to 64 channels can be displayed on each sheet.)   |  |  |  |
|   | waveform   |  |  |  |  |
|   | Trepresentation  | (Every channel can be set to be displayed on multiple  |  |  |  |
|   | representation   | sheets.)   |  |  |  |
| Display format  |  | sheets.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens)   |  |  |  |
| Display format  | XY composite waveform display  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set)   |  |  |  |
| Display format  | XY composite   | sheefs.)  1. 2. 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled)   |  |  |  |
| Display format  | XY composite   | sheets.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms  |  |  |  |
| . ,   | XY composite waveform display  | sheefs.)  1, 2, 4 Screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)  |  |  |  |
| Sheet function  | XY composite<br>waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)  1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  *The display format can be selected for each sheet. are displayed in chronological order in the top part of the   |  |  |  |
| Sheet function Zoom display   | XY composite<br>waveform display  FFT display  Up to 16 sheets ON/OFF (Waveforms waveform screen, whe  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zooned waveforms are displayed in the bottom part.)  |  |  |  |
| Display format  Sheet function  Zoom display  Full screen display  Grid anchoring mode  | XY composite waveform display  FFT display  Up to 16 sheets ON / OFF (Waveforms waveform screen, whe Displays waveforms The waveform display   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)  1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  *The display format can be selected for each sheet.  are displayed in chronological order in the top part of the reast the zoomed waveforms are displayed in the bottom part.)  over the entire waveform screen.  ay position can be defined by specifying a waveform   |  |  |  |
| Sheet function  Zoom display  Full screen display   | XY composite waveform display  FFT display  Up to 16 sheets ON / OFF (Waveforms waveform screen, whe Displays waveforms The waveform display   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  "The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  |  |  |  |
| Sheet function  Zoom display  Full screen display   | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveform sispla display magnification   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)  1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  *The display format can be selected for each sheet.  are displayed in chronological order in the top part of the reast the zoomed waveforms are displayed in the bottom part.)  over the entire waveform screen.  ay position can be defined by specifying a waveform n and a zero-level position.  |  |  |  |
| Sheet function  Zoom display  Full screen display   | XY composite waveform display  FFT display  Up to 16 sheets ON / OFF (Waveforms waveform screen, whe Displays waveform display magnification Waveform color Interpolation Variable display   | sheels.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  "The display format can be selected for each sheet, are displayed in chronological order in the top part of the treas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  ay position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors) Linear  |  |  |  |
| Sheet function  Zoom display  Full screen display   | XY composite waveform display  FFT display  Up to 16 sheets  ON/OFF (Waveforms waveform screen, whe Displays waveforms The waveform display magnification Waveform color Interpolation   | sheels.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen. ap position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  | XY composite waveform display  FFT display  Up to 16 sheets ON / OFF (Waveforms waveform screen, whe Displays waveform display magnification)  Waveform color Interpolation Variable display Waveform display magnification Waveform display Waveform display Waveform display   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  *The display format can be selected for each sheet.  are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.)  over the entire waveform screen.  ay position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enable.  |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  | XY composite waveform display  FFT display  Up to 16 sheets ON/OFF (Waveforms waveform screen, whe Displays waveforms The waveform displat display magnification Waveform color Interpolation Variable display Waveform display magnification Waveform display waveform display waveform display waveform display waveform display waveform display position   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  The display format can be selected for each sheet. are displayed in chronological order in the top part of the treas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  aly position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors) Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enable   |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveforms The waveform display magnification Waveform color Interpolation Variable display magnification Waveform display magnification Waveform display regordisplay position Vernier  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  "The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  ay position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled in increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustment range: 50% to 250% of the input)   |  |  |  |
| Sheet function Zoom display   | XY composite waveform display  FFT display  Up to 16 sheets ON/OFF (Waveforms waveform screen, whe Displays waveforms The waveform displat display magnification  Waveform color Interpolation Variable display Waveform display magnification Waveform display waveform display position Vernier Grid   | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  *The display format can be selected for each sheet.  are displayed in chronological order in the top part of the reast the zoomed waveforms are displayed in the bottom part.)  over the entire waveform screen.  ay position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enable In increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON   |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveforms The waveform display magnification Waveform color Interpolation Variable display magnification Waveform display magnification Waveform display regordisplay position Vernier  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  'The display format can be selected for each sheet. are displayed in chronological order in the top part of the reast he zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  ay position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100 to 1/10x (available when grid anchoring mode is enabled)  In increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down.   |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  Waveform display  | XY composite waveform display  FFT display  Up to 16 sheets  ON/OFF (Waveforms waveform screen, whe Displays waveforms. The waveform display magnification  Waveform color Interpolation  Variable display magnification  Waveform display cerodisplay position  Vernier  Grid  Logic display width  Waveform inversion  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  "The display format can be selected for each sheet. are displayed in chronological order in the top part of the treas the zooned waveforms are displayed in the bottom part.) over the entire waveform screen. ay position can be defined by specifying a waveform and a zero-level position. Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled) In increments of 1 percent point (available when grid anchoring mode is enabled) Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down. "Not available with 8967, 8970, and 8973  |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  Waveform display  | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveform displadisplay magnification)  Waveform color Interpolation  Variable display  Waveform display  magnification  Waveform display  wagnification  Waveform display  Waveform display  regordisplay position  Vernier  Grid  Logic display width  Waveform inversion  Allows you to adjust grid anchoring mode  | sheets.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Unsettable when envelope is enabled) (Uns teight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  The display format can be selected for each sheet. are displayed in chronological order in the top part of the treas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen. aly position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled)  In increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustable input waveform (Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down. Not available with 8967, 8970, and 8973 the zoom ratio as necessary by pinching in or out.(when et a disabled)          |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  Waveform display  | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveforms from screen waveform display magnification)  Waveform color Interpolation  Variable display magnification  Waveform display waveform display magnification  Waveform display waveform display waveform display position  Vernier  Grid  Logic display width  Waveform inversion  Allows you to adjust grid anchoring mode  Scroll left or right by  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  'The display format can be selected for each sheet. are displayed in chronological order in the top part of the reast he zoomed waveforms are displayed in the bottom part.) over the entire waveform screen. ay position can be defined by specifying a waveform and a zero-level position. Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled. 100 to 1/10x (available when grid anchoring mode is enabled) In increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down.  Not available with 8967, 8970, and 8973 the zoom ratio as necessary by pinching in or out. (when e is disabled) swiping the screen and scroll back while measuring.  |  |  |  |
| Sheet function Zoom display Full screen display Grid anchoring mode Waveform display Enlarge / Reduce Waveform scrolling                          | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveform display display magnification)  Waveform color Interpolation  Variable display magnification  Waveform display magnification  Waveform display magnification  Waveform display position  Vernier  Grid  Logic display width  Waveform inversion  Allows you to adjust grid anchoring mode  Scroll left or right by  Always displays the  The drawing start pc  | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  'The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen. aly position can be defined by specifying a waveform and a zero-level position. Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled) In increments of 1 percent point (Adjustable input waveform (Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down.  Not available with 8967, 8970, and 8973 the zoom ratio as necessary by pinching in or out.(when e is disabled) swiping the screen and scroll back while measuring. latest data by following the measuring process.                       |  |  |  |
| Sheet function  Zoom display  Full screen display  Grid anchoring mode  Waveform display  Enlarge / Reduce  Waveform scrolling  Roll display mode | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveform display display magnification)  Waveform color Interpolation  Variable display wayeform display magnification  Waveform display magnification  Waveform display position  Vernier  Grid  Logic display width  Waveform inversion  Allows you to adjust grid anchoring mode Scroll left or right by Always displays the The drawing start pc "The roll cannot be c"   | sheets.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Uns teight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)  1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  The display format can be selected for each sheet. are displayed in chronological order in the top part of the treas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen.  aly position can be defined by specifying a waveform and a zero-level position.  Fixed colors (32 colors) Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled)  In increments of 1 percent point (available when grid anchoring mode is enabled)  Adjustable input waveform (Adjustable input waveform (Adjustable input waveform (Adjustable with 8967, 8970, and 8973)  the zoom ratio as necessary by pinching in or out.(when e is disabled)  swiping the screen and scroll back while measuring. latest data by following the measuring process. spitch (listplayed when the overlay function is turned on. |  |  |  |
| Sheet function Zoom display Full screen display Grid anchoring mode Waveform display  Enlarge / Reduce Waveform scrolling                         | XY composite waveform display  FFT display  Up to 16 sheets  ON / OFF (Waveforms waveform screen, whe Displays waveform display display magnification)  Waveform color Interpolation  Waveform display magnification  Waveform display waveform display position  Waveform display waveform display position  Vernier  Grid  Logic display width  Waveform inversion  Allows you to adjust grid anchoring mode Scroll left or right by Always displays the The drawing start por The roll cannot be control to the control of the position of the control of the c | sheefs.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Un to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms) 1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)  'The display format can be selected for each sheet. are displayed in chronological order in the top part of the reas the zoomed waveforms are displayed in the bottom part.) over the entire waveform screen. aly position can be defined by specifying a waveform and a zero-level position. Fixed colors (32 colors)  Linear  Always enabled when grid anchoring mode is disabled.  100x to 1/10x (available when grid anchoring mode is enabled) In increments of 1 percent point (Adjustable input waveform (Adjustable input waveform (Adjustment range: 50% to 250% of the input)  OFF / ON  Wide / Standard / Narrow  Displays waveforms upside down.  Not available with 8967, 8970, and 8973 the zoom ratio as necessary by pinching in or out.(when e is disabled) swiping the screen and scroll back while measuring. latest data by following the measuring process.                       |  |  |  |

|   |   | Up to 8 cursors can be displa   |  |  | Saving  |  |  |  |
|---|---|---|--|--|---|--|--|--|
|   | Tracing cursor  | *Displays potential, time from<br>between cursors, and potenti  |  |  |   | SD MEMORY CARD USB MEMORY STICK  | Z4001 (2 GB), Z4003 (8 GB)<br>Z4006 (16 GB)  |  |
| 0   | Horizontal cursor   | Up to 8 cursors can be displayed. *Displays potential and potential difference.   |  |  | SSD   | U8332 SSD UNIT (256 GB)  |  |  |
| Cursor  | Gauge   | Up to 8 gauges can be displa  | _  |  | Save destination  | HDD<br>Sending to FTP  | U8333 HD UNIT (320 GB) PC with a LAN connection  |  |
|   | Specifying segments   | Segment cursor 1 / Segment<br>*Specifies the calculation range, s   |  | and search range.                                |   | Sending e-mails  Network drive   | Send files via e-mail to specified address  LAN-connected drive  |  |
|   | Jump  | Tap the screen to jump to the   | specified                                      | location.  | Dooluum   | If the save destinati  | on is FTP, network drive or email transmission, an alternate   |  |
| Event mark  |   | ng the measuring process (up to<br>or external input terminal for in  |  | arks)  | Backup  | SSD/HDD, SD card   | set for use in the event communications fail. , or USB drive (user-selectable)   |  |
| Setting screen  |   |   |  |  | File format<br>Filename   | FAT, FAT32, NTFS,<br>Alphanumeric and  |  |  |
|   | Normal  | 200 M, 100 M, 50 M, 20 M, 10<br>500 k, 200 k, 100 k, 50 k, 20 l<br>500, 200, 100, 50, 20, 10, 5, 2<br>*The speed for real-time wavefor<br>from 100 MS/s.  | k, 10 k, 5 k,<br>2, 1 [S/s]<br>orm process     | 2 k, 1 k<br>sing can be set                      | Processing identical filenames  | Sequence number file names (user-seil ON / OFF *Automatically save   | es the data obtained for the recording length at the end of a  |  |
|   |   | External sampling: Depending on the input signal of the external sampling terminal Up to 10 MHz   |  |  | Auto saving   | *When using memo   |  |  |
|   | Envelope  | 500 k, 200 k, 100 k, 50 k, 20 l<br>500, 200, 100, 50, 20, 10, 5, 2<br>30, 12, 6, 2, 1 [S/min]<br>*Calculation speed for maxim<br>*Oversampling rate: 100 MS/s   | 10, 5, 2, 1 [S/s] r maximum and minimum values |  | Real-time saving  | ON / OFF "Saves the waveform data (binary) obtained during the measuring process directly to the save destination. "The auto saving function is not available.  File division Files are divided for approx. every 512 MB of data.  |  |  |
|   |   | [Instantaneous waveform]<br>100 M, 50 M, 20 M, 10 M, 5 M<br>500 k, 200 k, 100 k, 50 k, 20 l<br>500, 200, 100, 50, 20, 10, 5, 2  | 1, 2 M, 1 M<br>k, 10 k, 5 k,                   |  | Deleting and saving   | free space left on th  | Divides a file at specified intervals.  the oldest creation dates and saves data when there is no ne specified media at the save destination.  aving and real-time saving.   |  |
|   |   | "Selectable from sampling ratwaveform "When the real-time wavef sampling rate of 50 MS/s or sli   | te 10 times<br>orm calcu                       | lation is used, a                                |   | Settings data  Waveform data   | .SET Binary format (.MEM, .REC, .FLT, .MDF, MF4) Text format (.TXT, .CSV)  |  |
| Sampling rate   | Dual sampling   | [Trend waveform]<br>10 M, 5 M, 2 M, 1 M   |  |  |   | Index  | COMTRADE format (.CFG, .DAT)  Divided saving (.IDX), memory segmentation (.SEQ), dual sampling batch save (.R_M)   |  |
|   |   | 500 k, 200 k, 100 k, 50 k, 20 k<br>500, 200, 100, 50, 20, 10, 5, 2  |  | 2 k, 1 k   | Types of saved data   | Displayed images   | .BMP, .PNG, .JPG   |  |
|   |   | 30, 12, 6, 2, 1 [S/min]  *The sampling rate represents  | a rate at wl                                   | nich maximum and                                 | .,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,   | Numerical calculation results Startup  | S .CSV, .TXT STARTUP.SET   |  |
|   |   | minimum values are calculated.  *The instrument performs oversampling at the sampling rate set for instantaneous waveforms.  Maximum available sampling rate [Save destination: SSD] 20 MS/s (2 channels), 10 MS/s  |  |  |   | CAN frame data Arbitrary waveform data Generation program data   | Binary format (.CLG), text format (.TXT, .CSV) .WFG (when Model U8793 is installed) .FPG (when Model U8793 is installed)   |  |
|   |   | (4 channels), 5 MS/s (8 channels), 500 kS   | nels), 2 MS,                                   | /s (16 channels),                                | Saving channels   |  | .PLS (when Model MR8791 is installed) om all the channels available or from the displayed channels   |  |
|   | For real-time saving  | [Save destination: HDD] 10 M<br>(4 channels), 2 MS/s (8 chan  | S/s (2 chan<br>nels), 1 MS                     | nels), 5 MS/s<br>/s (16 channels),               |   | when saving waveform data (tex   | orm data.  It format) is culled according to the specified culling value   |  |
|   | *The values in ( )  | 500 kS/s (32 channels), 200<br>[Save destination: SD memory   | card, USB i                                    | memory stick,                                    | Culled data saving  | (from 2 to 1000) be<br>Types of saved data   | fore saving.   |  |
|   | indicate<br>the number of   | sending via FTP, Network driv<br>(4 channels), 1 MS/s (8 channels)  | nels), 500 kS                                  | S/s (16 channels),                               | *Real-time saving and   | Binary format  | OFF / Every 16 MB of data / Every 32 MB of data / Every 64 MB of data  |  |
|   | channels used.  | 200 kS/s (32 channels), 100 k *Guaranteed only when the a for the save destination.   |  |  | memory segmentation excluded  | Text format  Numerical calculation results   | OFF / Every 60,000 points of data / Every 1,000,000 points of data<br>S OFF / By the calculation number  |  |
|   |   | *USB memory data guarantee 3.0 connector.   | ed only whe                                    | en using the USB                                 | Specifying files  |  | iles *Enabled when numerical calculation results are saved.<br>ate a new file or add data to an existing file when starting to measure.  |  |
|   | Normal  | [Built-in presets] 20 M (32 channels channels), 200 M (4 channels), 50 [Point]  | 00 M (2 chann                                  | nels), 1 G (1 channel)                           | SAVE button operation   | Instant saving Saving range  | Press the SAVE button to save data to a save destination, under a fillename, and with saving settings that have been pre-set.  Select the full range or a specific segment.  *Enabled only when data is saved with the SAVE key.   |  |
|   | Nomica  | [Arbitrary recording length] 33554400 (32 channels), 67108800 (16 channels), 134217700 (8 channels), 268435400 (4 channels), 536870900 (2 channels), 1073741800 (1 channel) [Point]   |  | Loading data                                     |   |  |  |  |
|   |   | *Setting is possible in units of 100  | points.  |  |   | USB MEMORY STICK   | 2 Z4001 (2 GB), Z4003 (8 GB)<br>C Z4006 (16 GB)  |  |
|   |   | [Built-in presets] 10 M (32 channel<br>(8 channels), 100 M (4 channels)<br>channel) [Point]   | , 200 M (2 ch                                  | nannels), 500 M (1                               | Loading source  | SSD<br>HDD   | U8332 SSD UNIT (256 GB)<br>U8333 HD UNIT (320 GB)  |  |
|   | Envelope  | (16 channels), 67108800 (8 channels), 5368709   |  | 17700 (4 channels),                              |   | Network drive<br>Setting data (.SET)   | LAN-connected drive  |  |
|   | Dual sampling   | "Setting is possible in units of 100 points.  [Instantaneous waveform] Less than half of the maximum recording length provided for the normal method [Trend waveform] 1/2 of maximum recording length listed under "Envelope"                               |  |  | Types of loaded data  | Waveform data: Binary format (MEM, .REC, .MDF, .MF4)<br>Index: Division saving (.IDX), memory division (.SEQ), dual-sampling batch saving (.F<br>Start-up (STARTUP.SET)<br>Arbitrary waveform data (.WFG, .TFG) (when Model U8793 is installed)<br>Generation program data (.FPG) (when Model U8793 is installed)<br>Pulse pattern data (.PLS) (when Model MR8791 is installed)  |  |  |
| Maximum recording<br>length                             |   | or less   |  |  | Automatic loading of divided files.  Divided waveform files (in binary format) can be loaded seamlessly. When a chosen file is adjacent to the end of a waveform saved in the instrument's in |  |  |  |
|   | For real-time saving  | Determined according to the am<br>destination, file system, and num   |  |  | Numerical calculat  |  | t will additionally load files, leaving the waveform in the internal memory.<br>vith envelope setting  |  |
|   | *The numbers in parentheses above show the number of channels to be used.  Definition of the number of channels to be used  1. For modules with two input channels  Consider the use of one input channels  |   |  | be used.   | Maximum number of calculations  Calculation range   | 32 items x Measure   | ement channels   |  |
|   | Consider that use of one input channel occupies one channel. For Model MR980 only, consider that use of one input channel occupies two channels. Por modules with three or four input channels (Models U8975, U8978). Consider that use of either CH1 or CH2 or simultaneous use of CH1 and CH2 occupies one channel. Consider that use of either CH3 or CH4 or simultaneous use of CH3 and CH4 occupies one channel. Using channels under the combined condition of those provided in items -1. and -2. occupies two channels. |   |  | Calculation items                                | Normal  | Peak to peak value, maximum value, minimum value, high-level, low-level, average value, effective (RMS) value, standard deviation, rise time (1), fall time (1), frequency (1), period (1), duty ratio (1), pulse count, area value, X-Y area value, itme difference (1), phase difference (1), time to maximum value, time to minimum value, specified level time, specified time level, pulse width (1), four arithmetic operations, median value, amplitude, integration value, burst width (1), X-Y waveform angle, overshoot, undershoot, +width (1), width, CAN statistics |  |  |
|   | Consider that one exp<br>*When either any one of<br>waveform calculation  | Real-lime waveform calculation     Consider that one expression occupies one channel.     When either any one of Model U8975, U8977, U8978, and MR8990 or the real-time waveform calculation is used, each maximum recording length reduces to half or less |  |  | Numerical judgment  | Targeted waveforms Judgment settings   | *Statistical functions (start, average, maximum, minimum, count) available<br>Analog channels, logic channels, real-time waveform<br>processing channels, waveform processing results<br>ON / OFF  |  |
| Repeated  |   | ecified number of times *Repeate  |  |  |   | Stop conditions  | PASS, FAIL, PASS&FAIL  |  |
| measurements  Waveform monitoring function              |   | of times cannot be specified for r  |  |  | Waveform processing<br>Maximum number of  |  | envelope setting, not available simultaneously with real-time saving   |  |
| Scaling   | Conversion ratio and  | offset / 2-point input / Model / O<br>del to configure the scaling se   |  |  | calculations  Calculation range   | 16 formulas Full range / Specifie  | ed segments  |  |
| _ Jam.ig  | *Automatic detection a  | and automatic scaling are available   | e when a cu                                    | urrent unit is used.                             | Standard operator   | +, -, ×, ÷   | nent, common logarithm, moving average, derivative, second   |  |
| Comments  | Title comments, channel comments Channel numbers and channel comments are added on the setting screen and waveform screen.  Calculation formulas 32 formulas  Measurement channels in 8966, 8967, 8968, U8969, 8970,  |   |  |  | Calculation items   | derivative, integral, se<br>PLC shift, sine, cosine<br>FIR (LPF, HPF, BPF, B<br>half-wave frequency, I   | cond integral, square root, cubic root, parallel move (translation),<br>t, tangent, arc sine, arc cosine, arc tangent, 2-argument arc tangent,<br>SP, IIR (LPF, HPF, BPF, BSF), half-wave average, half-wave period,<br>half-wave RMS value, full-wave average, fullwave period, full-wave |  |
| Digital filter  | Calculation targets   | 8971, 8972, U8974, U8975, U8<br>*The 8973 and MR8990 measurem<br>10 M / 1 M / 100 k / 10 k / 1 k  | 976, U8977<br>ent channels                     | , U8978, U8979<br>are not applicable.            |   | value (*), minimum val   | IMS value, polarity, binarization, CAN/LIN average (*), maximum lue (*), level at specified time (*), Resolver, ABZ encoder an be specified as constants in expressions.  analyzed circuits: 4   |  |
| Digital filter  *MR6000-01 only (Option to be specified | Calculation update rate   | *Up to 8 calculations can be  *Up to 16 calculations can be   | set for 10 N<br>set for 1 N                    | NS/s.<br>NS/s.                                   |   | Supported wiring methods   | 1-phase/2-wire (1P2W), 1-phase/3-wire (1P3W), 3-phase/3-wire (3P3W), 3-phase/3-wire (3-voltage/3-current method) (3V3A), 3-phase/4-wire (3P4W)   |  |
| upon order)   | Calculation delay   | update rate 10 M3/S 1 M3/S  | 100 kS/s                                       |  | Power calculations  | Measurement method   | Zero-cross synchronization method  |  |
|   | Filter types  | Calculation 6.2 or 6.3 us 5 us  FIR (LPF / HPF / BPF / BSF), I  |  | Calculation update rate period  PF / BPF / BSF), |   | Calculation items  | Voltage RMS value, voltage average value, voltage simple mean<br>value, current RMS value, current average value, current simple<br>mean value, active power value, apparent power value, reactive   |  |
|   | Filter types  | moving average, delay device  | e  |  |   |  | power value, power factor, power phase angle, efficiency, loss   |  |

| Averaging function   | Simple average, ex<br>specified from 2 to<br>*Roll display not available   | 10,000)<br>able when the averag  | ging func   | tion is to  | urned on.  |  |
|--|--|--|---|---|--|--|
| Bool time wayeforn   | *One simple averaging equation uses three calculation spots. (The two calculations spots directly following the calculation number for simple averaging will be unavailable.)  m processing 'Option to be specified upon order (Order code: MH6000-01)   |  |   |   |  |  |
| Maximum number of calculations   | 16 formulas  |  |   |   |  |  |
| Calculation targets  | Measurement channels in 8966, 8967, 8968, U8969, 8970, 8971, 8972, 8973, U8974, MR8990 (*), U8975, U8976, U8977, U8978, U8979, U |  |   |   |  |  |
| Calculation update rate  | cannot be set with o   | s can be set for 10<br>certain calculation   | MS/s. *<br>update r   | rates.  | types of calculations  |  |
| Calculation delay  | Calculation update rate  Calculation delay  Add the delay times selected for calculation  Calculation update rate  Added calculation delay   | 6.2 or 6.3 us 5 isted below when recon. 10 MS/s 1 M  | us 2<br>eal-time v  | 0 kS/s<br>20 us<br>wavefor<br>0 kS/s<br>0 us  | 10 kS/s or less  Calculation update rate period m processing channels are 10 kS/s or less  Calculation update rate period  |  |
| Calculation type   | Addition, subtraction, m equations, monomials, p   | ultiplication, division, fo  | our arithm  | etic oper   | rations with coefficients, quarti-<br>erentiation, integrals, integration  |  |
| FFT calculation *Nd  | FIR (LPF / HPF / BPF / B<br>ot available with envel  |  |   | _   | average, delay device<br>cously with real-time saving  |  |
| Maximum number of calculations   | 8  |  |   |   |  |  |
| Frequency range<br>Number of sampling points                             | 500 mHz to 100 MH<br>1 k, 2 k, 5 k, 10 k, 2  |  | J.5), ext   | ernai s   | ampling  |  |
| Frequency resolution   | 1/500, 1/1000, 1/25<br>AAF (8968, U8979),  |  |   |   |  |  |
| Anti-aliasing filter   | waveform processir   | ng LPF filter (FIR, II   | R) _  |   |  |  |
| Calculation targets  | Analog waveform, war<br>Newly loaded   | veform processing re<br>Data newly meas  |   |   | vaveform processing results<br>ing START key   |  |
| Analyzed data  | Memory   | Data measured r  | nost rec  | ently o   | r data loaded from media   |  |
| FFT analysis modes   |  | nsfer function, cohe   | erence fu   | inction,  | 2CH phase spectrum   |  |
| Vindows  | Rectangular, Hanning   | , Hamming, Blackm  |   |   | larris, Flat-top, Exponential  |  |
| Display scale<br>Peak value display                                      | Linear scale, log sc<br>OFF, local maxima,   |  |   |   |  |  |
| Averaging function   | Simple averaging, e  |  | ing, pea  | k hold  | (arbitrary setting from  |  |
| Calculation execution button   | 2 to 10,000 times)<br>Execution button dis   | splayed in screen  |   |   |  |  |
| Memory division  | 1024 blooks  |  |   |   |  |  |
| Max. divisions<br>Block search   | 1024 blocks<br>Search from the dat   |  |   | nemor   | y block.   |  |
| Reference block  | Superimposes wave  | eforms of a specific   | block.  |   | in be compared with  |  |
| latch save   | previously measure   | d waveform data th   | nat is loa  | aded in   | the reference block.   |  |
| laveform search  | Saves entire range   | or uata III ali Diocks   | ıası Me   | asure)  |  |  |
|  |  | Level, window-in   |   |   | e when a logic channel is  |  |
|  | Trigger  | selected as the ta   | argeted   | chann   |  |  |
|  | Peak   | Maximum value, n   | ninimum   | value,  | local maxima, local minima   |  |
| earch method   | Histogram, standard deviation  "Select whether to compare each value to the reference waveform or to the directly preceding waveform.  "Disabled with envelope setting  Event mark, cursor, time (absolute time, relative time, or time  |  |   |   |  |  |
|  | Jump   | specified by the n   | umber o   | f points  | ), trigger point, search mark  |  |
| Search range   | Full range<br>Specifying   |  | range s   |   | d for segment 1 or the on  |  |
| Number of searches   | segments Specifiable (Up to 1  | specified for seg<br>000 data points)  | ment 2.   |   |  |  |
| arget channels   | Built-in unit, real-tim  | e waveform proces  |   |   |  |  |
| Search position  |  |  |   |   | t at, search positions.  |  |
| Continuous search  |  | d number, the way  |   |   | owing the last search  |  |
| Display method   | Specify a search loo   |  | e data.   |   |  |  |
|  |  |  |   |   |  |  |
| CAN measurement  | Compliant standards  | CANED CAN / III  | ah Saar   | ıd)   |  |  |
| CAN measurement  | Compliant standards Supported  | Vector Informatik \  | VN1610,   | , VN16  |  |  |
| CAN measurement  | -  | Vector Informatik \  | VN1610,   | , VN16  | 30A, VN1640<br>ggy 1051cap/1057Gcap  |  |
| CAN measurement  | Supported products Connector Number of   | Vector Informatik \ Compatible transc USB 1 (If multiple device  | VN1610,<br>ceivers:   | , VN163<br>CANpig<br>connec   | ggy 1051cap/1057Gcap<br>sted, only the first detecte   |  |
| CAN measurement  | Supported products Connector Number of connectable devices   | Vector Informatik \ Compatible transc<br>USB<br>1 (If multiple devicinterface will be av<br>Up to 4 (C1 to C4)   | VN1610,<br>ceivers:<br>ces are d<br>vailable  | , VN16:<br>CANpig<br>connect<br>for use   | ggy 1051cap/1057Gcap<br>ted, only the first detecte  |  |
| CAN measurement  | Supported products Connector Number of   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple devicinterface will be av<br>Up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim   | vN1610,<br>ceivers:<br>ces are c<br>vailable<br>)<br>ers are a<br>ultaneou  | , VN163<br>CANpig<br>connect<br>for use<br>affixed to<br>usly wit   | ggy 1051cap/1057Gcap<br>eted, only the first detecte<br>e.)<br>to VN1630A or VN1640<br>th LIN measurement)   |  |
|  | Supported products Connector Number of connectable devices Number of input   | Vector Informatik \ Compatible transc USB    1 (If multiple device interface will be a \ Up to 4 (C1 to C4) When 4 transceives   | vN1610,<br>ceivers:<br>ces are c<br>vailable<br>)<br>ers are a<br>ultaneou  | , VN163<br>CANpig<br>connect<br>for use<br>affixed to<br>usly wit   | ggy 1051cap/1057Gcap<br>eted, only the first detecte<br>e.)<br>to VN1630A or VN1640<br>th LIN measurement)   |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple device<br>interface will be available sim<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M [baud]<br>33.3 k, 50 k, 83.3 l   | VN1610,<br>ceivers: ces are c<br>vailable<br>)<br>ers are a<br>ultaneou<br>k, 100 k   | CANDIO<br>CONDECTOR OF THE CONTROL OF T   | ggy 1051cap/1057Gcap ted, only the first detecte t.) to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k,   |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple devicinterface will be a<br>Up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3<br>1 M [baud]<br>33.3 k, 50 k, 83.3<br>1 M, 2 M, 4 M [b<br>"Setting available  | vN1610,<br>ceivers: ces are c<br>vailable<br>)<br>ers are a<br>ultaneou<br>k, 100 k<br>baud]<br>only who  | CANDIQ<br>CONNECTOR OF THE CONNECTOR OF THE   | ggy 1051cap/1057Gcap<br>ted, only the first detecte<br>.)<br>to VN1630A or VN1640<br>h LIN measurement)<br>, 250 k, 500 k,<br>, 250 k, 500 k,  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple devicinterface will be av<br>Up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M [baud]<br>33.3 k, 50 k, 83.3 l<br>1 M, 2 M, 4 M [b   | vN1610,<br>beivers: value of the control of the contro | CANDIQ<br>CONNECTOR OF<br>CONNECTOR O   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate   | Vector Informatik \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \  | VN1610, ceivers: ces are covailable )  pers are a cultaneou k, 100 k k, 100 k k, aud] only who 29-bit (crailable fersillable f    | CANDIG<br>CANDIG<br>CONNECTOR OF<br>CONNECTOR OF<br>CONNECTOR OF<br>CANDIGOR OF<br>C | ggy 1051cap/1057Gcap ted, only the first detecte .) to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) ames.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter   | Vector Informatik Compatible transc<br>USB<br>1 (If multiple devicinterface will be a<br>up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sin<br>3.3 k, 50 k, 83.3<br>1 M (Baud)<br>3.3 3, 50 k, 83.3<br>1 1 M, 2 M, 4 M [b<br>"Setting available<br>11-bit (standard),<br>Block setting is av<br>Normal / ACK OFF<br>CAN frame data rmeasurement can   | vN1610, beivers: constant of the constant of t    | CANDIGORANDIST CONTROL OF CONTROL  | ggy 1051cap/1057Gcap ted, only the first detecte .) to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. edd) arames. thronism with the start of the build-in memory (up to   |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK   | Vector Informatik Compatible transc<br>USB<br>1 (If multiple devicinterface will be a<br>up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sin<br>3.3 k, 50 k, 83.3<br>1 M (Baud)<br>3.3 3, 50 k, 83.3<br>1 1 M, 2 M, 4 M [b<br>"Setting available<br>11-bit (standard),<br>Block setting is av<br>Normal / ACK OFF<br>CAN frame data rmeasurement can   | vN1610, beivers: constant of the constant of t    | CANDIGORANDIST CONTROL OF CONTROL  | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) ames.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory  | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple devicinterface will be a<br>up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M [baud]<br>33.3 k, 50 k, 83.3 l<br>1 M, 2 M, 4 M [b<br>"Setting available"<br>11-bit (standard),<br>Block setting is av<br>Normal / ACK OFF<br>CAN frame data ir<br>measurement can<br>10 MB). Data is cli<br>Yes<br>Signal number: Fre  | vN1610, beivers: ces are covailable valuation only who should be some are desired on 1  | CANDIQ<br>CONNECTOR OF THE CONNECTOR OF THE   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) armes.  thronism with the start of the build-in memory (up to the measurement starts.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory  | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple device<br>interface will be a<br>Up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M [baud]<br>33.3 k, 50 k, 83.3 l<br>1 M, 2 M, 4 M [b<br>'Setting available<br>11-bit (standard),<br>Block setting is av<br>Normal / ACK OFF<br>CAN frame data ir<br>measurement can<br>10 MB). Data is cle<br>Yes  | VN1610, beivers: (ces are devailable ) ers are aultaneou k, 100 k k, 100 k k, 100 k k, 100 k baud] only who callable ferallable ferallable ferallable ferallable for the care devaluation of the care     | CANDIQ<br>CONNECTOR OF THE CONNECTOR OF THE   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) armes.  thronism with the start of the build-in memory (up to the measurement starts.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple device<br>interface will be a<br>Up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M [baud]<br>33.3 k, 50 k, 83.3 l<br>1 M, 2 M, 4 M [b<br>"Setting available<br>"Setting available<br>"Setting available<br>of the companie of the companie of the<br>Setting available of the companie of the companie of the<br>Normal / ACK OFF<br>CAN frame data ir measurement can<br>10 MB). Data is cle<br>Yes<br>Signal name: upt to<br>Signal name: upt to<br>Lip: 0 to 1FFFFFFF<br>Start bit: 0 to 511   | VN1610, beivers: (ces are devailable ) ers are aultaneou k, 100 k k, 100 k k, 100 k k, 100 k baud] only who callable ferallable ferallable ferallable ferallable for the care devaluation of the care     | CANDIQ<br>CONNECTOR OF THE CONNECTOR OF THE   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) armes.  thronism with the start of the build-in memory (up to the measurement starts.  |  |
|  | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory  | Vector Informatik \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \  | vN1610, belivers: it can be safe to the sa    | CANDIQ<br>CONNECTOR OF THE CONNECTOR OF THE   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) armes.  thronism with the start of the build-in memory (up to the measurement starts.  |  |
| nterface   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function   | Vector Informatik Compatible transc USB  1 (If multiple device interface will be as Up to 4 (C1 to C4) When 4 transceive (Not awailable sim 33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M, 2 M, 4 M [b Setting available transceive (Not awailable transceive (Not  | vN1610, belivers: it can be said to the said the said to the said the    | VN16:CANpig Connector use Conn  | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, N FD is selected. ad) rames.  chronism with the start of ne build-in memory (up to ne measurement starts.  |  |
| nterface   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function  Definition settings  | Vector Informatik Compatible transc USB  1 (If multiple device interface will be as Up to 4 (C1 to C4) When 4 transceive (Not awailable sim 33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M, 2 M, 4 M [b Setting available transceive (Not awailable transceive (Not  | vN1610, besidens: in the control of     | VN16:CANpig<br>connecconnector use<br>for use<br>tiffixed I usly wit<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k   | ggy 1051cap/1057Gcap ted, only the first detecte .) to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, , 250 k, 500 k, N FD is selected. ed) arames. thronism with the start of the build-in memory (up to the measurement starts.  |  |
| nterface   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function   | Vector Informatik N<br>Compatible transc<br>USB<br>1 (If multiple devicinterface will be a<br>up to 4 (C1 to C4)<br>When 4 transceive<br>(Not available sim<br>33.3 k, 50 k, 83.3 l<br>1 M, 2 M, 4 M [b<br>*Setting available<br>11-bit (standard),<br>Block setting is av<br>Normal / ACK OFF<br>CAN frame data ir<br>measurement can<br>10 MB). Data is cl<br>Yes<br>Signal name: up to<br>10:0 to 1FFFFFF<br>Start bit: 0 to 511<br>Bit length: 1 to 64<br>Byte order: Big / L<br>Data type: Signed   | vN1610, besidens: in the control of     | VN16:CANpig<br>connecconnector use<br>for use<br>tiffixed I usly wit<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k<br>, 125 k   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k, N FD is selected. ad) rames.  chronism with the start of ne build-in memory (up to ne measurement starts.  |  |
| nterface   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function  Definition settings  Number of signals that can be registered  | Vector Informatik Compatible transcuSB  1 (If multiple devicinterface will be a word to the following the followin | vN1610, between: increase are cavailable between are a validable between a validable betwe    | VN16: CANpig connect for use affixed t usely with 125 k 125 k 125 k 126 c 127 c 128   | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k,  N FD is selected. ed) names.  thronism with the start of the build-in memory (up to the measurement starts.   |  |
| nterface   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function  Definition settings Number of signals that can be registered Input method  | Vector Informatik Compatible transcuSB  1 (If multiple devicinterface will be a word to the following the followin | vN1610, between: increase are cavailable between are a validable between a validable betwe    | VN16: CANpig connect for use affixed t usely with 125 k 125 k 125 k 126 c 127 c 128   | ggy 1051cap/1057Gcap ted, only the first detecte to VN1630A or VN1640 h LIN measurement) to VS 650 k, to 500 k, to 5 |  |
| ignal settings   | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function  Definition settings Number of signals that can be registered Input method Number of displayed waveforms  | Vector Informatik N Compatible transc USB  1 (If multiple devicinterface will be a Up to 4 (C1 to C4) When 4 transceive (Not available sim 33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M [baud]  33.3 k, 50 k, 83.3 l 1 M [baud]  Normal A CA CH CAN (A C C C C C C C C C C C C C C C C C C  | WN1610. Leivers: ices are c validable ces are c validable per services are considerable per putted of the services are conside    | , WN16: CANpin C  | ggy 1051cap/1057Gcap  tled, only the first detecte  to VN1630A or VN1640  h LIN measurement)  to So k, 500 k,  So b, 500 k,  FD is selected.  ad)  rames.  thronism with the start of the build-in memory (up to the measurement starts.   |  |
| can measurement  Interface  Signal settings  Real-time waveform  display | Supported products Connector Number of connectable devices Number of input CAN ports Baud rate Data rate Acceptance filter ACK Storage memory Monitor function  Definition settings Number of signals that can be registered Input method  Number of displayed   | Vector Informatik Normatik Normatik Normatik Propagatible transcrusses 1 (If multiple devicinterface will be a word to the Normatik Normat | vN1610. Delevers: icoses are ce variable ble consistence are consistence are consistence are ce variable ble consistence are consistence are consistence are ce variable ble consistence are c    | , VN16: CANpig Connector uses the connector uses th  | ggy 1051cap/1057Gcap  ted, only the first detecte .)  to VN1630A or VN1640 h LIN measurement) , 250 k, 500 k,  N FD is selected. ed) names.  thronism with the start of the build-in memory (up to the measurement starts.   |  |

|  | Timing<br>Transmit ID  | Key S1, Key S2, Start, Trigger, Reply, Pass, Fail, Error  0 to 1FFFFFFF  |
|--|--|--|
|  | Transmit port  | C1 to C4, ALL  |
|  | Types  | Standard CAN, extended CAN, standard CAN FD, extended CAN FD, standard CAN remote, extended CAN remote   |
| Transmit function  | DLC  | 0 to 15 (0 to 8 / 12 / 16 / 20 / 24 / 32 / 48 / 64 bytes)  |
|  | Delay<br>Periodic transmit   | 0 to 10000 ms  Repeated transmission (select key S1, key S2, or start)   |
|  | Interval   | Transmit interval can be set for regular transmission: 1 to 10000 ms   |
| I IN manaurament   | Response ID  | 0 to 1FFFFFFF (if timing is set to response)   |
| LIN measurement  | Conforming standard  | LIN  |
|  | Supported products   | VN1611, VN1630A (Vector Informatik)<br>Installable transceiver: LINpiggy 7269mag   |
|  | Connector  | USB  |
|  | Number of connectible  | One (If more than one interface is connected, only the one   |
|  | interfaces   | detected first can be used.)   |
| Interface  | Number of input<br>LIN ports   | Up to four (C1 to C4) When four transceivers are connected to VN1630A (Not available simultaneously with CAN / CAN FD  |
|  |  | measurement)   |
|  | Baud rate<br>LIN protocol  | 2400, 9600, 14400, 19200 (bps)<br>1.3 / 2.0 / 2.1 / 2.2  |
|  |  | LIN packet data inputted in sync with the start of   |
|  | Storage memory   | measurement can be stored in the built-in memory (up to 10 MB). Data will be cleared every time measurement starts   |
|  | Monitor function   | Yes<br>Signal number: From 1   |
|  |  | Signal number: From 1<br>Signal name: Up to 32 characters  |
|  |  | ID: 0 to 63<br>Start bit: 0 to 63  |
|  | Definition configuration   | Bit length: 1 to 64<br>Byte order: Big, Little   |
| Signal configuration   |  | Data type: Signed, Unsigned, Float, Double<br>Checksum: Classic, Enhanced  |
|  |  | Conversion into physical quantity: Conversion using conversion ratio and offset  |
|  | Number of definitions that can be registered   | Up to 300  |
|  | Input method   | Direct entry using the instrument's display Loading of an LDF file   |
| Real-time waveform display   | Number of displayed<br>waveforms   | Up to 64   |
| αισριαγ  | How to configure   | Select the arithmetic expression CAN/LIN in the waveform   |
| Calculation waveform display   | Number of displayed  | calculation setting and specify signals using signal numbers   |
|  | waveforms  | Up to 16   |
| Waveform generati<br>*Details of the hardware  |  | n MR8790, MR8791 and U8793 units.  |
| Waveform generation mode   | By the respective g  | eneration units of MR8790, MR8791 and U8793  |
|  | Signal generation  | On (generation), off (halt)  |
|  |  |  |
| Waveform generation  | Synchronized   | Synchronization of all channels with one another: Outputs generated signals via all channels in sync with one another.   |
|  | Synchronized control   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with   |
| Waveform generation control  |  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  |
|  | WAVEFORM GENERATOR<br>UNIT MR8790  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with   |
|  | CONTROL  WAVEFORM GENERATOR  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern   |
| control  | CONTROL  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary  |
| control  | CONTROL  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform  |
| Waveform types  Supported waveforms for  | CONTROL  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not supp   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported)  |
| Waveform types  Supported waveforms for output (U8793 only)  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not saved v  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic  |
| Waveform types  Supported waveforms for output (U8793 only)  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not supp Waveforms saved w Waveforms general   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker   |
| Waveform types  Supported waveforms for output (U8793 only)  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms aved u Waveforms general  "When the Available previous!"   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model S78000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.   |
| Waveform types  Supported waveforms for output (U8793 only)  Other   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not sup Waveforms aved v Waveforms general  "When th Available "The HDE that orde!   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform  ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  JSSD, SD memory card, and USB memory are searched, in , for the save location.  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup   | Control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms aved u Waveforms general  "When th Available previous! The HDC that orde!  y In the hor  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform  ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  JSSD, SD memory card, and USB memory are searched, in  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms neasur waveforms saved v Waveforms saved v Waveforms speneral  "When th Available "The HDI that orde! X In the hor display p y In the ver  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, rectangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform  ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  JSSD, SD memory card, and USB memory are searched, in r, for the save location.  izontal direction, the sampling rate, compression rate, or solition can be changed and the cursor can be moved.  tical direction, the measurement range, compression rate,  |
| Waveform types  Supported waveforms for output (U8793 only)  Other   | Control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms aswed v Waveforms general  "When the Available previous! "The HDIC that order  X In the hor display p Y In the ver or display  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in , for the save location. izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  | Control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR733  Waveforms measur waveforms not supp Waveforms not supp Waveforms saved v Waveforms general  "When the Available The HDE that order that order X lin the hor or display p In the ver or display S1, S2 A function Available (The optic   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform  ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model SF8000 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  NSSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It can be changed and the cursor can be moved. In can be allocated.  mal sampling rate and measurement range for the input   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  | waveform generator unit marso PULSE GENERATOR UNIT MRS790 PULSE GENERATOR UNIT MRS791 ARBITRARY WAVEFORM GENERATOR UNIT UR3793 Waveforms not supply waveforms saved vaveforms saved vaveforms general  "When the previous" X In the hor display p Y In the ver or display S1, S2 A function Available (The optic waveform are autor "Not available for e   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  DC, sine wave, rectangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  De power is turned on, the unit loads the settings data y saved (STARTUP-SET) to start up.  JSSD, SD memory card, and USB memory are searched, in for the save location. It is sampling rate, compression rate, or osition can be changed and the cursor can be moved. It can be allocated.  The sampling rate and measurement range, compression rate, or can be allocated.  The sampling rate and measurement range for the input matically set.)  The save placetime saving, or external sampling.   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  | waveform generator unit marso PULSE GENERATOR UNIT MRS790 PULSE GENERATOR UNIT MRS791 ARBITRARY WAVEFORM GENERATOR UNIT UR3793 Waveforms not supply waveforms saved vaveforms saved vaveforms general  "When the previous" X In the hor display p Y In the ver or display S1, S2 A function Available (The optic waveform are autor "Not available for e   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model S750 Waveform Generator ted with Model S750 Waveform Maker  be power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up.  JISSD, SD memory card, and USB memory are searched, in y, for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. Itical direction, the measurement range, compression rate, position can be changed and the cursor can be moved.  In can be allocated.  The start of the input material waveful or the input matically set.)   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR793  Waveforms measur waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  Available  The HDI that ordel  X In the hor display p y In the very or display S1, S2 A function Available (The optimate of the previous) S1, S2 A function Three levels of settim and hard buttons.  OFF, alarm only, ali   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  D/SSD, SD memory card, and USB memory are searched, in , for the save location.  Izonald direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. Itical direction, the measurement range, compression rate, or can be allocated.  mal sampling rate and measurement range for the input matically set.)  notes the save of the save of the save of the providence of the save location.  The save of the  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms not supp Waveforms not supp Waveforms not supp Waveforms saved v Waveforms general  "When the Available "The HDI that order  X In the hor display p Y In the ver or display S1, S2 A function  Available (The optir waveform are autor Not available for e Three levels of setti and hard buttons.  OFF, alarm only, ali Sending e-mails via  Sending e-mails via   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model SF8000 Waveform Maker  be power is turned on, the unit loads the settings data yeaved (STARTUP-SET) to start up.  SSD, SD memory card, and USB memory are searched, in for the save location. It is a sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or can be allocated.  The sampling rate and measurement range for the input natically set.)  The sampling rate and measurement range for the input natically set.)  The sampling rate and measurement sampling.  The sampling rate and measurement sampling.  The sampling are available: OFF, touch screen only, or touch screen arm and operation is SMTP   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR793  Waveforms measur waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  Available  The HDI that ordel  X In the hor display p y In the very or display S1, S2 A function Available (The optimate of the previous) S1, S2 A function Three levels of settim and hard buttons.  OFF, alarm only, ali   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model ST8000 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up.  D(SSD, SD memory card, and USB memory are searched, in y, for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  not set the save location.  It is a save a savilable: OFF, touch screen only, or touch screen arm and operation  It is MTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR393  Waveforms not supp Waveforms not supp Waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  "When the previous" The HDI that ordel that ordel waveforms are under the previous of the previ | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model S75 Waveform Generator with Model S750 Waveform Maker  et power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, rosition can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input matically set.)  In a sampling rate and measurement range for the input matically set.)  In a sampling rate and measurement plant in the input matically set.)  In a sampling rate and measurement plant in the input matically set.)  In a sampling rate and measurement plant in the input matically set.)  In a sampling rate and measurement plant in the input matically set.)  In a sampling rate and measurement mand operation is MTP  Automatic saving, saving with the SAVE button  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR733  Waveforms measur waveforms not supy Waveforms not supy Waveforms saved v Waveforms saved v Waveforms Seneral  "When the Available The Popticus of the Variable The Hold That order X In the hor or display p Y In the ver or display Seneral Available (The optic waveform are autor Three levels of setti and hard buttons.  OFF, alarm only, als Sending e-mails via Sending timing  Sent data  Waveform data initi Memory, LCD, butt   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model S78000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input matically set.)  In some available: OFF, touch screen only, or touch screen arm and operation and operation and operation and the cursor can be compression are arm and operation and the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not sup Waveforms saved v Waveforms general  The HDI that ordei  X In the hor display p Y In the ver of display S1, S2 A function Available (The opti waveform are autor "Not available for e Three levels of setti and hard buttons.  OFF, alarm only, ali Sending e-mails vie Sending timing Sent data  Waveform data initi Memory, LCD, buttle English, Japanese,   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model S78000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input matically set.)  In some available: OFF, touch screen only, or touch screen arm and operation and operation and operation and the cursor can be compression are arm and operation and the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check Language  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR373  Waveforms not supply Waveforms not supply Waveforms not supply Waveforms saved waveforms saved waveforms saved waveforms general  "When the previous" The HDI that order waveforms and waveform are autor of sipplay by In the very or display S1, S2 A function Available (The optima waveform are autor Not available for e Three levels of setting and hard buttons. OFF, alarm only, all Sending e-mails via Sending timing  Sent data  Waveform data inititi Memory, LCD, butth English, Japanese, Displays the oetsalie.  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model T075 Waveform Generator ted with Model SF8000 Waveform Maker  be power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  JISSD, SD memory card, and USB memory are searched, in for the save location.  Izontal direction, the sampling rate, compression rate, or costicular direction, the measurement range, compression rate, rposition can be changed and the cursor can be moved. In can be allocated.  The allocated.  The allocated.  The allocated in all sampling rate and measurement range for the input matically set.)  The position can be changed and the cursor can be moved.  The can be allocated.  The allocated in the measurement range for the input matically set.)  The position can be changed and the cursor can be moved.  The can be allocated.  The allocated in the measurement range for the input matically set.)  The position can be changed and the cursor can be moved.  The can be allocated.  The allocated in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not sup Waveforms general  "When th previous" "The HDC that order  X In the hor display p Y In the ver display p Y In the ver Three levels of setti and hard buttons.  OFF, alarm only, ali Sending e-mails vie Sending timing  Sent data  Waveform data initi Memory, LCCD, buttle English, Japanese, Displays the detailia Displays the clearing Settings for decima   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  D/SSD, SD memory card, and USB memory are searched, in for the save location.  It can be changed and the cursor can be moved. It can be changed and the cursor can be moved. It can be allocated.  mal sampling rate and measurement range, compression rate, or can be allocated.  mal sampling rate and measurement range for the input matically set.)  notes are available: OFF, touch screen only, or touch screen arm and operation  arm and operation  ISMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  alization, setting initialization, complete initialization ones, LAN, media, touch screen  Chinese  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR393  Waveforms not supp Waveforms not supp Waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  "When the Available "The HDI that order  X In the hor display p Y In the ver or display S1, S2 A function  Available (The optir waveform are autor Not available for e Three levels of setti and hard buttons.  OFF, alarm only, ali Sending e-mails via Sending timing  Sent data  Waveform data intit Memory, LCD, butt English, Japanese, Displays the details  Displays the details  Displays the on-scr  Settings for decima  Cettings for decima  Decimal point   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  2/SSD, SD memory card, and USB memory are searched, in for the save location. It is sampling rate, compression rate, or osition can be changed and the cursor can be moved. It can be changed and the cursor can be moved. The ampling rate and measurement range, compression rate, or can be allocated.  The ampling rate and measurement range for the input matically set.)  The save location is sampling or external sampling.  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR733  Waveforms measur waveforms not sup) Waveforms saved v Waveforms are autor that order  X In the hor display p Y In the ver or display S1, S2 A function Available (The optir waveform are autor Not available for e Three levels of setti and hard buttons. OFF, alarm only, ali Sending e-mails via Sending e-mails via Sending e-mails via Sending timing Sent data  Waveform data initit Memory, LCD, buttle English, Japanese, Displays the on-sor Settings for decima (text) files and num Decimal point Break  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, traingular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model S78000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in, for the save location.  Izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  The allocated direction in the measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Touch keyboard  Region specifications  Time value display   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR733  Waveforms measur waveforms not sup Waveforms saved v Waveforms and v Waveforms saved v Waveforms and v Waveforms are votated by The HDI that order v In the hor display p In the ver or display S1, S2 A function Available (The optimaveform are autor Not available for e Three levels of setting and hard buttons.  OFF, alarm only, ali Sending e-mails via Sending e-mails via Sending e-mails via Sending timing  Sent data  Waveform data initit Memory, LCD, butth English, Japanese, Displays the on-sor Settings for decima (text) files and num Decimal point Break  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, triangular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  2/SSD, SD memory card, and USB memory are searched, in for the save location. It is sampling rate, compression rate, or osition can be changed and the cursor can be moved. It can be changed and the cursor can be moved. The ampling rate and measurement range, compression rate, or can be allocated.  The ampling rate and measurement range for the input matically set.)  The save location is sampling or external sampling.  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)  The ampling rate and measurement range for the input matically set.)   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms measur waveforms not sup Waveforms general  "When th previous" "The HDC that order  X In the hor display p Y In the ver display p Y In the ver Three levels of setti and hard buttons.  OFF, alarm only, ali Sending e-mails via Sending timing  Sent data  Waveform data initi Memory, LCD, buttle English, Japanese, Displays the on-scr Settings for decima (text) files and num Decimal point Break Hours, sexagesima   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, traingular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model S78000 Waveform Maker  Be power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in, for the save location.  Izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  The allocated direction in the measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)  The saving rate and measurement range for the input matically set.)   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR793  Waveforms not supply Waveforms not supply Waveforms not supply Waveforms saved vaveforms saved vaveforms saved vaveforms general  "When the previous" The HDI that order or display part of the previous of the | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  D/SSD, SD memory card, and USB memory are searched, in , for the save location.  Izonald direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. Itical direction, the measurement range, compression rate, or osition can be changed and the cursor can be moved. In can be allocated.  mal sampling rate and measurement range for the input matically set.)  nvelope, real-time saving, or external sampling.  ngs are available: OFF, touch screen only, or touch screen arm and operation  ISMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  alization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese  of errors and warnings when they occur.  een keyboard. I point and break characters in data saved to waveform erical calculation result files  Period, comma  Comma, space, tab, semicolon  I time, date, data values   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR393  Waveforms not supply Waveforms not supply Waveforms not supply Waveforms saved waveforms saved waveforms saved waveforms general  "When the previous" The HDE that ordel  X In the hor display p  Y In the ver or display p  Y In the ver or display p  S1, S2 A function  Available (The opting waveform are autor waveform data initit and hard buttons. OFF, alarm only, alt Sending e-mails via Sending timing  Sent data  Waveform data initit Memory, LCD, butth English, Japanese, Displays the details Displays the on-scr Settings for decimal cutyl files and num Decimal point Break  Hours, Sexagesima ON / OFF  Black or white  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, tramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  JOSSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. Itical direction, the measurement range, compression rate, position can be changed and the cursor can be moved. In can be allocated.  In all sampling rate and measurement range for the input matically set.)  Invelope, real-time saving, or external sampling.  Ings are available: OFF, touch screen only, or touch screen arm and operation as MSTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  allization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese  of errors and warnings when they occur.  een keyboard.  I point and break characters in data saved to waveform erical calculation result files  Period, comma  Comma, space, tab, semicolon  I time, date, data values   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display Touch keyboard  Region specifications  Time value display  Zero position display Waveform screen background color  Restart permission  Display settings                                    | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR793  Waveforms not sup Waveforms not sup Waveforms saved v Waveforms general  "When th previous!  X In the hor display p Y In the ver or display S1, S2 A function Available (The opti waveform are autor "Not available for e Three levels of setti and hard buttons.  OFF, alarm only, ale Sending e-mails vie Sending timing Sent data  Waveform data initi Memory, LCD, buttle English, Japanese, Displays the details Displays the details Displays the details Displays the details Displays the displays Break Hours, sexagesima ON / OFF  Black or white Permitted / Not permitte unit is restarted. "Not permitte Adjust brightness of Set the date and tir   | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  JISSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, reposition can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input natically set.)  In some available: OFF, touch screen only, or touch screen arm and operation are available: OFF, touch screen only, or touch screen arm and operation at the sampling and provided data.  BisMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  alization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese  of errors and warnings when they occur.  een keyboard.  I point and break characters in data saved to waveform erical calculation result files  Period, comma  Comma, space, tab, semicolon  I time, date, data values  |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen  background color  Restart permission   | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR393  Waveforms not supp Waveforms not supp Waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  "When the previous" The HDI that order waveforms and the previous of the previo | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  JISSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input natically set.)  In some available: OFF, touch screen only, or touch screen arm and operation are available: OFF, touch screen only, or touch screen arm and operation and supplied of the main text or files specified by a type of saved data.  BISMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  alization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese  of errors and warnings when they occur.  een keyboard.  I point and break characters in data saved to waveform erical calculation result files  Period, comma  Comma, space, tab, semicolon  I time, date, data values   |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Self-check  Language  Error and warning display Touch keyboard  Region specifications  Time value display Zero position display Waveform screen background color  Restart permission  Display settings Time settings  | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR793  Waveforms not supply Waveforms not supply Waveforms not supply Waveforms saved vaveforms saved vaveforms saved vaveforms saved vaveforms general  "When the Available Previous" The HDI that order variety of setting vaveform are autor vaveform data initi Memory, LCD, butt English, Japanese, Displays the on-scr Settings for decimal point Break Hours, sexagesima ON / OFF  Black or white  Permitted / Not permitte unit is restarted. "Not permitted value brightness of Set the date and tir ON / OFF  Protects the system recommend turning recommend turning recommend turning the set of the system recommend turning the province of | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model To75 Waveform Generator ted with Model SF8000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP SET) to start up.  D/SSD, SD memory card, and USB memory are searched, in for the save location. It is sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. In can be allocated.  The sampling rate and measurement range, compression rate, or osition can be changed and the cursor can be moved. In can be allocated.  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically set.)  The sampling rate and measurement range for the input matically included the sampling rate and measurement range for the input matically included the sampling rate and measurement range for the input matically included the sample sampling rate and measurement range for the input measuring process, the smitted. If settings are changed during th |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and waming display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings  Time settings  System protection | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT U8793  Waveforms not sup Waveforms not sup Waveforms not sup Waveforms saved v Waveforms general  "When th previous!  X In the hor display p Y In the ver or display S1, S2 A function Available (The opti waveform are autor "Not available for e Three levels of setti and hard buttons.  OFF, alarm only, ale Sending e-mails vie Sending timing Sent data  Waveform data initi Memory, LCD, buttle English, Japanese, Displays the details Displays the on-scr Settings for decima (text) files and num Decimal point Break Hours, sexagesima ON / OFF Black or white Permitted / Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte into restarted. "Not permitte into restarted." Not permitte into restarted. "Not permitte into restarted." Not permitte unit is restarted. "Not permitte into restarted." Not permitte into restarted. "Not permitte unit is restarted." Not permitte into restarted. "Not permitte into restarted." Not permitte unit is restarted. "Not permitte into restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." Not permitte unit is restarted. "Not permitte unit is restarted." No | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, traingular wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model Synchroma of the waveform denerator teed with Model Synchroma of the waveform denerator teed with Model Synchroma of the waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up.  JOSSD, SD memory card, and USB memory are searched, in y, for the save location.  Izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The allocated of the cursor can be moved. In can be allocated.  The cursor can be changed and the cursor can be moved. In can be allocated.  The cursor can be changed and the cursor can be moved. In can be allocated.  The cursor can be changed the cursor can be moved. In can be allocated.  The cursor can be changed the cursor can be moved. In can be allocated.  The cursor can be changed during the measuring process, the emitted. If settings cannot be changed during the measuring process. In the cursor can be changed during the measuring process. In the cursor can be cal |
| Waveform types  Supported waveforms for output (U8793 only)  Other  Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings  Time settings  System protection  function                       | control  WAVEFORM GENERATOR UNIT MR8790  PULSE GENERATOR UNIT MR8791  ARBITRARY WAVEFORM GENERATOR UNIT UR393  Waveforms not supp Waveforms not supp Waveforms not supp Waveforms not supp Waveforms saved v Waveforms saved v Waveforms general  "When the Available "The HDI that order or display p Y In the ver or display p Y In the ver or display p Y In the ver or display p S1, S2 A function Available (The optir waveform are autor Not available for e Three levels of setting and hard buttons.  OFF, alarm only, ali Sending e-mails via Sending e-mails via Sending timing  Sent data  Waveform data intit Memory, LCD, butt English, Japanese, Displays the on-scr Settings for decimal (text) files and num Decimal point Break  Hours, sexagesima ON / OFF  Black or white  Permitted / Not permitte unit is restarted. "Not permitted in the date and tir ON / OFF  Black or white  Permitted / Not permitte unit is restarted. "Not permitted in the date and tir ON / OFF  Protects the system recommend turning external UPS when  | generated signals via all channels in sync with one another.  Synchronization with measurement: Outputs signals in sync with the start and stop of measurement.  DC, sine wave  pulse, pattern  DC, sine wave, triangular wave, rectangular wave, pulse wave, ramp-up wave, ramp-down wave, arbitrary waveform, programmed waveform ed with Model MR6000/MR6000-01 Memory HiCorder (logic ported) with Model 7075 Waveform Generator ed with Model S78000 Waveform Maker  e power is turned on, the unit loads the settings data y saved (STARTUP, SET) to start up.  J/SSD, SD memory card, and USB memory are searched, in for the save location.  izontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. It call direction, the measurement range, compression rate, or position can be changed and the cursor can be moved. In can be allocated.  In can be allocated.  In all sampling rate and measurement range for the input matically set.)  In some available: OFF, touch screen only, or touch screen arm and operation  Is MITP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data.  alization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese  of errors and warnings when they occur.  een keyboard.  I point and break characters in data saved to waveform encal calculation result files  Period, comma  Comma, space, tab, semicolon  I time, date, data values  of Permitted: If settings are changed during the measuring process, the emitted: Settings cannot be changed during the measuring process, the emitted: Settings cannot be changed during the measuring process, the semitted: Settings cannot be changed during the measuring process, the semitted: Settings cannot be changed during the measuring process, the semitted: Settings cannot be changed during the measuring process, the semitted: Settings cannot be changed during the measuring process, the semitted: Settings cannot be changed during  |

#### Option Specifications (sold separately)

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 280 g (9.9 oz). Accessories: None



| 190.5 Hill (7.74 III) D, app | 10x. 200 g (9.9 02)                         | , Accessories. None  |                     |
|------------------------------|---|--|---------------------|
| HIGH SPEED ANAL<br>U8976     | OG UNIT                                     | (Accuracy at 23 $\pm 5^{\circ}\text{C/73}$ $\pm 9^{\circ}\text{F}$ , 20 to 80% RH awarm-up time and zero adjustment; Accuracy                            |                     |
| Measurement functions        | No. of channels: 2, t                       | or voltage measurement   |                     |
| Input terminals              | Max. rated voltage t<br>the maximum voltage | ector (input impedance 1 $M\Omega$ , input capa to ground:1000 V AC, DC (with input isolate that can be applied between input characters without damage) | ated from the unit, |
| Measurement range            |   | 100, 200, 400 V f.s., 12 ranges<br>ssible measurement/display: 280 V rms   |                     |
| Measurement resolution       | 1/1600 of measuren                          | nent range (using 12-bit A/D conversion)   |                     |
| Maximum sampling rate        | 200 MS/s (simultane                         | eous sampling in 2 channels)   |                     |
| Measurement accuracy         | ±0.5% f.s. (with filte                      | r 5 Hz, zero position accuracy included)   |                     |
| Frequency characteristics    | DC to 30 MHz -3 dE                          | (with AC coupling: 7 Hz to 30 MHz -3 df  | 3)                  |
| Input coupling               | AC/DC/GND                                   |  |                     |
| Maximum input voltage        | 400 V DC (with dire                         | ct input), 1000 V DC (with 9665)   | •                   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



| 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None |   |                    |
|---|---|--------------------|
| ANALOG UNIT 896   | (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 3 up time and zero adjustment; Accuracy guaranteed   |                    |
| Measurement functions   | No. of channels: 2, for voltage measurement   |                    |
| Input terminals   | Isolated BNC connector (input impedance 1 M $\Omega$ , input capacita Max, rated voltage to ground: 300 V AC, DC (with input isolated maximum voltage that can be applied between input channel ar between input channels without damage) | from the unit, the |
| Measurement range   | 100, 200, 400 mV f.s.<br>1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges<br>AC voltage for possible measurement/display: 280 V rms<br>Low-pass filter: 5/50/500/5 k/50 k/500 kHz   |                    |
| Measurement resolution  | 1/2000 of measurement range (using 12-bit A/D conversion)   |                    |
| Maximum sampling rate   | 20 MS/s (simultaneous sampling across 2 channels)   |                    |
| Measurement accuracy  | ±0.5% f.s. (with filter 5 Hz, zero position accuracy included)  |                    |
| Frequency characteristics                                       | DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)   |                    |
| Input coupling  | AC/DC/GND   |                    |
| Maximum input voltage   | 400 V DC (the maximum voltage that can be applied across input pin  | s without damage)  |
|   |   |                    |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D. approx. 250 g (8.8 gz). Accessories: None



| 196.5 mm (7.74 m) D, approx. 250 g (8.8 oz), Accessories: None |   |   |                            |
|--|---|---|----------------------------|
| 4CH ANALOG UNI   | T U8975                                 | (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% warm-up time and zero adjustment; Accu  |                            |
| Measurement functions  | No. of channels: 4,                     | for voltage measurement   |                            |
| Input terminals  | Max. rated voltage<br>maximum voltage t | nector (input impedance 1 $M\Omega$ , input c<br>to ground: 300 V AC, DC (with input is<br>that can be applied between input cha<br>nnels without damage) | solated from the unit, the |
| Measurement range  |   | 200 V f.s., 6 ranges<br>sible measurement/display: 140 V rms<br>500/5 k/200 kHz   | 3                          |
| Measurement resolution   | 1/32,000 of measu                       | rement range (using 16-bit A/D conve  | rsion)                     |
| Maximum sampling rate  | 5 MS/s (simultaneo                      | ous sampling in 4 channels)   |                            |
| Measurement accuracy   | ±0.1% f.s. (with filte                  | er 5 Hz, zero position accuracy include   | ed)                        |
| Frequency characteristics                                      | DC to 2 MHz -3 dB                       | 1   |                            |
| Input coupling   | DC/GND                                  |   |                            |
| Maximum input voltage  | 200 V DC (the maxin                     | num voltage that can be applied across in   | nput pins without damage)  |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



|                           |  | ,,   |        |
|---------------------------|--|--|--------|
| 4CH ANALOG UNI            | T U8978  | (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes warm-up time and zero adjustment; Accuracy guaranteed for  |        |
| Measurement functions     | No. of channels: 4   | I, for voltage measurement   |        |
| Input terminals           | Max. rated voltage<br>(CAT II) when cor                      | nector (input impedance 1 M $\Omega$ , input capacitance 30 pF; e to ground: 30 V AC or 60V DC for direct input, 300 V Ambined with the 9665 (Between each input channel a tween the input channels) | AC, DC |
| Measurement range         | 100, 200, 400 mV<br>1, 2, 4, 10, 20, 40 Low-pass filter: 5/5 | V f.s., 9 ranges   |        |
| Measurement resolution    | 1/32,000 of measu  | urement range (using 16-bit A/D conversion)  |        |
| Maximum sampling rate     | 5 MS/s (simultaneo   | ous sampling in 4 channels)  |        |
| Measurement accuracy      | ±0.3% f.s. (with filt  | ter 5 Hz, zero position accuracy included)   |        |
| Frequency characteristics | DC to 2 MHz -3 dE  | В  |        |
| Input coupling            | DC / GND   |  |        |
| Maximum input voltage     | 40 V DC (with dire   | ect input), 400 V DC (with 9665)   |        |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 260 g (9.2 oz), Accessories: None



| 100.0 mm (7.7 mm) 2, approx. 200 g (6.2 02), 7.0000001100. Note                                      |  |  |
|--|--|--|
|  |  |  |
| No. of channels: 2, for DC voltage measurement   |  |  |
| 10 V f.s. range, otherwise 10 M $\Omega$ ) Max. rated voltage to ground: 300 V AC, DC (with input is | solated from the unit, the   |  |
| 100, 1000 mV f.s.<br>10, 100, 1000 V f.s., 5 ranges  |  |  |
| 1/1,000,000 of measurement range (using 24-bit $\Delta\Sigma$ mod                                    | dulation A/D)  |  |
| 20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during   | 60 Hz)   |  |
| 2 ms +2× integration time or less (rise - f.s. $\rightarrow$ + f.s., fall +                          | + f.s. → - f.s.)   |  |
| ±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)   |  |  |
| 500 V DC (the maximum voltage that can be applied across in  | nput pins without damage)  |  |
|  | TER UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RI warm-up time and calibration, Accuracy gue No. of channels: 2, for DC voltage measurement Banana input connectors (Input resistance: 100 MΩ or hi 10 vf.s. range, otherwise 10 MΩ) Max. rated voltage to ground: 300 V AC, DC (with input is maximum voltage that can be applied between input chabetween input channels without damage) 100, 1000 mV f.s. 10, 100, 1000 v f.s., 5 ranges 1/1,000,000 of measurement range (using 24-bit $\Delta\Sigma$ mod 20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 2 ms +2× integration time or less (rise - f.s. $\rightarrow$ + f.s., fall - |  |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



| HIGH RESOLUTIO<br>8968    | N UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)   |
|---------------------------|---|
| Measurement functions     | No. of channels: 2, for voltage measurement   |
| Input terminals           | Isolated BNC connector (input impedance 1 MΩ, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage) |
| Measurement range         | 100, 200, 400 mV f.s.<br>1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges<br>AC voltage for possible measurement/display: 280 V rms<br>Low-pass filter: 5/50/500/5 k/50 kHz   |
| Anti-aliasing filter      | Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)   |
| Measurement resolution    | 1/32,000 of measurement range (using 16-bit A/D conversion)   |
| Maximum sampling rate     | 1 MS/s (simultaneous sampling across 2 channels)  |
| Measurement accuracy      | ±0.3% f.s. (with filter 5 Hz, zero position accuracy included)  |
| Frequency characteristics | DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)   |
| Input coupling            | AC/DC/GND   |
| Maximum input voltage     | 400 V DC (the maximum voltage that can be applied across input pins without damage)   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



| 100:0 ::::: (1:: 1:::) B; app |   |
|-------------------------------|---|
| DC/RMS UNIT 897               | 2 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)  |
| Measurement functions         | No. of channels: 2, for voltage measurement, DC/RMS selectable  |
| Input terminals               | Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage) |
| Measurement range             | 100, 200, 400 mV f.s.<br>1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges<br>AC voltage for possible measurement/display: 280 V rms<br>Low-pass filter: 5/50/500/5 k/100 kHz  |
| Measurement resolution        | 1/2000 of measurement range (using 12-bit A/D conversion)   |
| Maximum sampling rate         | 1 MS/s (simultaneous sampling across 2 channels)  |
| Measurement accuracy          | ±0.5% f.s. (with filter 5 Hz, zero position accuracy included)  |
| RMS measurement               | RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz) ±3% f.s. (1 kHz to 100 kHz) Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), FAST 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2                    |
| Frequency characteristics     | DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)   |
| Input coupling                | AC/DC/GND   |
| Maximum input voltage         | 400 V DC (the maximum voltage that can be applied across input pins without damage)   |
|                               |   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz), Accessories: None



| HIGH-VOLTAGE UI<br>U8974  | NIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)  |
|---------------------------|---|
| Measurement functions     | No. of channels: 2, for voltage measurement, DC/RMS selectable  |
| Input terminals           | Banana input terminal (Input impedance: $4 M\Omega$ , Input capacitance: $5 pF$ ) Max. rated voltage to ground: $1000 V$ AC, DC for measurement category III, $600 V$ AC, DC for measurement category IV (Between each input channel and the main unit, and between the input channels) |
| Measurement range         | 4, 10, 20, 40, 100, 200, 400, 1000 V f.s. (DC mode), 8 ranges<br>10, 20, 40, 100, 200, 400, 1000 V f.s. (RMS mode), 7 ranges<br>Low-pass filter: 5/50/500/5 k/50 kHz  |
| Measurement resolution    | 1/32,000 of measurement range (using 16-bit A/D conversion)   |
| Maximum sampling rate     | 1 MS/s  |
| Measurement accuracy      | ±0.25% f.s. (with filter 5 Hz, zero position accuracy included)   |
| RMS measurement           | RMS accuracy: $\pm$ 1.5% f.s. (DC, 30 Hz to 1 kHz), $\pm$ 3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s   |
| Frequency characteristics | DC to 100 kHz -3 dB   |
| Input coupling            | DC / GND  |
| Maximum input voltage     | 1000 V DC, 700 V AC   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 245 g (8.6 oz), Accessories: CONVERSION CABLE L9769  $\times$  2 (cable length 60 cm (1.97 ft))



| STRAIN UNIT U89                              | (Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less after 30 minutes of warm-up time and auto-balance; Accuracy guaranteed for 1 year)   |  |
|--|---|--|
| Measurement functions                        | No. of channels: 2, for distortion measurement (electronic auto-balancing, balance adjustment range within ±10,000 με or less)  |  |
| Input terminals                              | NDIS connector EPRC07-R9FNDIS (via CONVERSION CABLE L9769, NDIS connector PRC03-12A10-7M10.5) Max. rated voltage to ground: 30 V AC rms or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage) |  |
| Suitable transducer                          | Strain gauge converter, Bridge impedance: 120 $\Omega$ to 1 k $\Omega$ , Bridge voltage: 2 V ±0.05 V, Gauge rate: 2.0   |  |
| Measurement range                            | 400, 1000, 2000, 4000, 10,000, 20,000 με f.s., 6 ranges<br>Low-pass filter: 5/10/100/1 kHz  |  |
| Measurement resolution                       | 1/25,000 of measurement range (using 16-bit A/D conversion)   |  |
| Maximum sampling rate                        | 200 kS/s (simultaneous sampling across 2 channels)  |  |
| Measurement accuracy<br>After auto-balancing | ±0.5% f.s. ±4 με (5 Hz filter ON)   |  |
| Frequency characteristics                    | DC to 20 kHz +1/-3 dB   |  |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 190 g (6.7 oz), Accessories: None



| LOGIC UNIT 8973       |  |
|-----------------------|--|
| Measurement functions | No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)                                   |
|                       | Mini DIN connector (for HIOKI logic probes only),<br>Compatible logic probes: 9320-01, 9327, MR9321-01 |



3CH CURRENT UNIT U8977 Measurement functions No. of channels: 3, Current measurement with optional current sensor Dedicated connector terminal (ME15W) (input impedance 1 MΩ, commor Input terminals GND with recorder) 9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6846-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876, Compatible current CT6877 (Direct connection)
CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045,
CT7046 (Connection using optional CONVERSION CABLE CT9920)
- Directly connected current sensor: Automatically identify rating of sensors compatible current sensors Using 9272-05 (20 A), CT6841A: 2 A/ 4 A/ 10 A/ 20 A/ 40 A/ 100 A f.s. Using CT6862-05, CT6872: 4 A/ 10 A/ 20 A/ 40 A/ 100 A/ 200 A f.s. Using 9272-05 (200 A), CT6843A, CT6863-05, CT6873: 20 A/ 40 A/ 100 A/ 200 A/ 400 A/ 1000 A f.s. Jsing CT6844A, CT6845A, CT6904A, CT6875A 40 A/ 100 A/ 200 A/ 400 A/ 1000 A/ 2000 A f.s Using CT6846A, CT6876A: Measurement range 100 A/ 200 A/ 400 A/ 1000 A/ 2000 A/ 4000 A f.s. Using CT6877A: 200 A/400 A/1000 A/2000 A/4000 A/10000 A f.s. Current sensors connected using CT9920: Select conversion rate or model Using CT7631, CT7731: 200 A Using CT7636, CT7736: 200 A/ 400 A/ 1000 A Using CT7642, CT7742: 2000 A/ 4000 A Using CT7044, CT7045, CT7046: 2000 A/ 4000 A/ 10000 A The measurable range is limited by the connected sensor(s). Please check your current sensors' specifications Measurement accuracy (with 5 Hz filter ON) +0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB Note: Add the accuracy and attributes of the current sensor being used. Measurement resolution 1/32,000 of measurement range (using 16-bit A/D conversion) Maximum sampling rate 5 MS/s (simultaneous sampling in 3 channels) Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz), Accessories: None



(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after up time and zero adjustment; Accuracy guarantee **CHARGE UNIT U8979** Measurement functions No. of channels: 2, for acceleration measuremen Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance 1 MΩ, input capacitance 200 pF or less)
Charge input: Miniature connector (#10-32UNF) Max. rated voltage to ground: 30 V AC or 60 V DC (with input isolated from Input terminals the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)

\*Voltage input terminal GND and charge input terminal GND for the same channel are shared. Charge output type acceleration detector Pre-amp embedded acceleration detector (IEPE type) Suitable transducer 1 (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC /(m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV /(m/s²) Measurement range Charge input (Miniature connector) Amplitude accuracy: ±2% f.s. Frequency characteristics: 1(1.5) to 50 kHz 3 dB (charge input) Low-pass filter: 500/5 kHz Pre-amp embedded input (BNC connector) Pre-amp supply power: 3.5 mA ±20%. 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side) 10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to Measurement range Voltage input (BNC connector) 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND Maximum input voltage: 40 V DC Measurement resolution 1/25,000 of measurement range (using 16-bit A/D conversion) Maximum sampling rate 200 kS/s Integrated filter for suppressing aliasing distortion caused by FFT Anti-aliasing filter essing (automatic cutoff frequency setting/OFF) IEEE 1451.4 class 1 support (Support for sensor information reading and **TEDS** automatic sensitivity setting)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



| FREQ UNIT 8970                          | (Accuracy at 23 $\pm$ 5°C/73 $\pm$ 9°F, 20 to 80 % RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year)   |
|---|---|
| Measurement functions                   | No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width  |
| Input terminals                         | Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, $DC$ (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage) |
| Frequency mode                          | Measurement range: Between DC to 100 kHz (minimum pulse width 2 μs), 20 Hz to 100 kHz f.s., 8 ranges Accuracy: ±0.1% f.s. (exclude 100 kHz range), ±0.7% f.s. (100 kHz range)   |
| Rotation mode                           | Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2 µs), 2 kr/min to 2 Mr/min f.s, 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)  |
| Power frequency mode                    | Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges  Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)   |
| Integration mode                        | Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.  |
| Duty ratio mode                         | Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 μs), 100% f.s. Accuracy: ±1% (10 to 10 kHz), ±4% (10 k to 100 kHz)   |
| Pulse width mode                        | Measurement range: Between 2 μs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.  |
| Measurement resolution                  | 0.0025% f.s. (Integration mode), 0.01% f.s. (exclude integration, power frequency mode), 0.01 Hz (power frequency mode)   |
| Input voltage range and threshold level | ±10 V to ±400 V, 6 ranges, selectable threshold level at each range   |
| Other functions                         | Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling, Frequency dividing, Integration over-range keep/return   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: CONVERSION CABLE 9318  $\times$  2 (To connect the current sensor to the 8971)



| CURRENT UNIT 89  | (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-<br>up time and zero adjustment; Accuracy guaranteed for 1 year)  |
|--|---|
| Measurement functions  | No. of channels: 2, Current measurement with optional current sensor  |
| Input terminals  | Sensor connector (input impedance 1 $M\Omega$ , exclusive connector for current sensor via conversion cable the 9318, common GND with recorder)   |
| Compatible current sensors   | CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)  |
| Measurement range  | Using 9272-10 (20 A), CT6841A: 2 A/ 4 A/ 10 A/ 20 A/ 40 A/ 100 A f.s. Using CT6862-05, CT6872: 4 A/ 10 A/ 20 A/ 40 A/ 100 A/ 200 A f.s. Using 9272-05 (200 A), CT6843A, CT6863-05, CT6873: 20 A/ 40 A/ 100 A/ 200 A/ 400 A/ 1000 A f.s. Using CT6844A, CT6845A, CT6846A, CT6875A, CT6876A: 40 A/100 A/200 A/400 A/1000 A/2000 A f.s. How to connect to 8971: use Conversion Cable 9318 + Conversion Cable CT9901 **The measurable range is limited by the connected sensor(s). Please check your current sensor's specifications. |
| Measurement accuracy<br>(with 5 Hz filter ON)<br>Note: Add the accuracy<br>and attributes of the current<br>sensor being used. | ±0.65% f.s. RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz) RMS response time: 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2 Frequency characteristics: DC to 100 kHz ±3 dB (with AC coupling: 7 Hz to 100 kHz   |
| Measurement resolution   | 1/2000 of measurement range (using 12-bit A/D conversion)   |
| Maximum sampling rate  | 1 MS/s (simultaneous sampling across 2 channels)  |
| Other functions  | Input coupling: AC/DC/GND, Low-pass filter: 5/50/500/5 k/50 kHz   |

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 204.5 mm (8.05 in) D, approx. 240 g (8.5 oz), Accessories: Ferrite clamp x 2



| 204.5 mm (8.05 m) D, app  | orox. 240 g (8.5 oz), Accessories: Ferrite clamp x 2  |
|---|---|
| TEMP UNIT 8967  | (Accuracy at 23 $\pm$ 5°C/73 $\pm$ 9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year)  |
| Measurement functions   | No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)   |
| Input terminals   | Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter $\Phi$ 0.18 mm (0.01 in) or more), AWG 26 to 16 Input impedance: min. 5 M $\Omega$ (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)   |
| Temperature measurement range Note: Upper and lower limit values depend on the thermocouple | 200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges  Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion  |
| Thermocouple range<br>(JIS C 1602-1995)<br>(ASTM E-988-96)                                  | K: -200°C to 1350°C (-328°F to 2462°F), J: -200°C to 1100°C (-328°F to 2012°F), E: -200°C to 800°C (-328°F to 1472°F), T: -200°C to 400°C (-328°F to 752°F), N: -200°C to 1300°C (-328°F to 2372°F), R: 0°C to 1700°C (32°F to 3092°F), S: 0°C to 1700°C (32°F to 3092°F), B: 400°C to 1800°C (752°F to 3632°F), WRe5-26); 0 to 2000°C (32°F to 3632°F) Reference junction compensation: internal/ external (switchable), line fault detection ON/OFF possible  |
| Data refresh rate   | 3 methods, Fast:1.2 ms (digital filter OFF), Normal:100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)   |
| Measurement accuracy  | Thermocouple K, J, E, T, N: $\pm$ 0.1% f.s. $\pm$ 1°C ( $\pm$ 1.8°F), ( $\pm$ 0.1% f.s. $\pm$ 2°C ( $\pm$ 3.6°F) at -200°C to 0°C ( $\pm$ 328°F to 32°F)) Thermocouple R, S, B, W: $\pm$ 0.1% f.s. $\pm$ 3.5°C ( $\pm$ 6.3°F)(at 0°C ( $\pm$ 22°F); to less than 400°C ( $\pm$ 52°F); However, no accuracy guarantee at less than 400°C ( $\pm$ 752°F) for B), $\pm$ 0.1% f.s. $\pm$ 3°C ( $\pm$ 5.4°F) (at 400°C or more) Reference junction compensation [RJC] accuracy: $\pm$ 1.5°C ( $\pm$ 2.7°F) (added to measurement accuracy with internal reference junction compensation) |

Dimensions and mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz), Accessories: None



| ARBITRARY WAVER                   | Power supply frequency range of installed MEMORY HiCORDER at 50 Hz/60 Hz +2 Hz.  |  |  |  |  |  |
|-----------------------------------|--|--|--|--|--|--|
| Output terminal                   | Number of channels: 2, SMB terminal (Output impedance: 1 Ω or less) Max. rated voltage to ground: 33 V rms AC or 70 V DC               |  |  |  |  |  |
| Output voltage range              | -10 V to 15 V (Amplitude setting range: 0 V to 20 V p-p, Setting resolution: 1 mV  |  |  |  |  |  |
| Max. output current               | 10 mA (Allowable load resistance: 1.5 kΩ or more)  |  |  |  |  |  |
| FG function                       | DC, Sine wave, Square wave, Pulse wave, Triangular wave, Ramp wave, Output frequency: 0 Hz to 100 kHz                                  |  |  |  |  |  |
| Arbitrary waveform generator mode | Waveforms measured by MR8847A, etc., generated by Hioki Model 7075 or SF8000, CSV waveforms D/A refresh rate: 2 MHz (using 16-bit D/A) |  |  |  |  |  |
| Sweep function                    | Frequency, Amplitude, Offset, Duty (Pulse only)  |  |  |  |  |  |
| Program function                  | Max. 128 steps (Number of loops for each step, Number of total loops)  |  |  |  |  |  |
| Other                             | Self-test function (Voltage), External input/output control  |  |  |  |  |  |

Dimensions and weight: approx.  $106 \, \text{mm} (4.17 \, \text{in.}) \, \text{W} \times 19.8 \, \text{mm} (0.78 \, \text{in.}) \, \text{H} \times 196.5 \, \text{mm} (7.74 \, \text{in.}) \, \text{D}$ , approx.  $230 \, \text{g} (8.1 \, \text{oz.})$ , Accessories: none



| WAVEFORM GENE        | RATOR UNIT MR8790 (Accuracy at 23 ±5°C [73 ±9°F], 80% rh after 30 minutes of warm-up time; accuracy guaranteed for 1 year) |  |  |  |  |  |
|----------------------|--|--|--|--|--|--|
| Output terminal      | Number of channels: 4, SMB terminal (output impedance: 1 Ω or less)  |  |  |  |  |  |
|                      | Max. rated voltage to ground: 30 V rms AC or 60 V DC   |  |  |  |  |  |
| Output voltage range | -10 V to 10 V (amplitude setting range: 0 V to 20 V p-p, setting resolution: 1 mV)   |  |  |  |  |  |
| Max. output current  | 5 mA   |  |  |  |  |  |
| Output function      | DC, sine wave (output frequency range: 0 Hz to 20 kHz)   |  |  |  |  |  |
|                      | Amplitude accuracy: ±0.25% of setting ±2 mV p-p (1 Hz to 10 kHz)   |  |  |  |  |  |
| Accuracy             | Offset accuracy: ±3 mV   |  |  |  |  |  |
|                      | DC output accuracy: ±0.6 mV  |  |  |  |  |  |
| Other                | Self-test function (voltage, current)  |  |  |  |  |  |

Dimensions and weight: approx. 106 mm (4.17 in.) W  $\times$  19.8 mm (0.78 in.) H  $\times$  196.5 mm (7.74 in.) D, approx. 230 g (8.1 oz.), Accessories: none



| PULSE GENER     | ATOR UNIT MR8791  | (Accuracy at 23 ±5°C [73 ±9°F], 80% rh or less with no condensation; accuracy guaranteed for 1 year)                                |  |  |  |  |
|-----------------|---|---|--|--|--|--|
| Output terminal |   | ector: D-sub, half-pitch, 50-pin<br>10 V rms AC or 60 V DC (between unit and output channels)<br>output                             |  |  |  |  |
| Output mode 1   |   | Pattern output: read frequency: 0 Hz to 120 kHz, 2,048 logic patterns<br>Pulse output: frequency 0 Hz to 20 kHz, duty 0.1% to 99.9% |  |  |  |  |
| Output mode 2   | Logic output voltage level: 0<br>(high level: 3.8 V or more, lo<br>Open collector output: 50 V<br>Overcurrent protection: 100 | w level: 0.8 V or less) absolute maximum rated voltage for collector/emitter  |  |  |  |  |
| Other           | Self-test function  |   |  |  |  |  |

### System Chart of Options

All prices are exclusive of tax.



#### Factory-installed option A \*Must specify when ordering

\*Power can be supplied to up to 9 current sensors, including the current sensors connected to the CURRENT UNIT US977 and CURRENT UNIT 8971.



PROBE POWER UNIT Z5021 Specified upon order, ±12 V DC, supply for up to 8 probes

#### Factory-installed option B

\*Must specify when ordering



SSD UNIT U8332 Specified upon order; built-in type, 256 GB

#### Factory-installed option C



HD UNIT U8333 Specified upon order; built-in type, 320 GB

#### Storage media

\*Use only the storage media sold by HIOKI. Compatibility and performance are not guaranteed for storage media made by other manufacturers. You may be unable to read from or save data to such media.



SD MEMORY CARD Z4001 2 GB

SD MEMORY CARD Z4003 8 GB

USB DRIVE Z4006

16 GB Using highly durable and reliable SLC flash memory

#### Non-contact CAN measurement



Non-Contact CAN Sensor SP7001-90 CAN FD/CAN support, bundle including SP7001/SP7100/SP9200, use by connecting to Vector interface or similar product,

Non-Contact CAN Sensor SP7002-90 CAN support,

bundle including SP7002/SP7100/SP9200, use by connecting to Vector interface or similar

#### Case



CARRYING CASE C1010

For the MR6000, hard trunk type, for storing

Waveform Viewer Wv

..Standard accessory

#### HIGH SPEED ANALOG UNIT U8976 2 ch, voltage input, 200 MS/s, (DC to 30 MHz)

**ANALOG UNIT 8966** 

Input modules

2 ch, voltage input, 20 MS/s, (DC to 5 MHz)

4CH ANALOG UNIT U8975 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), Input voltage limit: 200 V DC

4CH ANALOG UNIT U8978 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.

HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)

DC/RMS UNIT 8972

2 ch, voltage/1 MS/s, (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz)

HIGH-VOLTAGE UNIT U8974 2 ch, voltage input, max. 1000 V DC and 700 V AC

DIGITAL VOLTMETER UNIT MR8990

2 ch, high-precision DC voltage, 0.1 µV resolution, maximum sampling rate 500 times/s

3CH CURRENT UNIT U8977

3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units

**CURRENT UNIT 8971** 

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units

TEMP UNIT 8967

2 ch, thermocouple temperature input

STRAIN UNIT U8969

2 ch, strain gauge type converter amp

CONVERSION CABLE L9769 (for STRAIN UNIT U8969 only, included)

FREQ UNIT 8970

2 ch, for measurement of frequency, RPM, pulse, etc.

CHARGE UNIT U8979
2 ch, for acceleration measurement, supports charge output, pre-amp output (IEPE type), and voltage output

LOGIC UNIT 8973

4 terminals, 16 ch, installable in all 8 slots

#### Output modules \* Input cords not included. Please purchase separately



ARBITRARY WAVEFORM GENERATOR UNIT U8793 2 ch, 10 mHz to 100kHz FG, -10 V to 15 V output, D/A refresh rate (arbitrary waveform generator mode): 2 MHz

WAVEFORM GENERATOR UNIT MR8790

PULSE GENERATOR UNIT MR8791

8 ch, 0.1 Hz to 20 kHz pulse output, pattern output

#### Logic signal measurement



LOGIC PROBE 9327 LOGIC PROBE 9320-01

4-channel type, for voltage/contact signal ON/OFF detection Not isolated Response pulse width: 500 ns or more (9320-01), 100 ns or more (9327) Digital input threshold: 1.4 V / 2.5 V / 4.0 V Maximum input voltage: 0 to +50 V DC

Logic Probe MR9321-01



4 channels, ON/OFF detection of AC/DC voltage

Isolated
Response time: rising, 1 ms or less; falling, 3 ms or less
Output (H) detection: 170 to 250 V AC, ±(70 to 250) V DC (HIGH range)
60 to 150 V AC, ±(20 to 150) V DC (LOW range)
Output (L) detection: 0 to 30 V AC, ±(0 to 43) V DC (HIGH range)
0 to 10 V AC, ±(0 to 15) V DC (LOW range)
Maximum input voltage: 250 Vrms (HIGH range), 150 Vrms (LOW range)

#### External sampling measurement



CONNECTION CABLE L9795-01 Max. rated voltage to ground: 33 V AC rr SMB terminal to alligator clip, 1.5 m (4.92 ft)

CONNECTION CABLE L9795-02

Max. rated voltage to ground: 33 V AC rms or 70 V DC, SMB terminal to BNC terminal, 1.5 m (4.92 ft)

#### **PC Software**



MR6000 Viewer Software that provides operability similar to the MR6000, allowing you to load measurement data splay waveforms, and perform ...Free download

Naveform Viewer vvv Software for checking waveforms with binary data on a PO, saving data in CSV format, and transferring to spreadsheet programs



WAVE PROCESSOR 9335 LAN CABLE 9642 PC display for massive amounts of waveform data and more

Straight Ethernet cable, supplied with straight to cross conversion cable, 5 m (16.41 ft) length

ent \* PL14 terminal type

AC/DC AUTO ZERO CURRENT SENSOR CT7731

AC/DC AUTO ZERO CURRENT SENSOR CT7736

AC/DC AUTO ZERO CURRENT SENSOR CT7742

AC/DC CURRENT SENSOR CT7631

AC/DC CURRENT SENSOR CT7636

AC/DC CURRENT SENSOR CT7642 DC, 1 Hz to 10 kHz, 2,000 A

AC FLEXIBLE CURRENT SENSOR CT7044

AC FLEXIBLE CURRENT SENSOR CT7046 \$\phi 254 \text{ mm (10.00 in.), 6,000 A}

CONVERSION CABLE CT9920

Convert PL14 terminal to ME15W (12-pin) terminal

SENSOR UNIT CT9555

SENSOR UNIT CT9556

SENSOR UNIT CT9557

4ch, with waveform, total wave

form, and total RMS output

CONNECTION CORD L9217

Cord has insulated BNC connectors at both ends, 1.6 m

(5.25 ft.) length

output

1ch, with waveform and RMS

How to connect to 3CH Current Unit U8977

 $\fbox{ Current sensor (PL14) } + \fbox{ CT9920 } \rightarrow \fbox{ 3CH Current Unit U8977 }$ 

Power supply

For details, see product information on Hioki's website.

General-purpose current measure

DC, 1 Hz to 5 kHz, 100 A

DC, 1 Hz to 5 kHz, 600 A


DC, 1 Hz to 5 kHz, 2,000 A

DC. 1 Hz to 10 kHz. 100 A


DC, 1 Hz to 10 kHz, 600 A


ф100 mm (3.94 in.), 6,000 A AC FLEXIBLE CURRENT SENSOR CT7045


φ180 mm (7.09 in.), 6.000 A













CURRENT PROBE CT6710

CLAMP ON PROBE 3276 Frequency characteristics: DC to 100 MHz wideband response, 10 mA-class up to 30 A rms CLAMP ON PROBE 3274 Frequency characteristics: DC to 10 MHz wideband response, up to 150 A ms

Frequency characteristics: DC to 50 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3275 Frequency characteristics: DC to 2 MHz wideband response, up to 500 A rms

Precautions for connecting current sensors and current probes

\*The bandwidth of current sensors and current probes is limited by the bandwidth of the current unit to be connected.

\*Depending on the combination of current sensors and current

probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables - please inquire with your local distributor.

\*A total of 9 current sensors and current probes can be connected imultaneously to the Memory HiCorder. However, when using the CT6710 or CT6711, a total of 4 probes can be connected. (Total with the CURRENT UNIT U8977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

\*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory HiCorder.

\*If combining a current sensor or current probe with a sensor power source and using the voltage input analog unit for current measurement, there is no limitation on the number of connections.

\*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.



AC ADAPTER Z1013

100 to 240 V AC

(1) Bus powered USB cable

(2) USB(A)- Micro B cable

(3) 3-prong cable



NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width NON-CONTACT AC VOLTAGE PROBE SP3000 Sold individually

AC LEAKAGE CLAMP METER CM4003

AC VOLTAGE PROBE SP9001 Sold individually

#### Other options for input



CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, signal output use, 1.6 m (5.25 ft) length CONVERSION ADAPTER 9199 Receiving side banana terminal, output BNC

#### Temperature sensor



THERMOCOUPLE \*For reference only. Please purchase locally.

#### INPUT CABLE (H)



CONNECTION CABLE 9166 BNC - clips, cable length: 1.5 m (4.92 ft)

INPUT CORD (G) \*For the MR8990 \*Voltage is limited to the specifications of the input modules in use TEST LEAD L2200

BUS BAR CLIP L4936

GRABBER CLIP L9243

MAGNETIC ADAPTER L4937

600 V



Cable length: 70 cm (2.30 ft), tips interchangeable with a pin test lead or alligator clip, maximum input voltage: CAT IV 600 V, CAT III 1000 V

Attach to the tip of banana plug cables, CAT IV 600 V, CAT III 1000 V

Attach to the tip of banana plug cables, CAT III

Attach to the tip of banana plug cables, CAT III

Attaches to the tip of banana plug cables, red/black set, full length: 185 mm (7.28 in), CAT II 1000 V


## R&D testing and analysis Meeting the demanding requirements of a broad range of industries



















We have drastically improved the technology used in our Memory HiCorders, developing the MR6000 Memory HiCorder to meet the advanced demands of all industries.

#### Unit selection guide (18 types)

Unit interchangeability

The following units are compatible with the MR6000. Some units in the list are also compatible with the MEMORY HiCORDER MR8827, MR8847A, MR8740, MR8741, and MR8740-50. Please check the brochure of each product.

| Measurem                          | ent Units |                           |                     |                  |  |                   |   |                            |                  |                              |           |   |
|-----------------------------------|-----------|---------------------------|---------------------|------------------|--|-------------------|---|----------------------------|------------------|------------------------------|-----------|---|
| Measured<br>signal                | Model     | Description               | No. of channels     | Fastest sampling | Bandwidth                                | A/D<br>resolution | DC accuracy                                       | Max. input voltage         | Sensitivity (#1) | Max.<br>sensitivity<br>range | Isolation | Supplement                                    |
| Voltage<br>(high speed)           | U8976     | High-Speed<br>Analog Unit | 2 ch                | 200 MS/s         | DC to 30 MHz                             | 12 bits           | ±0.5% f.s.  | 400 V DC<br>1000 V DC (#2) | 0.0625 mV        | 100 mV f.s.                  | Yes       | n/a   |
| Voltage                           | 8966      | Analog Unit               | 2 ch                | 20 MS/s          | DC to 5 MHz                              | 12 bits           | ±0.5% f.s.  | 400 V DC                   | 0.05 mV          | 100 mV f.s.                  | Yes       | n/a   |
| Voltage<br>(4ch)                  | U8975     | 4ch Analog Unit           | 4 ch                | 5 MS/s           | DC to 2 MHz                              | 16 bits           | ±0.1% f.s.  | 200 V DC                   | 0.125 mV         | 4 V f.s.                     | Yes       | n/a   |
| Voltage<br>(4ch, high resolution) | U8978     | 4ch Analog Unit           | 4 ch                | 5 MS/s           | DC to 2 MHz                              | 16 bits           | ±0.3% f.s.  | 40 V DC                    | 3.125 uV         | 100 mV f.s.                  | Yes       | n/a   |
| Voltage<br>(high resolution)      | 8968      | High Resolution<br>Unit   | 2 ch                | 1 MS/s           | DC to 100 kHz                            | 16 bits           | ±0.3% f.s.  | 400 V DC                   | 3.125 uV         | 100 mV f.s.                  | Yes       | with AAF                                      |
| Voltage<br>(DC, RMS)              | 8972      | DC/RMS Unit               | 2 ch                | 1 MS/s           | DC to 400 kHz                            | 12 bits           | ±0.5% f.s.  | 400 V DC                   | 0.05 mV          | 100 mV f.s.                  | Yes       | with RMS                                      |
| Voltage<br>(high voltage)         | U8974     | High Voltage<br>Unit      | 2 ch                | 1 MS/s           | DC to 100 kHz                            | 16 bits           | ±0.25% f.s.                                       | 1000 V DC<br>700 V AC      | 0.125 mV         | 4 V f.s.                     | Yes       | n/a   |
| Voltage<br>(high resolution)      | MR8990    | Digital<br>Voltmeter Unit | 2 ch                | 2 ms             | n/a                                      | 24 bits           | ±0.01% rdg.<br>±0.0025% f.s.                      | 500 V DC                   | 0.1 uV           | 100 mV f.s.                  | Yes       | n/a   |
| Current                           | U8977     | 3ch Current<br>Unit       | 3ch                 | 5 MS/s           | DC to 2 MHz                              | 16 bits           | ±0.3% f.s.  | Current sensor only        |                  | on current<br>nsor           | n/a       | Max. 3 Units                                  |
| Current                           | 8971      | Current Unit              | 2 ch                | 1 MS/s           | DC to 100 kHz                            | 12 bits           | ±0.65% f.s.                                       | Current sensor only        |                  | on current<br>nsor           | n/a       | with RMS<br>Max. 4 Units                      |
| Temperature                       | 8967      | Temperature<br>Unit       | 2 ch                | 1.2 ms           | DC                                       | 16 bits           | Detailed reference                                | Thermocouples only         | 0.01°C           | 200°C<br>(392°F)f.s.         | Yes       | n/a   |
| Strain                            | U8969     | Strain Unit               | 2 ch                | 200 kS/s         | DC to 20 kHz                             | 16 bits           | ±0.5% f.s.<br>±4 με                               | Strain only                | 0.016 με         | 400 μεf.s.                   | Yes       | Discontinued product<br>8969 can also be used |
| Frequency                         | 8970      | Frequency Unit            | 2 ch                | 200 kS/s         | DC to 100 kHz<br>(#3)                    | 16 bits           | n/a   | 400 V DC                   | 0.002 Hz         | Depends<br>on mode           | Yes       | n/a   |
| Acceleration                      | U8979     | Charge Unit               | 2 ch                | 200 kS/s         | DC to 50 kHz (DC)<br>1 Hz to 50 kHz (AC) | 16 bits           | ±0.5% f.s. (Voltage)<br>±2.0% f.s. (Acceleration) | 40 V DC                    |                  | nds on<br>tion sensor        | Yes       | Supports TEDS                                 |
| Logic                             | 8973      | Logic Unit                | 4 probes<br>(16 ch) | n/a              | n/a                                      | n/a               | n/a   | n/a                        | n/a              | n/a                          | n/a       | Requires 9320-01,<br>9327 or MR9321-01        |

(#1) Minimum resolution shows the highest sensitivity resolution. (#2) When using the 9665 (#3) Minimum pulse width 2 µs

| Output signal       | Model  | Description                          | No. of channels | Output function  | Output voltage range                                 | Supplement |
|---------------------|--------|--------------------------------------|-----------------|--|--|------------|
| Waveform generation | U8793  | Arbitrary Waveform<br>Generator Unit | 2 ch            | FG: Sine, Square, Pulse, Triangle, Ramp, DC<br>Arbitrary waveform generation: Measurement waveform with Memory<br>HiCorder, Waveform editted with the SP8000 | -10 to 15 V  | n/a        |
| Waveform generation | MR8790 | Waveform<br>Generator Unit           | 4 ch            | DC, Sine wave (output frequency range: 0 Hz to 20 kHz)   | -10 to 10 V  | n/a        |
| Pulse generation    | MR8791 | Pulse Generator<br>Unit              | 8 ch            | Pulse output: frequency is 0 Hz to 20 kHz<br>Logic output: output voltage level is 0 V to 5 V, Open collector output   | Output terminal Connector: D-sub, half-pitch, 50-pin | n/a        |

 $Note: \ Company\ names\ and\ product\ names\ appearing\ in\ this\ brochure\ are\ trademarks\ or\ registered\ trademarks\ of\ various\ companies.$ 



Generator Units