

Product Datasheet - Technical Specifications



More information in our Web-Shop at > www.meilhaus.com and in our download section.

Your contact

Technical and commercial sales, price information, quotations, demo/test equipment, consulting:

Tel.:	+49 - 81 41 - 52 71-0		
FAX:	+49 - 81 41 - 52 71-129		
E-Mail: sales@meilhaus.com			
Downloads:			

www.meilhaus.com/en/infos/download.htm

Meilhaus Electronic GmbHTel.Am Sonnenlicht 2Fax82239 Alling/GermanyE-Mat

 Tel.
 +49 - 81 41 - 52 71-0


 Fax
 +49 - 81 41 - 52 71-129

 E-Mail
 sales@meilhaus.com

Mentioned company and product names may be registered trademarks of the respective companies. Prices in Euro plus VAT. Errors and omissions excepted. © Meilhaus Electronic.

www.meilhaus.de

Transmitters: TT230 Series



RTD (Pt, Ni, Cu) or 0-450 ohm input 🔶 4-20mA output (sink/source) 🔶

Description

TT235 Configuration Software

CONFIGURE I/O

Input Options

Output Option

Input Type:

Input Filtering:

Break Direction

Celsiu:

Temperature Units

I/O Scaling

-200.00

(Zero-Scale

No Erro

TEST I/O

Help

The TT235 model is a space-saving two-wire transmitter that isolates and converts an RTD sensor input to a proportional 4-20mA signal. Power is received from the output loop current or a DC supply when using a three-wire connection. The transmitter provides sensor excitation plus performs linearization, lead-wire compensation, and lead-break detection.

Setup and calibration are fast and easy with a convenient USB connection to your PC and Acromag's Windows configuration software.

Get I/O Config

850.00

(Full-Scale)

Send I/O Config

Click "Start Polling" to poll the input and display its value. The LED next to the button will flash when polling is active Click "Stop Polling" to discontinue polling the input.

um 100 Obms, alpha = 0.00385

°C = 20mA Out

(-200.00°C to 850.00°C

tion Setup I/O Config/Test Calibra

RTD PM

°C = 4mA Out

Start Poling Temperature:

Advanced signal processing capabilities, variable range input, and convenient USB programming make this instrument a very versatile temperature measurement device. These transmitters can withstand harsh industrial environments and operate reliably across a wide temperature range with very low drift. They feature RFI, EMI, ESD, EFT, and surge protection plus low radiated emissions.

> TT230 Series Transmitter Configuration Software is downloadable (FREE) from <u>www.acromag.com</u>. Windows XP, Vista, 7, & 8

The Agility™ Config Tool is downloadable (FREE) at the <u>Google Play Store</u> For Android Devices only

12-32V DC loop/local power

Key Features & Benefits

- Easy setup and digital calibration via USB with Windows configuration software
- Selectable RTD or linear resistance input type: Pt RTD (100 Ω , 200 Ω , 500 Ω , or 1000 Ω), Ni RTD (120 Ω), Cu RTD (10 Ω), or Resistance (0-450 Ω)
- 1500V isolation between input/output circuits
- Space-saving 12.5mm (0.5 inch) unit with pluggable terminals for convenient wiring
- High accuracy, linearity, stability, and reliability
- Supports normal or reverse-acting output
- Supports sink or source output wiring
- User-selectable filtering (none, low, med., high)
- Fast response (as low as 22ms)
- Selectable upscale or downscale operation for sensor errors and lead-break detection
- NAMUR-compliant output loop current
- Shock (25g) and vibration (4g) resistant
- Wide ambient operation (-40 to 80°C)
- CE compliant. UL/cUL Class I Div 2, ATEX / IECEx Zone 2 approvals



TT235 Model software allows you to configure transmitters offline, save the file, and download into units later, at your convenience.

Transmitters: TT230 Series

TT235 Isolated RTD/resistance input two-wire transmitter

Performance Specifications

IMPORTANT: To prevent damage or errors from grounded PCs and surges, Acromag strongly recommends use of their USB-ISOLATOR when configuring a TT230 Series transmitter.

USB Interface

USB Connector USB Mini-B type socket, 5-pin.

USB Data Rate 12Mbps. USB v1.1 and 2.0 compatible.

USB Transient Protection Transient voltage suppression on power and data lines.

USB Cable Length

5.0 meters maximum. Driver

Not required. Uses built-in Human Interface Device (HID) USB drivers of the Windows operating system.

Input

Default Configuration

100 Ω Pt RTD, α =0.00385, -200 to 850°C input, 4-20mA output, upscale break detect, medium filter.

Input Configuration

Two-, three- or four-wire sensor input connections.

Programs in °C, °K, °F, or ohmic integer values only.

Input Ranges

Input Type	Input Range	Accuracy ²
RTD, Pt 100Ω	-200 to 850°C	±0.25°C
RTD, Pt 200Ω	-200 to 850°C	±0.30°C
RTD, Pt 500Ω	-200 to 850°C	±0.50°C
RTD, Pt 1000Ω	-200 to 850°C	±1.0°C
Ni 120Ω (Minco 7-120)	-80 to 320°C	±0.08°C
Cu 10Ω (Minco 16-9)	-200 to 270°C	±1.0°C
Resistance (linear)	0 to 25Ω	±0.05Ω
Resistance (linear)	0 to 450Ω	±0.10Ω
Resistance (linear)	0 to 9000Ω	±0.90Ω
Resistance (linear)	0to 2250Ω	±2.25Ω
Resistance (linear) ¹	0 to 4500Ω	±4.50Ω

Note 1: Linear resistance input range approaches but does not include 0Ω and 500Ω . If exactly 0Ω or 500Ω is measured, break detection is triggered.

Note 2: Rated accuracy (in °C and % of span) applies for input spans greater than 5% of input full-scale.

Input Scaling Adjust

Zero: 0 to 95% of range, typical. Full scale: 5 to 100% of full scale range, typical.

Lead Break (Sensor Burnout) Detection

Configurable for either upscale or downscale.



Output

Output Range 4 to 20mA DC Under-range capability 3.5mA Over-range capability 24mA

Output Compliance RLOAD = (VSUPPLY - 11V) / 0.020A. RLOAD = 0 to 650 ohms @ 24V DC

Output DAC Resolution 16-bit D/A converter

Output Accuracy

Better than $\pm 0.05\%$ of span, typical ($\pm 0.1\%$ max.) for for nominal input spans. Includes the effects of repeatability, terminal point conformity, and linearization, but does not include sensor error.

Ambient Temperature Effect

Better than $\pm 0.008\%$ per °C of input span or ± 80 ppm/°C, typical. Includes the combined effects of zero and span drift over temperature.

Output Response Time (for step input change) No filter: 22ms Low filter: 50ms Medium filter: 160ms High filter: 1210ms

Environmental

Operating temperature -40 to 80°C (-40° to 176°F)

Storage temperature -40 to 85°C (-40 to 185°F)

Relative humidity 5 to 95% non-condensing

Power Requirement 12-32V DC SELV (Safety Extra Low Voltage), 24mA maximum.

Shock and Vibration Immunity Vibration: 4g, per IEC 60068-2-6 Shock: 25g, per IEC 60068-2-27

Electromagnetic Compatibility (EMC) Compliance

Radiated Emissions: BS EN 61000-6-4, CISPR 16 RFI: BS EN 61000-6-2, IEC 61000-4-3 Conducted RFI: BS EN 61000-6-2, IEC 61000-4-6 ESD: BS EN 61000-6-2, IEC 61000-4-2 EFT: BS EN 61000-6-2, IEC 61000-4-4 Surge Immunity: BS EN 61000-6-2, IEC 61000-4-5

Approvals

CE compliant. Designed for UL/cUL Class I Division 2 Groups ABCD, ATEX / IECEx Zone 2.

ⓑ II 3 G Ex nA IIC T4 Gc -40°C ≤ Ta ≤ +80°C

Physical

General

General-purpose enclosure designed for mounting on 35mm "T-type" DIN rail.

Case Material

Self-extinguishing polyamide, UL94 V-0 rated, color light gray. General-purpose NEMA Type 1 enclosure.

I/O Connectors

Removable plug-in terminal blocks rated for 12A/250V; AWG #26-12, stranded or solid copper wire.

Dimensions

12.5 x 114.5 x 99.0 mm (0.5 x 4.51 x 3.90 inches)

Shipping Weight 0.22 kg (0.5 pounds) packed

Ordering Information

Models

TT235-0600 Transmitter, isolated RTD/resistance input.

Services

TT230-Config/Cal

Factory custom configuration/calibration service. Specify input type, input/output zero and full-scale values, filtering, and sensor fault settings on order.

Software

TTC-SIP (recommend one kit per customer) Software Interface Package for Acromag TT Series transmitters. Includes configuration software CD-ROM (5040-944), isolator (USB-ISOLATOR) and two USB cables (4001-112, 4001-113).

Accessories

See www.acromag.com for more information.

USB-ISOLATOR

USB-to-USB isolator, includes USB cable (4001-112)






Transmitters: TT Series


Acromag Agility[™] Config Tool Mobile Application

The Agility[™] Config Tool is a mobile application that allows easy setup and configuration of Acromag TT Series transmitters via a tethered mobile device.


This free app is available for Android devices at the Google Play store at <u>Acromag Agility™ Config Tool</u>.

Demo the software, no need for a module. To enter demo mode simply tap the icon in the upper left corner 8 times.





With a couple of taps, quickly configure input, output, unit and scaling options.



Quick and easy access to the wiring diagram, even offline without internet access.

Key Features & Benefits

- Connects to Acromag TT Series transmitters (except models TT231)
- Requires the use of USB OTG Cable (Acromag part #: 5028-565) and USB A to Mini B Cable (Acromag part #: 4001-113)
- Configures and calibrates TT Series products via phone or tablet running Android 4.3 ICS (Ice Cream Sandwich) or later.
- View wiring diagrams, even without an internet connection
- Perform quick and easy field diagnostics and troubleshooting
- Ideal for field technicians

